



STEP 1: Connect to a Wireless Network

This Quick Start Guide covers the most common type of wireless network connection. If your wireless network requires manual configuration refer to the User Guide. Also refer to the “Troubleshooting” section in the User Guide if you encounter any problems.

Turning the **TUNE knob** scrolls through menus and lists to highlight items, and pressing the **TUNE knob** selects a highlighted item.

Connect to a Wireless Network



- a. Plug the AC Power Adapter into an AC outlet, and plug the power plug into the connector on the rear of the SiriusXM Sound Station. Press the **Power** button if the Sound Station does not turn on automatically.
- b. Wait while the Sound Station scans for wireless networks and then select your wireless network from the list. Turn the **TUNE knob** to highlight your wireless network and then press the **TUNE knob** to select.
- c. The Sound Station will attempt to connect to the wireless network. If you chose a network that requires a password, you will be prompted to enter the Network Key (password). Otherwise, the Sound Station will attempt to connect to the wireless network.
- d. To enter the network key, turn the **TUNE knob** to highlight each character of the password and press the **TUNE knob** to select the character. If you make an error, press the **BACK** button to erase the character. When you have completed entering the network key, highlight **Enter** and press the **TUNE knob** or press the **Enter** button.
- e. When the Sound Station has successfully connected to the wireless network, **Network OK** will be displayed. Wait while the Sound Station updates itself after which it will enter Standby mode. Continue with step 2.



STEP 2: Enter Your SiriusXM Account Information

Enter Your SiriusXM Streaming User Name and Password

- a. If the Sound Station is in Standby mode, press the **Power** button
- b. Next you will be prompted to enter your SiriusXM streaming username. Enter each character in your username and when complete select **Enter** and press the **Tune knob** or press the **Enter** button. Your username is case sensitive. If you entered an incorrect username you will be prompted that the username does not exist. Repeat this step and enter the correct username.
- c. Next enter your password and select **Enter** and press the **Tune knob** or press the **Enter** button. Your password is case sensitive.
- d. When the Sound Station connects to SiriusXM the Channel Listing screen will be displayed. Turn the **TUNE knob** to scroll through the category choices and highlight a category. Press the **TUNE knob** to display the channels in the category. You can select a channel to begin listening.



The installation is complete.

IMPORTANT! You must have a qualifying SiriusXM subscription to use the SiriusXM Sound Station. You can add this service to your existing Sirius or XM subscription, or subscribe only to the SiriusXM Internet Radio package.

To subscribe, go to siriusxm.com/streaming or call 866-635-2349.

TIP! To verify that you are subscribed to SiriusXM Internet Radio, listen online:

- Go online to siriusxm.com/streaming. Click on the **Listen Now** link, enter your username and password, and click **Login**. If you can listen, then you are subscribed to stream SiriusXM.

IMPORTANT NOTICE: REQUIRED SUBSCRIPTION
Hardware and subscription sold separately. **The subscription plan you choose will automatically renew and you will be charged according to your chosen payment method at then-current rates.** Fees and taxes apply. **To cancel, you must call us at 1-866-635-2349. See our Customer Agreement for complete terms at www.siriusxm.com.** All fees and programming subject to change. SiriusXM streaming is available throughout our satellite area and also AK and HI. Service available in Canada; see www.siriuscanada.ca or www.xmradio.ca.

© 2015 Sirius XM Radio Inc. Sirius, XM and all related marks and logos are trademarks of SiriusXM Radio Inc. All other marks, channel names and logos are the property of their respective owners. All rights reserved.

Sound Station Functions

TUNE Knob (Multifunction)
Turning the knob at the Now Playing screen displays the Channel Listing screen; pressing the knob at the Now Playing screen displays the Direct Tune screen; turning the knob in a menu or user input screen scrolls through and highlights menus and choices; pressing the knob in a menu or user input screen selects the highlighted item.

HOME Button
Press to access the menu for listening modes and configuration options.




Action Panel Button
Press to learn more about the channel, show, or artist, and for additional selection options, for example, customizing a channel.

BACK Button
Press to return to the previously displayed screen.


Display Screen
Context Sensitive Buttons (5)
These buttons change their functions according to the context. Press to select the function shown on the display screen just above the button.

Volume / Mute Knob
Turn to adjust the volume; press to mute and un-mute audio.


0-9 Number Buttons
Press to tune to a favorite channel; press and hold to set the current channel as a favorite channel.



What's in the Box?



SiriusXM Sound Station




AC Power Adapter




Remote Control

Sound Station Main Display Screens

The Home Screen



The Now Playing Screen



siriusxm.com

Sirius XM Radio Inc.
1221 Avenue of the Americas
New York, NY 10020

1.866.635.2349

SiriusXM Sound Station
WiFi Table Radio

Quick Start Guide

