

Monster Bang Instructions

1. SISTALK Introduction

Founded in August 2015, SISTALK is continuously developing innovative technologies, intelligent products and satisfactory services to provide the most pleasurable experience for ladies with the aim of satisfying their aesthetic and emotional appeal.

Holding our motto “Be Joyful, Stay Healthy”, SISTALK have created a revolutionary way to improve sexual enjoyment and your health. Our Monster Pub products not only provide girls with experience of joy and health , but also serve as a safe platform to share their pleasure experience.

2. Basic Parameters

Brand: SISTALK

Model: Monster Bang Whip Kit, Monster Bang Candle Kit, Monster Bang Cuffs Kit

Material: Silica (edible grade) silicone

Size: Length 175mm * width 35mm

Weight: 106g

Compatible Devices: Smart phones running Android 4.3, iOS 7.0 or later versions


Battery: 420mA rechargeable lithium battery (not removable/can not be disassembled)

Max volume: less than 50dB

Charger: Input 5V, Max 500mA

Waterproof IP6X

Made in China



3. How to charge



1. Turn right to open the charger cover

2. Insert the charger into charging hole.

The product is charging when the small light starts to flash;

The battery is full when the small light stops flashing and remains on;

It takes about 2.5hrs to fully charge the product. The fully-charged product could be used under strong vibrate mode for 70 minutes.

Precautions:

For your safety, DO NOT use Monster Pub when charging.

Adult (18 years old and above) only.

Avoid internal use during menstrual period.

Pregnant women, patients with pacemaker or have diabetes, phlebitis, thrombosis and other health problems, please consult your doctor before using our products.

4. Instruction for use

Use Monster Pub products with your smart phone

1. Scan the QR code and install Monster Pub APP





Or search Monster Pub APP in Appstore or Google Play

Connect your Monster Pub product to your phone APP



2. Turn on the Bluetooth and the APP on your phone, long press the switch 2S to turn on your Monster Pub product.

Wait for an automatic connection until when the upper right corner of your smart phone shows the

mark  and displays the icon of the power button , indicating that your Monster Pub has been successfully connected with your smart phone .

3. Start using

Use Monster Pub products with your smart phone

Close your eyes and enjoy: Touch the screen and control the rhythm as you wish/Click on the screen and dominate the strength and speed by yourself.


Remote control: Your partner can control your Monster Pub without installing the APP. The distance is no longer a problem.

Share your vibration: Enjoy a safe adventure by using the vibration shared by others.

Use Monster Pub product without your smart phone/ alone


Long press the switch 2S to turn on your Monster Pub product.

Short Press to cycle through the pre-set stimulation modes



Long press 2S to turn off

Tips:



5. How to clean and store

Wash it with cold or warm water to wash it, and then dry it with a soft towel or cloth,;

Clean it with some mild soap or intimate wash;

Store it in clean and dry environment.

DO NOT clean it with hot water

DO NOT soak for a long time or boil it.

Avoid direct sunlight or sources of heat.

DO NOT use alcohol to clean it as it may damage the silicone.

Keep it away from Children.



6. Warranty

One year warranty

The warranty period is one year since purchase. The warranty covers any quality problem of materials, manufacturing process or any malfunction problems. Please contact SISTALK distributors and we will replace your product for free.

The warranty does not cover abrasion ,damage caused by improper use or damage caused by other irresistible natural factors such as fires, earthquakes, floods. Any damage caused by attempting to disassemble the product (or its accessory) is not covered either.

To claim your warranty service, please keep your original receipt and this warranty book.

7. Scrap and recycling

The recycling labels of this product are in line with the EU regulations of differentiated waste collection.

In case the trash can icon is crossed, this product should be considered as an electronic waste and can not be recycled together with normal trash.



8. Disclaimer

Users are responsible for the usage of this product. SISTALK and its retailers should not be bear any legal liability arising from this. SISTALK reserves the right to modify the contents of this manual and is under no obligation to notify anyone of the changes made.

This manual applies to all SISTALK products and is subject to changes without prior notice.

2015 SISTALK Technology (Beijing) Co., Ltd. All rights reserved

Address: Room 509, Block A of Ocean Express, Sanyuanqiao, Chaoyang District, Beijing

Designed by SISTALK in China

Website: www.sistalk.com

This product is suitable for all EU member states.

Operating Frequency Band (RF):

Bluetooth: 2402-2480 MHz (TX/RX);

Modulation mode:

GFSK (BLE)

Max. Of Transmit power:

Bluetooth: 0-10 dBm