Blutooth Dongle

SBD501

User's Manual

* FCC NOTICE:

(1) Section 15.19 Labelling requirements

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

(2) Section 15.21 Information to user

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

* IMPORTANT NOTE:

To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

Rev 1.0 1 of 4

CE Marking information :		
	C € 0197	

Features

- Quick connection to BluetoothTM phone
- Pairable up to 3 BluetoothTM phone
- Support for the BluetoothTM Headset profile 1.1

How to install to mobile phone

Just plug-in the dongle to mobile phone

Pairing

First, the dongle should be in "idle" state. If user presses on the button for about 2 seconds, the LED will be turned on. It indicates that the dongle has received a "LONG BUTTON". Once a "LONG BUTTON" is entered while the dongle is in "idle" state, it switches to "pincode input" mode. User can now enter a pincode.

A short button will increase a digit by one. A long button will complete a digit.

If a user pushes button shortly for 6 times preceded by a long button, a digit '6' is entered. If user pushes button for more than or equal to 10 times, then the number will be calculated by subtracting 10 from the original number. For example, 15

Rev 1.0 2 of 4

times of short click makes number '5', 10 times makes a number '0' and 11 times makes '1'.

If the number of entered digits exceeds four, any additional input will be dismissed. Pincode is made up of 4 digits at most. For instance, inputing '4465435' makes pincode '4465'.

When input is done, user *should* press the button for more than 6 seconds so that the dongle stores the new pincode and starts pairing.

Establishing connection between Dongle and a Headset

If you want to establish a connection between the Dongle and the headset, when there is no connection, you could do the following:

- 1. Press Dongel's button for less than one second
- 2. The dongle will try to connect to the paired mobile phone.

Making a call

(When an active call does not exsist)

1, Just call by mobile phone and enjoy call with headset.

Hanging up a call

(When an active call exsists)


1. Press the Call button on headset.

Answering an incomming call

1. Press Call button on the headset.

LED Indications

Rev 1.0 3 of 4



Rev 1.0 4 of 4