

The Samsung logo, consisting of the word "SAMSUNG" in white, uppercase letters inside a dark grey, horizontally-oriented oval.

SAMSUNG

Bluetooth Wireless Mouse User Guide

www.samsung.com

English.....3

Қазақша..... 55



한국어 17

中文(繁體)69

Русский.....27

Українська.....41

Overview





- The appearance of the product may differ from the figure.
- Usage is provided based on Windows 8. For other operating systems, refer to the help information of the corresponding operating system.

Connecting and using the mouse

- 1 Open the battery cover and insert the batteries.



- Be sure to confirm that the polarities (+ / -) of the batteries are correct.
- Do not recharge the batteries (AA type) supplied with the product.

- 2 Turn both the computer and the power switch at the bottom of the mouse **on**. Press and hold the **Connect** button for approximately 1 second.
- 3 Right-click over the Bluetooth icon (Figure) on the Desktop and select **Add Bluetooth device** from the popup menu.
- 4 Searching for devices is automatically performed. Select the mouse you want to use.



- If the system requests to enter the pincode for your mouse, please enter "0000".
- If the mouse is not used for 5 minutes, the mouse hibernates. In this case, click a mouse button to wake it up. Then, you can use the mouse after a moment.

Specification

Item	Specification
Operating Voltage	1.5VDC
Input Power	35mW
Input Voltage	1.5VDC

Copyright and trademarks

Samsung Electronics reserves the copyright of this user guide. No part of this guide shall be reproduced or published in any media or form without consent from Samsung Electronics.

The content of this guide is subject to change without notice. The logos and model names mentioned in this guide are the property of their respective owners.

FCC ID : A3LAA-SM8PWBW

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- i) This device may not cause harmful interference, and
- ii) This device must accept any interference received, including interference that may cause undesired operation.

WEEE SYMBOL INFORMATION



Correct disposal of this product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems.)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.



Pb

Correct disposal of batteries in this product

(Applicable in countries with separate collection systems)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains

mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material re-use, please separate batteries from other types of waste and recycle them through your local, free battery return system.

IC NOTICE TO USER :

This device complies with Industry Canada license-exempt RSS standard(s)

Operation is subject to the following two conditions:



- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.



Hereby, Samsung Electronics Co., Ltd declares that these models are in compliance with the essential requirement and other relevant provisions of directive 1999/5/EC.



각 부분의 명칭





- 제품 외관이 다르게 제공될 수 있습니다.
- Windows 8 설치 기준으로 사용법이 제공됩니다. 다른 OS는 해당 OS의 도움말을 참고하세요.

연결 및 사용하기

1 배터리 커버를 열고 배터리를 끼워주세요.



- 반드시 건전지 극성(+/-)을 확인하시기 바랍니다.
- 제공된 건전지(AA Battery)는 충전하여 사용하지 마세요.

- 2 컴퓨터를 켜고 마우스 밑면 전원 스위치를 **ON**으로 변경합니다. **Connect** 버튼을 1초 정도 누릅니다.
- 3 컴퓨터 바탕화면의 블루투스 아이콘을 마우스 오른쪽 클릭한 후 **Blooth** 장치 추가를 선택합니다.
- 4 자동으로 장치 추가 검색이 진행됩니다. 연결할 마우스를 선택합니다.



- 설치 중에 암호 입력 창이 나오면 “0000”을 입력해 주시기 바랍니다.
- 5분 이상 마우스를 사용하지 않으면 마우스는 최대절전모드로 들어가게 됩니다. 이때 마우스 버튼을 누르면 잠시 후 마우스를 사용할 수 있습니다.

제품 규격

구분	명칭 및 규격
작동전압	1.5VDC
입력 전력	35mW
입력 전압	1.5VDC



1. 기기의 명칭(모델명):
특정 소출력 무선기기
(AA-SM8PWBW)
(AA-SM8PWBB)
2. 인증 번호:
MSIP-CRM-SEC-
AA-SM8PWBW
MSIP-CRM-SEC-
AA-SM8PWBB
3. 인증 받은 자의 상호:
삼성전자 (주)
4. 제조사/제조국가:
삼성전자 (주) / 중국

해당 무선 설비는 운용 중 전파 혼선
가능성이 있음.

제품 사용 및 서비스 문의

☎ 지역번호 없이 1588-3366

저작권과 등록 상표

삼성전자 주식회사가 이 사용 설명서의 저작권을 소유합니다. 이 설명서의 어떤 부분도 삼성전자 주식회사의 서면 동의 없이 어떤 수단이나 형태로든 재 가공 되거나 발행될 수 없습니다.

설명서의 내용은 예고 없이 변경될 수 있습니다. 여기에 있는 모든 제품명 또는 회사명은 각 회사의 재산입니다.

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.