




Turning the device on or off

Slide the Power switch to **ON** to turn on the device.



Slide the Power switch to **OFF** to turn off the device.

Using a tablet

Mounting the tablet

Open the Slot cover on the device and place the tablet into the slot.



To remove the tablet from device, lift the tablet upwards.



Follow the instructions when removing the tablet from the device. The slot size is only for Galaxy Note Pro.


FCC ID : A3LSMP905V



Stowing the tablet

Place the tablet with the touch screen facing the device as shown in the image below.

- 1 Place the lower-edge of the tablet against the corner guides at the back of the device.
- 2 Align the upper-edge of the tablet with the front of the device and lower it to stack the tablet on the device.



To separate the tablet from the device, place your fingers in the indentation at the back-edge of the device. Then, lift the tablet with your fingers while pushing the corner guides at the back of the device.

