

QUICK START GUIDE

EI-YP322


Gamepad for Gear VR

Draft



SAMSUNG

Printed in Korea
GH68-46341A Rev.1.0
E Type 04/2016



A



Copyright © 2016 Samsung Electronics
Bluetooth® is a registered trademark of
Bluetooth SIG, Inc. worldwide.

- Please read this guide before using the device to ensure safe and proper use.

- Images may differ in appearance from the actual product. Content is subject to change without prior notice. You can access the full user manual for more information. Visit www.samsung.com to view device information, the user manual, and more.
- Before using the gamepad, make sure it is compatible with your mobile device.
- Your consumer rights are governed by the law of the country in which you purchased the product. Please contact your service provider for more information.

Device layout

a	Action buttons	e	Menu/Home button
b	Shoulder button (R)	f	Analogue stick
c	Indicator light	g	Battery cover
d	Bluetooth pairing button	h	Shoulder button (L)

Replacing the batteries

When the indicator light flashes red, replace the batteries.



Do not recharge the provided batteries.

1. Remove the battery cover from the back of the gamepad.



Be careful not to damage your fingernails when you remove the battery cover.



Do not bend or twist the battery cover excessively. Doing so may damage the cover.

2. Remove the batteries and insert new AAA batteries with the positive and negative terminals properly aligned with the + and - symbols on the gamepad.
3. Reattach the battery cover to the back of the gamepad.
Place the cover on the back of the gamepad and press the edges together to reassemble the gamepad.

Connecting devices via Bluetooth

1. Press the Bluetooth pairing button to enter Bluetooth pairing mode.
The indicator light will flash red, green, and blue.
2. On your other mobile device, activate the Bluetooth feature and tap **Gamepad for Gear VR (0000)** from the list of available devices.

Keep the gamepad attached to the Gear VR when you are not using it. (A)

Safety information

Read all safety information before using the device to ensure safe and proper use. To view the full safety information, refer to the Samsung website.

Use manufacturer-approved batteries, chargers, accessories, and supplies

Do not touch the device with wet hands

Do not drop or cause an impact to the charger or the device

The device can be used in locations with an ambient temperature of 0°C to 35°C. You can store the device at an ambient temperature of -20°C to 50°C. Using or storing the device outside of the recommended temperature ranges may damage the device or reduce the battery's lifespan

Do not allow children or animals to chew or suck the device

Do not disassemble, modify, or repair your device

Correct disposal



This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste.

This product is RoHS compliant.



This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste.

For information on Samsung's environmental commitments and product-specific regulatory obligations, e.g. REACH, WEEE, Batteries, visit samsung.com/uk/aboutsamsung/samsungelectronics/corporatecitizenship/data_corner.html

FCC Statement

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications not expressly approved by Samsung Electronics Co., Ltd. could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC Radiation exposure limits set forth for an uncontrolled environment. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

Industry Canada Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

IC Radiation Exposure Statement

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Déclaration d'Industrie Canada sur l'exposition aux radiations

Cet équipement est conforme aux limites établies par Industrie Canada en matière d'exposition aux radiations dans un environnement non contrôlé. Cet équipement ne doit pas être colocalisés ou fonctionner en conjonction avec tout autre antenne ou émetteur.

SAMSUNG

Declaration of Conformity

Product details

For the following

Product : Gamepad for Gear VR

Model(s) : EI-YP322



Draft

Declaration & Applicable standards

We hereby declare, that the product above is in compliance with the essential requirements of the Electromagnetic Compatibility Directive (2004/108/EC) by application of:

EN 55022 : 2010

EN 55024 : 2010

and the Directive (2011/65/EU) on the restriction of the use of certain hazardous substances in electrical and electronic equipment by application of EN 50581:2012.

Representative in the EU

Samsung Electronics Euro QA Lab.
Blackbushe Business Park, Saxony Way,
Yateley, Hampshire, GU46 6GG, UK

2016.XX.XX

(Place and date of issue)

Stephen Colclough / EU Representative

(Name and signature of authorised person)

* This is not the address of Samsung Service Centre. For the address or the phone number of Samsung Service Centre, see the warranty card or contact the retailer where you purchased your product.

SAMSUNG