

**EP-PA710** 

# User Manual

## **Table of Contents**

#### Read me first

#### **Getting started**

- 4 Package contents
- 4 Device layout

#### Using the device

- 5 Using wireless charger
- 7 Checking the battery level

### Read me first

Please read this manual before using the device to ensure safe and proper use.

- Descriptions are based on the device's default settings.
- Images may differ in appearance from the actual product. Content is subject to change without prior notice.

#### Instructional icons



Warning: situations that could cause injury to yourself or others



Caution: situations that could cause damage to your device or other equipment



Note: notes, usage tips, or additional information

## **Getting started**

### **Package contents**


Check the product box for the following items:

- Device
- Quick start guide



- Wireless charging cover and travel adaptor sold separately.
- The items supplied with the device and any available accessories may vary depending on the region or service provider.
- The supplied items are designed only for this device and may not be compatible with other devices.
- Appearances and specifications are subject to change without prior notice.
- You can purchase additional accessories from your local Samsung retailer. Make sure they are compatible with the device before purchase.
- Use only Samsung-approved accessories. Using unapproved accessories may cause the performance problems and malfunctions that are not covered by the warranty.
- Availability of all accessories is subject to change depending entirely on manufacturing companies. For more information about available accessories, refer to the Samsung website.

### **Device layout**



#### **Device layout**

a	USB charger port	е	Charger port
Ь	Wireless charging surface (left)	f	Fan vent
C	Indicator light (left)	g	Wireless charging surface (right)
d	Indicator light (right)		

## Using the device

### Using wireless charger

1 Connect the wireless charger and a travel adaptor with a charging cable, and plug the travel adaptor into an electric socket.

When the wireless charger is connected to the electric socket, the indicator light flashes from blue to green to cyan, and then turns off.





Use only Samsung-approved travel adaptors (12 V/2.1 A). Unauthorised travel adaptors may cause damage or the wireless charger may malfunction.

2 Connect the travel adaptor to the wireless charger. Then, place a supported mobile device in the centre of the charging surface.





Do not place the wireless charging cover solely on the wireless charger. Doing so may overheat the wireless charger and cause a fire. It may also result in serious burn or device malfunction.

3 When the mobile device is fully charged, disconnect the travel adaptor from the wireless charger.



- Check the mobile device's battery status using the charging icon displayed on the screen.
- Do not place any other object between the mobile device and the wireless charger.
   The mobile device may not charge properly.
- Charging a mobile device with the wireless charger in an area with a weak signal may cause a significant drop in reception.
- If you connect a travel adaptor to the mobile device during wireless charging, the wireless charging feature is unavailable.
- The wireless charger is compatible with WPC certified devices.
- To save energy, unplug the travel adaptor when not in use. The travel adaptor does
  not have a power switch, so you must unplug the travel adaptor from the electric
  socket when not in use to avoid wasting power. The travel adaptor should remain
  close to the electric socket and easily accessible while charging.

### **Checking the battery level**

You can check the device's charging status via the notification light.

Colour	Status		
Blue $\rightarrow$ Green $\rightarrow$ Cyan	When connecting to the power outlet		
Blue	When charging		
Green	When fully charged		
Cyan	When charging with a travel adaptor (less than 12 V/2.1 A)		
Flashing blue	When not charging properly due to a general error		
Off	When in Idle mode		



- If the indicator light is not working properly, reconnect the travel adaptor to the wireless charger.
- The indicator light's colour may vary depending on the mobile device or the wireless charging cover.

#### **FCC Statement**

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.
- FCC Radiation Exposure Statement
   This equipment complies with FCC Radiation exposure limits set forth for an uncontrolled environment. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

   This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

#### **IC Statement**

- This device complies with Industry Canada licence-exempt RSS standard(s).
   Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- IC Radiation Exposure Statement
   This equipment complies with IC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

   This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.
- Cet équipement est conforme aux limites établies par Industrie Canada en matière d'exposition aux radiations dans un environnement non contrôlé. Cet équipement ne doivent pas être colocalisés ou fonctionner en conjonction avec tout autre antenne ou émetteur.
  - Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

#### Copyright

Copyright © 2015 Samsung Electronics

This manual is protected under international copyright laws.

No part of this manual may be reproduced, distributed, translated, or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or storing in any information storage and retrieval system, without the prior written permission of Samsung Electronics.

#### **Trademarks**

- SAMSUNG and the SAMSUNG logo are registered trademarks of Samsung Electronics.
- All other trademarks and copyrights are the property of their respective owners.