

# QUICK START GUIDE

EP-PG920A



Printed in Korea  
GH68-44067A Rev.1.0  
SEA Type 04/2015



Copyright © 2015 Samsung Electronics

## English

- Please read this manual before using the device to ensure safe and proper use.
- Images may differ in appearance from the actual product. Content is subject to change without prior notice. You can access the full user manual for more information. Visit [www.samsung.com](http://www.samsung.com) to view device information, the user manual, and more.

### Device layout

<b>a</b>	Wireless charging surface	<b>c</b>	Indicator light
<b>b</b>	Charging port		

- Wireless charging cover sold separately.

### Using the wireless charger

1. Connect the travel adapter to the wireless charger. Then, place a supported mobile device in the center of the charging surface.
2. When the mobile device is fully charged, disconnect the travel adapter from the wireless charger.

- Use only Samsung-approved travel adapters (5 V/2 A).

- The travel adapter should remain close to the electric socket and easily accessible while charging.

### Safety information

Read all safety information before using the device to ensure safe and proper use. To view the full safety information, refer to the Samsung website.

**Use manufacturer-approved batteries, chargers, accessories, and supplies**

**Do not touch the device with wet hands**

**Do not drop or cause an impact to the charger or the device**

**Do not store your device in very hot or very cold areas. It is recommended to use your device at temperatures from 5°C to 35°C**

**Prevent the multipurpose jack and the small end of the charger from contact with conductive materials, such as liquids, dust, metal powders, and pencil leads**

**Do not allow children or animals to chew or suck the device**

**Do not disassemble, modify, or repair your device**

**Magnetic stripe cards, including credit cards, phone cards, passbooks, and boarding passes, may be damaged by magnetic fields**

### FCC Warning Statement

#### FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

#### FCC RF Radiation Exposure Statement

This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

### Recycling Direct

To dispose electronics properly, follow the recycling process regulated in your area or go to Samsung website to find the nearest recycling location:

[www.samsung.com/recyclingdirect](http://www.samsung.com/recyclingdirect)

Or call, (877) 278 – 0799.

### Samsung Electronics America, Inc

85 Challenger Road,

Ridgefield Park, New Jersey, 07660

Phone: 1-800-SAMSUNG (726-7864)

