

# GT - S6102E WLAN TEST MANUAL

# 1. Entering TestMode

- A. Press Key-string `"*#526#"` to enter WLANTEST mode
- B. After entering WLANTEST mode, wait for message "Driver loading successful" on device screen
- C. Select Menu (Menu key)

## 2. TX Test

- A. Select Tx Test
- B. Select Channel
- C. Select TX rate
- D. Select power value
- E. Click Start button to start Tx test
- F. Click Stop button to finish Tx test

# 3. Rx Test

- A. Select Rx Test
- B. Select Rx Channel
- C. Click Start button to Start Rx Test
- D. Click Stop button to finish Rx Test
- E. Click "Clear" button to clear the received packet count