


FCC RF EXPOSURE INFORMATION

WARNING! Read this information before using your phone



In August 1996 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards.



Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations.

Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations using the belt-clip, which provides 2.2cm. spacing from the body. The use of other belt-clip/holsters and other non-tested accessories may not comply with FCC RF Exposure requirements and should be avoided.

SCH-a690 Menu Tree

22-Apr-03

1. Calls

- 1. Outgoing
- 2. Incoming
- 3. Missed
- 4. Erase Logs
 - > 1.Outgoing 2.Incoming 3.Missed 4.All calls
- 5. Call Timer
 - > 1.Last Call 2.Total 3.Lifetime 4.Erase total
- 6. PTT Contact List

2. Phone Book

- 1. Find
 - > By Name, By Entry, By Group
- 2. Add
- 3. Rename Group
 - > 1.Friend 2.Family 3.Colleague 4.VIP 5.No name
- 4. My Phone #
- 5. Memory

3. Message

- 1. Send New Msg
- 2. Voice
- 3. Inbox
- 4. Outbox
- 5. Draft Msg
- 6. Saved Msg
- 7. Web Alert
- 8. Msg Setting
 - > 1.New Message
 - > 1.Save In Outbox
 - > Not Save, Prompt, Auto Save
 - 2.Callback#
 - 3.Entry Mode
 - > T9 Word, Alphabet

- 4.Delivery Ack
 - > Off, On
- 5.My Signature
 - > Edit Signature, Setting
- > 2.Msg. Alert
 - > 1.Volume/Vibrate
 - > Silent, 1 Beep, Vibrate, Vib + Ring, Level 1 ~ 5
 - 2.Type
 - > 1. Voice Mail
 - > Bell 1 ~ 5, Melody 1 ~ 10, **Downed Melody 1 ~ 20**
 - 2. Page
 - > Bell 1 ~ 5, Melody 1 ~ 10 , **Downed Melody 1 ~ 20**
 - 3. Text
 - > Bell 1 ~ 5, Melody 1 ~ 10 , **Downed Melody 1 ~ 20**
 - 4. Web Alert
 - > Bell 1 ~ 5, Melody 1 ~ 10 , **Downed Melody 1 ~ 20**
 - 3.Reminder
 - > Off, Once, Every 2 min
- > 3.Scroll Timer
 - > Off, 1 ~ 5 Seconds
- > 4.Auto Delete
 - > Warning Msg, Auto Delete
- > 5.Canned Msg.
 - > 1.Yes
 - 2.No
 - 3.Call me
 - 4.Need directions
 - 5.Where are you?
 - 6.Will call later
 - 7.Busy
 - 8.On my way
 - 9.Will arrive 15 m
 - 10.Thank you
 - 11.Love you
 - 12.~ 20 Blank
- > 6.Voice Mail #

9. Erase Msg

- > 1.Voice
- 2.OldInbox
- 3.NewInbox
- 4.Oldbox
- 5.Draft Msg
- 6.Saved Msg
- 7.All Messages

4. Mobile Web

- 1. Get In Web
- 2. Prompt

> None, To Start, To End, Both

5. Planner

- 1. Today
- 2. Scheduler
- 3. Jump To Date
- 4. To Do List
- 5. Memo Pad
- 6. Count Down
- 7. Alarm Clock

> Once, Daily, Off

- 8. World Time
- 9. Calculator

6. Display

- 1. Animation

- > 1. Opening
 - > Auroa, Sailing, Fall
- 2. Closing
 - > Auroa, Sailing, Fall
- 3. Wall Paper
 - > Landscape, Water Drop, Clock1, Dual Clock, Digital Clock, Aquarium

- 2. Banner
- 3. Backlight

> 5, 10, 15 Seconds, Folder Open, Power Save

- 4. Contrast

> 1. Main Display

5. Auto Hyphen 2. Front Display

> No, Yes

6. Service LED

> No, Yes

7. Sound

1. Volume/Vibrate

> 1. Calls

> Silent, 1 Beep, Vibrate, Vib + Ring, Level 1 ~ 5

2. Alarm

> Silent, 1 Beep, Vibrate, Vib + Ring, Level 1 ~ 5

2. Ringer Type

> 1. Calls

> Bell 1 ~ 5, Melody 1 ~ 10 , **DownedMelody 1 ~ 20**

2. Alarm

> Bell 1 ~ 5, Melody 1 ~ 10 , **DownedMelody 1 ~ 20**

3. Data/Fax In

> Bell 1 ~ 5, Melody 1 ~ 10 , **DownedMelody 1 ~ 20**

4. Planner

> Bell 1 ~ 5, Melody 1 ~ 10 , **DownedMelody 1 ~ 20**

3. Key Beep

> 1. Volume

> Silent, 1 Beep, Vibrate, Vib + Ring, Level 1 ~ 5

2. Tone Length

> Long, Normal

4. Alerts

> 1. Minute Beep

> On, Off

2. Service

> On, Off

3. Connect

> On, Off

4. Disconnect

> On, Off

5. Fade

> On, Off

- 5. Power On/Off
- 6. Roam Ringer
- 7. Whisper Mode

- 6. Roam
 - > On, Off
- 7. Privacy
 - > On, Off
- > On, Off
- > On, Off
- > On, Off

8. Voice Kit

- 1. Voice Dial
- 2. Voice Memo
- 3. Call Screen

- > 1. Record
- 2. Review
- 3. Erase All
 - > Yes, No
- 4. Set Active
 - > [*] Only, [*]/Folder, [*]/EarMic
- > 1. Record
- 2. Review
- 3. Erase All
 - > Yes, No
- > 1. On/Off
 - > Enable, Disable
- 2. Inbox
- 3. Greeting
 - > 1. Record
 - 2. Play
 - 3. Select
 - > Recorded, Default
- 4. Call Sound
 - > Enable, Disable
- 5. Wait Time
 - > Off, After 3 sec, After 5 sec, After 10 sec

9. Setup

1. Location

> Location On, 911 Only

2. Network

> 1.Set NAM

> NAM 1, NAM 2

2.Roam Option

> Home Only, Automatic

3. Data/Fax

> 1. Auto Detect

> data off, data until powered off

2. Baud Rate

> Auto, 19200, 38400, 57600, 115200, 230400

4. Security

> 1.Lock Phone

2.Change Lock

3.Emergency #

4.Voice Privacy

5.Restriction

> 1.Outgoing 2.Incoming 3.Phonebook

6.Erase Memory

(Pop Up Msg: "Erase Memory PHBK&VDial")

7.Reset Phone

(Pop UP Msg: "Restore Default Setting except PHBK & VDial")

5. Call Answer

> Send Key, Folder Open, Any Key

6. Aut Answer

> Off, After 5 sec, After 3 sec, After 1 sec

7. Auto Retry

> Off, Every 10 sec, Every 30 sec, Every 60 sec.

8. Language

> English, Spanish

9. Clock Set

> 1.Main Clock

2.Dual Clock

10. Version