

- \* Depending on the software installed or your service provider or country, some of the descriptions in this guide may not match your phone exactly.
- \* Depending on your country, your phone and accessories may appear different from the illustrations in this guide.

**SAMSUNG ELECTRONICS**



World Wide Web  
<http://www.samsungmobile.com>

Printed in Korea  
Code No.:GH68-xxxxxA  
English (CHN). 06/2007. Rev. 1.0



**Draft**  
**2007. 06. 05**

# **SCH-W619**

## **User's Guide**



# Important safety precautions



Failure to comply with the following precautions may be dangerous or illegal.

## Copyright information

- Bluetooth<sup>®</sup> is a registered trademark of the Bluetooth SIG, Inc. worldwide. Bluetooth QD ID: BO12689
- Java<sup>™</sup> is a trademark or registered trademark of Sun Microsystems, Inc.
- Pícel and Pícel Viewer<sup>™</sup> are trademarks of Pícel Technologies, Inc.

## Drive safely at all times

Do not use a hand-held phone while driving. Park your vehicle first.

## Switch off the phone when refuelling

Do not use the phone at a refuelling point (service station) or near fuels or chemicals.

## Switch off in an aircraft

Wireless phones can cause interference. Using them in an aircraft is both illegal and dangerous.

## Switch off the phone near all medical equipment

Hospitals or health care facilities may be using equipment that could be sensitive to external radio frequency energy. Follow any regulations or rules in force.

## Interference

All wireless phones may be subject to interference, which could affect their performance.

## Be aware of special regulations

Meet any special regulations in force in any area and always switch off your phone whenever it is forbidden to use it, or when it may cause interference or danger.


## Water resistance

Your phone is not water-resistant. Keep it dry.

## Sensible use

Use only in the normal position (held to your ear). Avoid unnecessary contact with the antenna when the phone is switched on.

## Emergency calls

Key in the emergency number for your present location, then press .

## Keep your phone away from small children

Keep the phone and all its parts, including accessories, out of the reach of small children.

## Accessories and batteries

Use only Samsung-approved batteries and accessories, such as headsets and PC data cables. Use of any unauthorised accessories could damage you or your phone and may be dangerous.

- The phone could explode if the battery is replaced with an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions.



At very high volumes, prolonged listening to a headset can damage your hearing.

## Qualified service

Only qualified service personnel may repair your phone.

For more detailed safety information, see "Health and safety information" on page 41.

# About this Guide

This User's Guide provides you with condensed information about how to use your phone.

In this guide, the following instruction icons appear:




Indicates that you need to pay careful attention to the subsequent information regarding safety or phone features.



Indicates that you need to press the Navigation keys to scroll to the specified option and then select it.



Indicates a key on the phone. For example, [  ]



Indicates a soft key, whose function is displayed on the phone screen. For example, < **Menu** >



## • **Dual standby mode**

Your phone operates on both GSM and CDMA networks, anytime, anywhere. Select a network before making calls or sending messages.

## *Special features of your phone*



## • **Touch screen**

Your phone has a touch-sensitive display. You can access a desired function with a touch on the screen.



## • **Camera and camcorder**

Use the camera module on your phone to take a photo or record a video.



- **MP3 player**

Play music files using your phone as an MP3 player.



- **Melody composer**

Make your own melodies for your phone.



- **Photo studio**

Add a frame or apply special effects to decorate your photos.



- **Bluetooth**

Transfer media files and personal data, and connect to other devices using wireless Bluetooth technology.



- **Web browser**

Access the wireless web to get up-to-the-minute information and a wide variety of media content.



- **Messenger**

Have a conversation with other people by sending and receiving instant messages.



- **SOS message**

Send SOS messages to your family or friends for help in an emergency.



- **Memory disk**

Connect your phone to a computer to copy files directly to and from it.

## Contents

### **Unpack 6**

---

*Make sure you have each item*

### **Get started 6**

---

*First steps to operating your phone*

Assemble and charge the phone .....	6
Power on or off.....	7
Phone layout.....	8
Keys and icons .....	9
Access menu functions .....	12
Enter text .....	13
Customise your phone.....	17
Use an optional memory card .....	19

### **Step outside the phone 21**

---

*Begin with call functions, camera, MP3 player, web browser, and other special features*

Make or answer calls .....	21
----------------------------	----

Use the camera .....	21
Play music.....	23
Browse the web .....	24
Use Contacts .....	24
Send or view messages.....	25
Use Bluetooth .....	26
Use Sketch memo .....	28

### **Menu functions 30**

---

*All menu options listed*

### **Health and safety information 41**

---

## Overview of menu functions

To access Menu mode, tap or press **<Menu>** in Idle mode.

### 1 Call history

- 1 Missed
- 2 Incoming
- 3 Outgoing
- 4 Air time
- 5 GSM call cost
- 6 Area code
- 7 Call reject
- 8 Int'l call prefix
- 9 Answer mode
- 0 Flight mode

### 2 Contacts

- 1 Find
- 2 Add
- 3 Group settings
- 4 Speed dial
- 5 Name card
- 6 My phone #
- 7 Memory info

### 3 Multimedia

- 1 Take photo
- 2 Namecard recognition
- 3 My album

### 3 Multimedia

- 4 External album
- 5 Photo studio
- 6 Settings

### 4 Display

- 1 Screen saver
- 2 Functional screen
- 3 Power on/off
- 4 Dialing font
- 5 Time settings
- 6 Backlight

### 5 Messages

- 1 New message
- 2 Inbox
- 3 Outbox
- 4 Drafts
- 5 Msg. setup
- 6 SOS message
- 7 Msg. wallpaper
- 8 Memory info

### 6 Sounds

- 1 Ringer
- 2 Ringer vol./type
- 3 Key tone

### 6 Sounds

- 4 Function alert
- 5 Hour alert

### 7 Entertainment

- 1 Games
- 2 MP3
- 3 Melody composer
- 4 Karaoke
- 5 Fun box
- 6 Samsung messenger

### 8 Utilities

- 1 Today
- 2 Calendar
- 3 Task list
- 4 Alarm
- 5 User memory
- 6 Voice tools
- 7 Memo
- 8 Calculator
- 9 Countdown
- 0 Clock
- \* Dictionary
- # Bluetooth

### 9 Settings

- 1 COMA network services
- 2 GSM network services
- 3 Shortcut settings
- 4 Security
- 5 Network selection
- 6 Input method
- 7 Stylus adjust
- 8 语言 /Language
- 9 Domains preset
- 0 Contents status
- # My phone info

Tap or press **<Menu>** →  
**<Favorites>** in Idle mode.

### uni

- 1 Mail
- 2 Magic
- 3 Info
- 4 Music street
- 5 Bookmarks



## Unpack

Make sure you have each item

- Phone
- Travel charger
- Battery
- User's Guide
- Stylus pen

You can obtain various accessories from your local Samsung dealer.



The items supplied with your phone and the accessories available at your Samsung dealer may vary, depending on your country or service provider.

## Get started

First steps to operating your phone

### Assemble and charge the phone

1



Use the slot 1 for UIM cards only. Use the slot 2 for either UIM or SIM cards.

2


3

4


## Removing the battery


## Power on or off

### Switch on

1. Open the phone.
2. Press and hold [  ].
3. Select a default network.
4. If necessary, enter the PIN and tap or press **<OK>**.

### Switch off

1. Open the phone.
2. Press and hold [  ].

 *Get started*

## **Phone layout**

**Front view**

**Rear view**

## Keys and icons

### Keys

Soft keys Perform the function indicated on the bottom line of the display.

Network selection key In Idle mode, enter the **Set mode** menu in **Network selection**.

Navigation keys In Idle mode, access the following menus:

- Left: **Messages; Mail** when held down
- Up/Down/Right: your favourite menus

In Menu mode, scroll through menu options.

---

Uni key In Idle mode, launch the web browser.  
In Menu mode, perform the functions indicated on the bottom line of the display.

Send key Make or answer a call.  
In Idle mode, retrieve the numbers recently dialled, missed, or received.

C (Clear) key Delete characters from the display.  
In Idle mode, initiate the voice recognition feature. Start voice dialling when held down.  
In Menu mode, return the display to the previous menu level.

---

**Bluetooth key** In Idle mode, enter the **Bluetooth** menu.

**End key** Press and hold to switch the phone on or off.  
End a call.  
In Menu mode, cancel input and return the phone to Idle mode.

**Numeric keys** Enter numbers, letters, and some special characters.  
In Idle mode, press and hold [**1**] to access your voicemail server. Press and hold [**0**] to enter an international call prefix.

**Special key** Enter numbers, letters, and some special characters.  
In Idle mode, press and hold [#] to activate or deactivate the Silent mode.

**Volume key** Adjust the phone volume.






**MP3 key** In Idle mode, enter the **MP3** menu. Press and hold to launch the MP3 player.

**Camera key** In Idle mode, enter the **Multimedia** menu. Press and hold to turn on the camera.  
In Camera mode, take a photo or record a video.

## Icons












The following icons may appear on the top line of the screen to indicate your phone's status. Depending on your country or service provider, the icons shown on the display may vary. You can change settings or open a message by tapping some icons.

---

	Signal strength in a CDMA network
	No signal strength in a CDMA network
	Inactive UIM card or no UIM card inserted
	Signal strength in a GSM network
	No signal strength in a GSM network













---

---

	Inactive SIM card or no SIM card inserted
	Roaming network
	Call in progress
	SOS message feature active
	Transferring data in 1X network
	Connected to a secured web page
	New message: <ul style="list-style-type: none"><li> : Text message</li><li> : Urgent text message</li><li> : Voicemail</li></ul>
	Messenger invitation

---

---


	Alarm status
	Ringer type <ul style="list-style-type: none"><li>•  : Ringer only</li><li>•  : Silent</li><li>•  : 1 Beep</li><li>•  : Vibration</li><li>•  : Vib. &amp; ringer</li><li>•  : Vib. then ringer</li><li>•  : Ringer then vib.</li></ul>
	Silent mode
	Bluetooth status
	Battery power level

---



## Access menu functions

### Select an option

By tapping on the touch screen:

1. Tap a desired soft key indicator.
2. Tap the left or right arrow to scroll left or right. Tap and drag the scroll bar to scroll up or down.
3. Tap a displayed option or function.
4. Tap  to move up one level.

By pressing the soft keys and Navigation keys:

1. Press a desired soft key.
2. Press the Navigation keys to move to the next or previous option.
3. Press <**Select**> or <**Save**> to confirm the function displayed or option highlighted.
4. Press [ C /  ] to move up one level.  
Press [  ] to return to Idle mode.

By pressing the number keys:

Press the number key corresponding to the option you want.



## Enter text

### Change the text input mode

1. In the text entry screen, press the right soft key.
2. Select the mode you want.

### Use Pen Stroke mode





To enter a word:

1. Write a character at a time on the pen stroke field.  
Tap  to enter numbers or symbols.
2. If the phone does not correctly recognise your writing, select a character from the character selection field.
3. Tap  to insert a space and enter the next character.



### Use the onscreen keyboards

#### To enter a word:

1. Tap  in Pen Stroke mode to open the onscreen keyboard.
2. Tap a character on the keyboard.
  - Tap  to open the numeric keyboard.
  - Tap  to open the symbolic keyboard.
3. Tap  to insert a space and enter the next character.

### Use Chinese Pinyin mode

#### To enter a word:

1. Press the keys corresponding to the Chinese phonetic spelling, pinyin.

2. Press [Left] or [Right] to select alternative pinyins.
3. If necessary, press [Up] or [Down] to find the character you want.
4. Press [**1**]. Numbers are added to each character.
5. Press the number key corresponding to the character.

#### To use the tones:

1. Press the keys corresponding to the pinyin of the letter you need.
2. If necessary, press [Left] or [Right] to select the pinyin.
3. Press [**\***] for tones.

4. If necessary, press [Up] or [Down] to find the character you want.
5. Press [**1**]. Numbers are added to each character.
6. Press the number key corresponding to the character.

#### Rapid character entry

To enter the word *zhong guo* (中国), enter the first character using the following keystrokes; [**9**], [**4**], [**6**], [**6**], [**4**], [**1**], and [**1**]. You do not have to complete the Pinyin spelling to include *guo* (国). The character displays automatically.

#### Use Chinese Stroke mode

#### To enter a word:

1. Press the keys corresponding to a character's component strokes.
2. If necessary, press [Up] or [Down] to find the character you want.
3. Press the number key corresponding to the character you want.


#### Rapid character entry

Try entering the characters *zhong guo* (中国) using the following keystrokes: [**2**], [**8**], and [**7**]. You can enter the complete pair in only three key presses.

Use ABC mode	<p><b>To enter a word:</b></p> <p>Press the appropriate key until the character you want appears on the display.</p>
Use English word (T9) mode	<p><b>To enter a word:</b></p> <ol style="list-style-type: none"><li>1. Press [<b>2</b>] to [<b>9</b>] to start entering a word.</li><li>2. Enter the whole word before editing or deleting characters.</li><li>3. When the word displays correctly, press [<b>#</b>] to insert a space. Otherwise, press [<b>0</b>] to display alternative word choices.</li></ol>

Use Number mode	Press the keys corresponding to the digits you want.
Use Symbol mode	Press the corresponding number key to select a symbol.
Copy and paste text	<ol style="list-style-type: none"><li>1. Tap or press &lt;<b>Options</b>&gt; and select <b>Copy/Paste</b> → <b>Copy</b>. To copy the whole text, select <b>Full copy</b>.</li><li>2. Highlight the text you want to copy, and tap or press &lt;<b>Select</b>&gt;.</li><li>3. Tap or press &lt;<b>Options</b>&gt; and select <b>Copy/Paste</b> → <b>Paste</b> to paste the copied text.</li></ol>

## Other operations

- Press [**1**] to enter punctuation marks or special characters in ABC mode and T9 mode.
- Press [#] to insert a space.
- Press [\*] to change case.
- Press the Navigation keys to move the cursor.
- Press [C/⌫] to delete characters one by one. In Pen Stroke mode and on the onscreen keyboard, tap .
- Press and hold [C/⌫] to clear the characters on the left side of the cursor.

## Customise your phone

---

### Display language

1. In Idle mode, tap or press <**Menu**> and select **Settings** → 语言 / **Language**.
  2. Select a language.
- 

### Call ringer melody

1. In Idle mode, tap or press <**Menu**> and select **Sounds** → **Ringer**.
2. Press [Down].
3. Press [Left] or [Right] to select a ringtone category.
4. Scroll to a ringtone.
5. Tap or press <**Play**> to listen to a melody.
6. Tap or press <**Save**>.

### Key tone volume

1. In Idle mode, press [**▲/▼**] to adjust the key tone volume.
2. Tap or press **<Save>**.

### Idle mode wallpaper

1. In Idle mode, tap or press **<Menu>** and select **Display** → **Screen saver** → **Image**.
2. Select a category.
3. Scroll to an image.
4. Tap or press **<Save>** or **<Select>**.

### Silent mode

You can switch the phone to Silent mode to avoid disturbing other people. In Idle mode, press and hold [**#**].

### Phone lock

1. In Idle mode, tap or press **<Menu>** and select **Settings** → **Security**.
2. Enter the default password, **00000000**, and tap or press **<Done>**.
3. Select **Change password**.
4. Enter a new 4- to 8-digit password and tap or press **<Done>**.

- 
5. Enter the new password again and tap or press **<Done>**.
  6. Select **Lock mode**.
  7. Select **Once** or **On**.

---

### Select a network

You can select a default network to be used for making calls or sending messages.

1. In Idle mode, press [**C/G**].
2. Scroll to **Main** on the network you want to use and tap or press **<Check>**.
3. Tap or press **<Save>**.

## Use an optional memory card

---

### Important memory card information

- Frequent erasing and writing will shorten a card's lifespan.
- Do not remove a card from the phone or turn off the phone while data is being accessed or transferred. This could result in loss of data and/or damage to the card or phone.
- Do not subject cards to strong shocks.
- Do not touch card terminals with your fingers or metal objects. If dirty, wipe the card with a soft cloth.
- Keep cards away from small children or pets.

- 
- Do not expose cards in a place subject to electrostatic discharge and/or electrical noise.

---

**Insert a memory card**

1. Remove the battery cover and the battery.
2. Unlock the card cover and lift it.
3. Insert the card into the card slot, with the label side face up.

- 
4. Close the card cover and lock it.
  5. Attach the battery and the battery cover.

---

**Remove the memory card**







1. Remove the battery cover and the battery, then open the card cover.
2. Remove the card from the slot.
3. Attach the battery and the battery cover.

## Step outside the phone



Begin with call functions, camera, MP3 player, web browser, and other special features

### Make or answer calls


#### Make a call

1. In Idle mode, enter an area code and phone number.
2. Select the network you want,  or .
3. Press [  ].  
Press [  /  ] to adjust the volume.  
During a call, press any key to activate the display when it turns off.
4. Press [  ] to end the call.

#### Answer a call


1. When the phone rings, press [  ].
2. Press [  ] to end the call.

#### Make a three-way call



1. During a call, call the second participant. The first call is put on hold.
2. Press [  ] to begin the three-way call.

### Use the camera


#### Take a photo

1. In Idle mode, press and hold [  ] to turn on the camera.








2. To change the shooting mode, press [1] once for a series shot, or twice for a divided shot (mosaic shot).
3. Aim the lens at the subject and make any desired adjustments.
4. Press [OK] or [] to take a photo.
5. Tap or press <Save>.


#### View a photo

1. In Idle mode, press [] and select **My album** → **Gallery**.
2. Select the photo you want.

#### Record a video

1. In Idle mode, press and hold [] to turn on the camera.
2. Press [1] three times to switch to Record mode.
3. Tap or press <>, or press [] to start recording.
4. Tap or press <>, or press [] to stop recording.
5. Tap or press <Save>.

#### View a video

1. In Idle mode, press [] and select **My album** → **Gallery**.
2. Select the video you want.
3. Tap or press <Play>.

## Play music

---

### Copy music files to the phone




Use these methods:

- Download from the wireless web.
- Copy directly from a PC.
- Receive via Bluetooth.
- Copy to a memory card and insert the card into the phone.

### Create a playlist

1. In Idle mode, press [**MP3**] and select **MP3 files**.
2. Tap or press <**Options**> and select **Add to play list**.
3. Tap or press <**Check**> to select files.
4. Tap or press <**Add**>.

### Play music files

1. In Idle mode, press [**MP3**] and select **MP3 player**.
2. Tap ▶ or press [OK] to begin playback.
3. During playback, use the following functions:
  - To pause playback, tap || or press [OK].
  - To return to the previous file, tap ⏮ or press [Left].
  - To skip to the next file, tap ⏭ or press [Right].
  - To change the repeat mode, tap  or press [Up].
  - To open the playlist, tap **LIST** or press [Down].

- To set a section in a file to play the section repeatedly, tap or press <**A-B**>.
  - To adjust the volume, press [**▲/▼**].
4. Press [**C/Ⓢ**] to stop playback.

## Browse the web

### Launch the web browser

In Idle mode, press [**ⓈOK**].  
The homepage of your service provider opens.

### Navigate the web

- To scroll through browser items, press [**Up**] or [**Down**].
- To select an item, press <**OK**> or <**✓**>.
- To return to the previous page, press [**C/Ⓢ**].
- To access browser options, press [**ⓈOK**].

## Use Contacts

### Add a contact

1. In Idle mode, enter a phone number and tap or press <**Save**>.
2. Select **New entry**.

- 
3. Tap or press <**Edit**>.
  4. Enter a name and tap or press <**Save**>.
  5. To add a contact to the phone's memory, press [Left] or [Right] and select a number type.
  6. Specify contact information.
  7. Tap or press <**Save**> to save the contact.

---

#### Find a contact

1. In Idle mode, tap or press <**Find**>.
2. Select a search method and press [Down].

- 
3. Enter the first few letters of the name of the contact or the digit of the speed dial entry, or select a contact group or memory location.
  4. Select a contact.
  5. Scroll to a number and press [↩] to dial or tap or press <**Edit**> to edit contact information.

---

## Send or view messages

---

#### Send a text message

1. In Idle mode, tap or press <**Menu**> and select **Messages** → **New message**.

2. Select the network type you want to use.
3. Enter the message text and tap or press **<Next>**.
4. Tap or press **<Next>** again.
5. Enter destination numbers.
6. Tap or press **<Send>** to send the message.


#### View a text message

1. In Idle mode, tap or press **<Menu>** and select **Messages** → **Inbox** → **Text**.
2. Select a text message.


## Use Bluetooth

Your phone is equipped with Bluetooth technology, enabling you to connect the phone wirelessly to other Bluetooth devices and exchange data with them, talk hands-free, or control the phone remotely.

#### Turn on Bluetooth

1. In Idle mode, press [>] and select **Activation** → **On**.
2. Select **Visibility** → **On** to allow other devices to find your phone.

#### Search for and pair with a Bluetooth device

1. In Idle mode, press [>] and select **My Devices**.
2. Tap or press **<Search>**.

- 
3. Scroll to a device and tap or press **<Add>**.
  4. Enter a Bluetooth PIN or the other device's Bluetooth PIN, if it has one, and tap or press **<Done>**.

When the owner of the other device enters the same code, the pairing is complete.

---

#### Send data

1. From the paired device list, scroll to the device you want.
2. Tap or press **<Menu>** and select **Send files**.

- 
3. Select a memory location.
  4. Tap or press **<Check>** to select files and tap or press **<Put>**.
  5. Scroll to the folder you want and tap or press **<Put>**.

---

#### Receive data

To receive from another device:

1. From the paired device list, scroll to the device you want.
2. Tap or press **<Menu>** and select **Get files**.
3. Select a file folder.

4. Tap or press <**Check**> to select files and tap or press <**Get**>.
5. Scroll to the folder you want and tap or press <**Get**>.



To receive sent files:

1. When a device attempts to access your phone, tap or press <**Yes**> to permit the connection.
2. If necessary, tap or press <**Yes**> to confirm that you are willing to receive.

## Use Sketch memo






---

Create a new sketch memo

1. In Idle mode, tap or press <**Menu**> and select **Utilities** → **Memo** → **Sketch memo** → **Sketch memo**.
2. To use a paint brush, tap .  
To use a sketch pen, tap .
3. Draw a sketch using the stylus pen on the screen.

---

4. You can use the following sketch tools on the screen:

- : erase the drawing as you move the pen.
- : cancel your last action.
- : change the line thickness. This option is not available when you use a paint brush.
- : change the pen or brush colour.
- : Access the **View** menu.

5. Tap or press <**Save**> to save the sketch memo.

6. Tap or press <**Yes**>.

---

### View a sketch memo

1. In Idle mode, tap or press <**Menu**> and select **Utilities** → **Memo** → **Sketch memo** → **View**.

2. Tap the memo you want to view.



## Menu functions

*All menu options listed*

This section provides brief explanations of menu functions on your phone.

### uni



The contents available in each menu option may be different, depending on the service provider. For further details, contact your service provider.

Menu	Description
Mail	Access the Mail service, which allows you to send or receive emails containing various media items, such as images, sounds, name cards, and applications.

Menu	Description
Magic	Download and use various Brew applications.
Info	This menu is available only when you use a UTK UIM card that provides additional services.
Music street	Access various audio services supported by your service provider.
Bookmarks	Save URL addresses in order to quickly access web pages.

## Call history

Menu	Description
Missed, Incoming, Outgoing	Check the most recent calls dialed, received, or missed.
Air time	Check the time record for voice calls and data calls made and received.
GSM call cost	Check the cost of your calls in a GSM network, if supported by your SIM card.
Area code	Find and retrieve area <b>or</b> country <b>code</b> to quickly and easily dial phone numbers.

Menu	Description
Call reject	Make a list of the phone numbers from which you do not want to accept calls.
Int'l call prefix	Set international call service numbers.
Answer mode	Select how to answer an incoming call.
Flight mode	Switch the phone to Flight mode, in which the phone functions requiring network connection are deactivated.

**Contacts**

Menu	Description
Find	Search for contact information stored in Contacts.
Add	Add a new contact to Contacts.
Group settings	Set up a caller group list for organising contacts.
Speed dial	Assign a speed dial number for your most frequently dialled numbers.
Name card	Save name cards as data file format and send them to other people.

Menu	Description
My phone #	Check your phone number or edit your number.
Memory info	Check information about the memory currently in use.

**Multimedia**

Menu	Description
Take photo	Use the camera embedded in your phone to take photos and record videos.
Namecard recognition	Take a name card photo and save it as a new contact in Contacts.

Menu	Description
My album	Access the photos you have taken and the videos you have recorded.
External album	Access photos and videos on a memory card, when you insert a memory card into the phone.
Photo studio	Edit photos by applying special effects or adding comments.
Settings	Change the default settings for the options when using the camera.

## Display

Menu	Description
Screen saver	Change the background image or set a banner message to be displayed on the idle screen.
Functional screen	Select a function screen to be displayed in Idle mode.
Power on/off	Select an image to be displayed when the phone is switched on or off.
Dialing font	Select a font style for digits to be displayed when you enter a phone number for dialling.
Time settings → Single clock	Set the current time and date.

Menu	Description
Time settings → Dual clock	Set up the time zones for the Dual clock wallpaper.
Time settings → Auto timezone	Set your phone to update the current time automatically when you travel abroad. Time information may not be updated when you move to one time zone to another within a country.
Backlight → Main LCD	Select the length of time the backlight or display stays on when the phone is not used.
Backlight → LCD brightness	Adjust the brightness of the display for varying lighting conditions.

Menu	Description
Backlight → Keypad	Set how the phone controls the use of the keypad light.

## Messages

Menu	Description
New message	Create and send text messages.
Inbox, Outbox, Drafts	Access messages that you have received, sent, saved to send at a later time, or that have failed during sending.
Msg. setup	Set up various options for using the messaging services.

Menu	Description
SOS message	Specify options for sending and receiving an SOS message. You can send an SOS message by pressing [▲/▼] 4 times in Idle mode, with the phone closed.
Msg. wallpaper	Select a background image to be displayed on the message screen so that you can view message with the image.
Memory info	Check information about the memory currently in use.

## Sounds

Menu	Description
Ringer	Set a ringer for calls, messages, alarms, or scheduler.
Ringer vol./type	Adjust the ringer volume for calls, messages, alarms, or scheduler.
Key tone	Select the tone that the phone sounds when you press a key.
Function alert	Set up audible alerts at a specified time to inform you that certain things have happened.
Hour alert	Set the phone to sound an alert every hour on the hour.

## Entertainment

Menu	Description
Games <sup>1</sup>	Play various games.
MP3	Listen to music.
Melody composer	Compose your own melodies using a variety of musical components.
Karaoke	Enjoy karaoke video files you have downloaded as you would in a karaoke.
Fun box <sup>1</sup>	Access Samsung Fun Club, the preset website providing Samsung mobile phone users with attractive download services.

Menu	Description
Samsung messenger	Have a conversation with your friends, family, or co-workers by sending and receiving instant messages.

1. All rights and responsibilities for the Java-based games embedded in your phone and media contents provided by Samsung Fun Club, such as images, sounds, and Java applications, belong to their respective owners.

## Utilities

Menu	Description
Today	View information of scheduled items for the current day.

Menu	Description
Calendar	Keep track of your schedule.
Task list	Make a list of tasks you need to do.
Alarm	Set a wake-up call to wake you up in the morning or an alarm to alert you to an event at a specific time. You can also set the alarm to sound when the phone is off.
User memory	Connect the phone to a PC, as you would use an external memory disk drive and access files of your phone's memory or a memory card.

Menu	Description
Voice tools	Use the voice recognition feature or record voice memos.
Memo	Make memos or sketch memos for things that are important and manage them.
Calculator	Perform arithmetic functions and do conversions, such as length and temperature.
Countdown	Measure how long it takes you to do something or how many days remain until a specific event occurs. The alarm for the timer will sound at 9 AM on the target date.



## Menu functions

Menu	Description
Clock	Find out the current time in another part of the world and measure elapsed time.
Dictionary	Search for words and organise your own dictionary.
Bluetooth	Connect the phone wirelessly to other Bluetooth devices.

## Settings

Menu	Description
CDMA network services → Call forward	Set the phone to reroute incoming calls to a phone number that you specify.

Menu	Description
CDMA network services → Call waiting	Set the phone to inform you when someone is trying to reach you while you are on another call.
CDMA network services → Emergency #	Store three emergency numbers or edit them. You can dial these numbers, even if your phone is locked.
CDMA network services → Voice privacy	Use an encrypted high security line so that people cannot eavesdrop on your conversation, or use a standard line.

Menu	Description
CDMA network services → Dialup networking	Set whether or not to use your phone as an external modem for a PC via USB.
GSM network services → Call diverting	Set the phone to reroute incoming calls to a phone number that you specify.
GSM network services → Call barring	Set the phone to restrict your calls.
GSM network services → Call waiting	Set the phone to inform you when someone is trying to reach you while you are on another call.

Menu	Description
GSM network services → Network selection	Allow you to either automatically or manually select the network used when roaming outside of your home area.
GSM network services → Band selection	Register with an available network for the phone to make and receive phone calls.
GSM network services → Caller ID	Set the phone to hide your phone number from the person you are calling.
Shortcut settings → Shortcuts	Use the Navigation keys as shortcuts to access specific menus directly from Idle mode. [Left] is fixed as a shortcut to <b>Messages</b> .

## Menu functions

Menu	Description
Shortcut settings → My menu	Set up a menu of your own using your favourite menu items.
Security → Lock mode	Activate your phone password to protect your phone against unauthorised use.
Security → Change password	Change the phone password.
Security → Contacts restriction	Restrict the use of Contacts.
Security → Clear memory	Delete contacts or messages stored on the SIM card or the UIM card, or in the phone's memory.

Menu	Description
Security → Reset phone	Reset the phone's settings you have changed.
Security → Card slot1 setup or Card slot2 setup	Access the security options for the currently used card.
Network selection	Switch between GSM and CDMA networks. You can also set how to select a network type the next time the phone turns on.
Input method → Mode setting	Select a default text input mode.
Input method → Fuzzy pinyin	Select Fuzzy pinyin pairs so that you can easily enter characters that are similar in phonetic spelling

Menu	Description
Stylus adjust	Calibrate your phone's touch screen by tapping the cross hair object firmly and precisely.
语言 /Language	Change the language of the display text.
Domains preset	Change the default domain name extensions.
Contents status	Check information about the memory currently in use.
My phone info	View your phone information.

## *Health and safety information*

### **The names and content of toxic and hazardous substances or elements**

Part	Toxic and hazardous substances or elements					
	Pb	Hg	Cd	Cr <sup>6+</sup>	PBB	PBDE
PBA	X	O	O	O	O	O
Plastic	O	O	O	O	O	O
Metal	X	O	O	O	O	O
Battery	X	O	O	O	O	O
Accessory	X	O	O	O	O	O

O: Indicates that the toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006.

X: Indicates that the toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363-2006.

The information provided in this table is based on figures presented by supply manufacturers and tests conducted by Samsung. All toxic and hazardous substances or elements are used at the minimum level allowed by current technology. Samsung continues to make every effort to reduce the need for these substances or elements through improved technology.



The “environmental protection use period” for this product is 20 years and the corresponding logo is as shown on the left. Exchangeable parts, such as batteries, may have different periods of warranty. The “environmental protection use period” is valid only when the product is used under normal conditions, as described in the user’s guide.

## Exposure to Radio Frequency (RF) Signals

---

### Certification Information (SAR)

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. government. These FCC exposure limits are derived from the recommendations of two expert organizations, the National Council on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The exposure limit set by the FCC for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg). The FCC exposure limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so

as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

When approval test is done, no Samsung supplied accessories are available but maybe available later after approval.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each model phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

The highest SAR values for this model phone as reported to the FCC are: CDMA800 Head: 0.397W/Kg; Body Worn: 0.614W/Kg.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with a Samsung accessory

designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.5 cm from the body.

Non-compliance with the above restrictions may result in violation of FCC RF exposure guidelines.

SAR information on this and other model phones can be viewed on-line at [www.fcc.gov/oet/fccid](http://www.fcc.gov/oet/fccid). This site uses the phone FCC ID number, A3LSCHW619. Sometimes it may be necessary to remove the battery pack to find the number. Once you have the FCC ID number for a particular phone, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone. Additional product specific SAR information can also be obtained at [www.fcc.gov/cgb/sar](http://www.fcc.gov/cgb/sar).

## **Consumer Information on Wireless Phones**

---

The U.S. Food and Drug Administration (FDA) has published a series of Questions and Answers for consumers relating to radio frequency (RF) exposure from wireless phones. The FDA publication includes the following information:

### **What kinds of phones are the subject of this update?**

The term wireless phone refers here to hand-held wireless phones with built-in antennas, often called "cell," "mobile," or "PCS" phones. These types of wireless phones can expose the user to measurable radio frequency energy (RF) because of the short distance between the phone and the user's head. These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other

federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures well within the FCC's compliance limits.

### **Do wireless phones pose a health hazard?**

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radio frequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by

heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

### **What is FDA's role concerning the safety of wireless phones?**

Under the law, FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radio frequency energy (RF) at a level that is hazardous to the user. In such a case, FDA



could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

- "Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- "Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- "Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health.

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure

coordinated efforts at the federal level. The following agencies belong to this working group:

- "National Institute for Occupational Safety and Health
- "Environmental Protection Agency
- "Federal Communications Commission
- "Occupational Safety and Health Administration
- "National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. FCC relies on FDA and other health

agencies for safety questions about wireless phones.

FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the primary subject of the safety questions discussed in this document.

### **What are the results of the research done already?**

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radio frequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated

in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers.

None of the studies demonstrated the existence of any harmful health effects from wireless phones RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

### **What research is needed to decide whether RF exposure from wireless phones poses a health risk?**

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but ten or more years' follow-up may be needed to provide answers about some health effects,

such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop - if they do - may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

### **What is FDA doing to find out more about the possible health effects of wireless phone RF?**

FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radio frequency energy (RF).

FDA has been a leading participant in the World Health Organization international

Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues.

FDA and Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs

in the context of the latest research developments around the world.

### **What steps can I take to reduce my exposure to radio frequency energy from my wireless phone?**

If there is a risk from these products - and at this point we do not know that there is - it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radio frequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

- "If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically

with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna.

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

### **What about children using wireless phones?**

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radio frequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and

increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

### **Do hands-free kits for wireless phones reduce risks from exposure to RF emissions?**

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that hands-free kits reduce

risks. Hands-free kits can be used with wireless phones for convenience and comfort. These systems reduce the absorption of RF energy in the head because the phone, which is the source of the RF emissions, will not be placed against the head. On the other hand, if the phone is mounted against the waist or other part of the body during use, then that part of the body will absorb more RF energy. Wireless phones marketed in the U.S. are required to meet safety requirements regardless of whether they are used against the head or against the body. Either configuration should result in compliance with the safety limit.

### **Do wireless phone accessories that claim to shield the head from RF radiation work?**

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that accessories that claim

to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone. Studies have shown that these products generally do not work as advertised. Unlike "hand-free" kits, these so-called "shields" may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption. In February 2002, the Federal Trade Commission (FTC) charged two companies that sold devices that claimed to protect wireless phone users from radiation with making false and unsubstantiated claims. According to FTC, these defendants lacked a reasonable basis to substantiate their claim.

### **What about wireless phone interference with medical equipment?**

Radio frequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical Instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI. FDA has tested wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a

person uses a compatible phone and a compatible hearing aid at the same time. This standard was approved by the IEEE in 2000.

FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct testing to assess the interference and work to resolve the problem.

Additional information on the safety of RF exposures from various sources can be obtained from the following organizations:

- FCC RF Safety Program:  
<http://www.fcc.gov/oet/rfsafety/>
- Environmental Protection Agency (EPA):  
<http://www.epa.gov/radiation/>
- Occupational Safety and Health Administration's (OSHA):  
<http://www.osha.gov/SLTC/radiofrequencyradiation/index.html>

- National institute for Occupational Safety and Health (NIOSH):  
<http://www.cdc.gov/niosh/emfpg.html>
- World health Organization (WHO):  
<http://www.who.int/peh-emf/>
- International Commission on Non-Ionizing Radiation Protection:  
<http://www.icnirp.de>
- National Radiation Protection Board (UK):  
<http://www.nrpb.org.uk>
- Updated 4/3/2002: US food and Drug Administration  
<http://www.fda.gov/cellphones>

## **Road Safety**

---

Your wireless phone gives you the powerful ability to communicate by voice, almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

1. Get to know your wireless phone and its features, such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.
2. When available, use a hands-free device. If possible, add an additional layer of convenience and safety to your wireless



- phone with one of the many hands free accessories available today.
3. Position your wireless phone within easy reach. Be able to access your wireless phone without removing your eyes from the road. If you get an incoming call at an inconvenient time, let your voice mail answer it for you.
  4. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice and even heavy traffic can be hazardous.
  5. Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or flipping through your address book takes attention away from your primary responsibility, driving safely.
  6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
  7. Do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that have the potential to divert your attention from the road.
  8. Use your wireless phone to call for help. Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies. Remember, it is a free call on your wireless phone!
  9. Use your wireless phone to help others in emergencies. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.

10. Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency number.

**“The wireless industry reminds you to use your phone safely when driving.”**

For more information, please call 1-888-901-SAFE, or visit our web-site [www.wow-com.com](http://www.wow-com.com)

Provided by the Cellular Telecommunications & Internet Association

## **Operating Environment**

---

Remember to follow any special regulations in force in any area and always switch your phone off whenever it is forbidden to use it, or when it may cause interference or danger. When

connecting the phone or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and for the safety of personnel, it is recommended that the equipment should only be used in the normal operating position (held to your ear with the antenna pointing over your shoulder).

## **Using Your Phone Near Other Electronic Devices**

---

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. Consult the manufacturer to discuss alternatives.

## **Pacemakers**

Pacemaker manufacturers recommend that a minimum distance of 15 cm (6 inches) be maintained between a wireless phone and a pacemaker to avoid potential interference with the pacemaker.

These recommendations are consistent with the independent research and recommendations of Wireless Technology Research.

### **Persons with pacemakers:**

- should always keep the phone more than 15 cm (6 inches) from their pacemaker when the phone is switched on.
- should not carry the phone in a breast pocket.
- should use the ear opposite the pacemaker to minimize potential interference.

If you have any reason to suspect that interference is taking place, switch your phone off immediately.

## **Hearing Aids**

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may wish to consult your hearing aid manufacturer to discuss alternatives.

## **Other Medical Devices**

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your phone off in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

## **Vehicles**

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

## **Posted Facilities**

Switch your phone off in any facility where posted notices require you to do so.

## **Potentially Explosive Environments**

Switch your phone off when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Users are advised to switch the phone off while at a refueling point (service station). Users are

reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

## **Emergency Calls**

---

This phone, like any wireless phone, operates using radio signals, wireless and landline networks as well as user programmed functions, which cannot guarantee connection in all conditions. Therefore, you should never rely solely on any wireless phone for essential communications (medical emergencies, for example).

Remember, to make or receive any calls the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks or when certain network services and/or phone features are in use. Check with local service providers.

To make an emergency call:

1. If the phone is not on, switch it on.
2. Key in the emergency number for your present location (for example, 911 or other

official emergency number). Emergency numbers vary by location.

3. Press .

If certain features are in use (call barring, for example), you may first need to deactivate those features before you can make an emergency call. Consult this document and your local cellular service provider.

When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your phone may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

### **Restricting Children's access to your Phone**

Your phone is not a toy. Children should not be allowed to play with it because they could hurt themselves and others, damage the phone or make calls that increase your phone bill.

## FCC Notice and Cautions

---

### FCC Notice

- ☑ • This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and,

- ☑ if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

The phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Battery march Park, Quincy, MA 02269, Attn: Publication Sales Division.

### **Cautions**

Changes or modifications made in the radio phone, not expressly approved by Samsung, will void the user's authority to operate the equipment.

Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and void the

phone warranty if said accessories cause damage or a defect to the phone.

Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.

### **Other Important Safety Information**

---

- Only qualified personnel should service the phone or install the phone in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Check regularly that all wireless phone equipment in your vehicle is mounted and operating properly.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as the phone, its parts or accessories.

- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including both installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Switch your phone off before boarding an aircraft. The use of wireless phone in aircraft is illegal and may be dangerous to the aircraft's operation.
- Failure to observe these instructions may lead to the suspension or denial of telephone services to the offender, or legal action, or both.

## **Product Performance**

---

### **Getting the Most Out of Your Signal Reception**

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current signal strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal.

If you're inside a building, being near a window may give you better reception.

### **Understanding the Power Save Feature**

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. If your phone is active, it periodically rechecks service availability or you can check it yourself by pressing any key.



Anytime the Power Save feature is activated, a message displays on the screen. When a signal is found, your phone returns to standby mode.

### **Understanding How Your Phone Operates**

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.006 watts to 0.2 watts in digital mode.

### **Maintaining Your Phone's Peak Performance**

For the best care of your phone, only authorized personnel should service your phone and accessories. Faulty service may void the warranty.

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- Hold the phone with the antenna raised, fully-extended and over your shoulder.
- Try not to hold, bend or twist the phone's antenna.
- Don't use the phone if the antenna is damaged.
- Speak directly into the phone's receiver.
- Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it is inoperable, call Customer Care for service.

### **Availability of Various Features/ Ring Tones**

---

Many services and features are network dependent and may require additional

subscription and/or usage charges. Not all features are available for purchase or use in all areas. Downloadable Ring Tones may be available at an additional cost. Other conditions and restrictions may apply. See your service provider for additional information.

## **Battery Standby and Talk Time**

---

Standby and talk times will vary depending on phone usage patterns and conditions. Battery power consumption depends on factors such as network configuration, signal strength, operating temperature, features selected, frequency of calls, and voice, data, and other application usage patterns.

## **Battery Precautions**

---

- Never use any charger or battery that is damaged in any way.
- Use the battery only for its intended purpose.

- If you use the phone near the network's base station, it uses less power; talk and standby time are greatly affected by the signal strength on the cellular network and the parameters set by the network operator.
- Battery charging time depends on the remaining battery charge and the type of battery and charger used. The battery can be charged and discharged hundreds of times, but it will gradually wear out. When the operation time (talk time and standby time) is noticeably shorter than normal, it is time to buy a new battery.
- If left unused, a fully charged battery will discharge itself over time.
- Use only Samsung-approved batteries and recharge your battery only with Samsung-approved chargers. When a charger is not in use, disconnect it from the power source. Do not leave the battery connected to a charger for more than a week, since overcharging may shorten its life.

- Extreme temperatures will affect the charging capacity of your battery: it may require cooling or warming first.
- Do not leave the battery in hot or cold places, such as in a car in summer or winter conditions, as you will reduce the capacity and lifetime of the battery. Always try to keep the battery at room temperature. A phone with a hot or cold battery may temporarily not work, even when the battery is fully charged. Li-ion batteries are particularly affected by temperatures below 0 °C (32 °F).
- Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object (coin, clip or pen) causes a direct connection between the + and - terminals of the battery (metal strips on the battery), for example when you carry a spare battery in a pocket or bag. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting.
- Dispose of used batteries in accordance with local regulations. In some areas, the disposal of batteries in household or business trash may be prohibited. For safe disposal options for Li-Ion batteries, contact your nearest Samsung authorized service center. Always recycle. Do not dispose of batteries in a fire.

## Care and Maintenance

---

Your phone is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years.

- Keep the phone and all its parts and accessories out of the reach of small children.
- Keep the phone dry. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits.

- Do not use the phone with a wet hand. Doing so may cause an electric shock to you or damage to the phone.
- Do not use or store the phone in dusty, dirty areas, as its moving parts may be damaged.
- Do not store the phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the phone in cold areas. When the phone warms up to its normal operating temperature, moisture can form inside the phone, which may damage the phone's electronic circuit boards.
- Do not drop, knock or shake the phone. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the phone. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.
- Do not paint the phone. Paint can clog the device's moving parts and prevent proper operation.
- Do not put the phone in or on heating devices, such as a microwave oven, a stove or a radiator. The phone may explode when overheated.
- When the phone or battery gets wet, the label indicating water damage inside the phone changes color. In this case, phone repairs are no longer guaranteed by the manufacturer's warranty, even if the warranty for your phone has not expired.
- If your phone has a flash or light, do not use it too close to the eyes of people or animals. This may cause damage to their eyes.

## *Health and safety information*

- Use only the supplied or an approved replacement antenna. Unauthorized antennas or modified accessories may damage the phone and violate regulations governing radio devices.
- If the phone, battery, charger or any accessory is not working properly, take it to your nearest qualified service facility. The personnel there will assist you, and if necessary, arrange for service.

Licensed by QUALCOMM incorporated under one or more of the following Patents.

U.S Patent No. 4,901,307 5,056,109  
5,099,204 5,101,501  
5,103,459 5,107,225  
5,109,390