

MOBILE ENHANCEMENT

Printed in Korea

Code NO.: GH68-xxxxxA

09/2006. Rev.1.0



Bluetooth Headset WEP210

MOBILE ENHANCEMENT





Contents

BEFORE USING YOUR HEADSET Checking phone compatibility Checking the accessories Your headset overview Charging the headset Storage of the headset	4 4 5
BASIC OPERATIONS Turning the headset on/off Pairing with your Bluetooth phone	
APPENDIX Frequently asked questions Certification and Safety approvals UL certified travel adapter Warranty and parts replacement Correct disposal of this product	17 18 19

Thank you for purchasing the Samsung Bluetooth Mono Headset WEP210. We hope you will be delighted with its operation.

Please read this user's guide to get started, and to make the best use of the headset's many features.



Safety precautions

- Never disassemble or modify your headset any reason. Doing this may the headset to malfunction or become combustible. Bring the headset to an authorised service centre to repair it or replace the battery.
- When you are driving a car, driving is your first responsibility.
- When using your headset while driving, follow local regulations in the country or region you are in.

BEFORE USING YOUR HEADSET



Checking phone compatibility

Your headset is compatible with most Bluetooth* phones that are compliant with Bluetooth version 1.1 or higher and support the headset and/or hands-free profile(s). Ensure that your phone has Bluetooth capability by visiting your phone manufacturer's web site.



Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your headset.

^{*} Bluetooth is a radio technology developed to connect devices, such as mobile phones and headsets, without wires or cords over a short distance of approximately 10 metres. More information is available at www.bluetooth.com.


R Checking the accessories

Make sure you have the following items with your headset: Travel Adapter, User's Guide



The items supplied with your headset may vary, depending on your country or service provider.

Your headset overview



Charging the headset

Your headset uses a rechargeable battery. You must charge the battery fully before using the headset for the first time.

1 Plug the travel adapter into the jack on the headset.



- 2 Plug the travel adapter into an electrical outlet.
 - Charge the headset until the red light on the headset turns to blue.
 - The headset will be fully charged in approximately 2 hours and 30 minutes.
- 3 Remove the travel adapter from the headset.



Do not attempt to charge the headset with anything other than the travel adapter provided. Using unauthorised travel adapter may damage the headset.



The headset is not able to operate while charging. Try connecting after charging is completed.

Storage of the headset

- Always store the headset with the power off and make sure it is safely protected.
- Avoid storage at high temperatures (above 40° C / 104° F), such as in a hot vehicle or in direct sunlight. Storage at high temperatures can damage performance and reduce battery life
- Do not expose the headset or any of its supplied parts to rain or other liquids.

BASIC OPERATIONS

Turning the headset on/off

То	Press and hold	You will hear	You will see
headset on	the Multi-Function button for 4 seconds until you see 4 blue flashes on the indicator light.	a tone.	the indicator light flashes while the power is on (see Meaning of the indicator light).

6

То	Press and hold	You will hear	You will see
headset off	the Multi-Function button for 4 seconds until you see blue and red flashes on the indicator light.	series of 2 tones.	the indicator light stops flashing.

Meaning of the indicator light

Light	Tone	Status
Flashes in blue every 8 seconds.	Quick series of 2 tones. (Active mode starts.)	The headset is in Active mode. • The headset has an active call in progress. • You can talk up to 4 hours. *
Flashes in blue every 3 seconds.	Quick series of 2 tones. (Standby mode starts.)	The headset is in Standby mode. The headset is waiting for a call. The headset can be in Standby mode up to 70 hours.*
Flashes in red.	5 tones every 20 seconds.	The battery of the headset is low. • There is less than 10% of battery power left. Recharge the battery.

 $^{^{\}star}$ Depending on the phone type and usage, the actual time may vary.


Real Pairing with your Bluetooth phone

Pairing will create a unique and encrypted wireless link between two Bluetooth enabled devices, such as your Bluetooth phone and Bluetooth headset



When you turn on your headset for the first time, the headset proceeds into Pairing mode so that you can immediately pair it with other devices.

- 1 Ensure that the headset is off (see Turning the headset on/off).
- 2 Press and hold the Multi-Function button until the indicator light turns on in blue (approximately 8 seconds).



- **3** Set your Bluetooth phone to discover the headset by following your phone's guide.
 - Typically, the steps involve going to a 'Settings,' 'Connection', or 'Bluetooth' menu on your phone and then selecting the option to discover Bluetooth devices.
- 4 Your phone will find the Samsung WEP210 headset and ask if you want to pair with it. Confirm this by pressing the Yes or OK key.
- 5 Enter a passkey or PIN, 0000 (4 zeros), then press the Yes or OK key.



If pairing was successful, the indicator light will flash in blue 10 times rapidly before going to flashing every 3 seconds. If unsuccessful, the light remains on, and you will need to re-attempt pairing.

Wearing the headset

Wear the headset on your ear. In general, you will get better performance when there are no obstructions (including parts of your body) between the headset and the phone.



Making a call

Making a voice activated call

If the voice recognition feature is on, you can make a voice activated call.

- 1 Press and hold the Multi-Function button. You will hear the voice-activation tone.
- 2 Say the name of the person you wish to call. Depending on your phone, this feature is not supported.

Redialling the last number

Press the Multi-Function button. When you release the button, the phone dials the last dialled or received number.



Depending on your phone, how to redial the last number may vary.




Press the Multi-Function button.

Answering a call

When a call comes in, the headset sounds the ring tone and flashes the blue indicator twice. Press the Multi-Function button.



Do not hold the Multi-Function button down too long when making a call with your voice, ending, or answering a call. This should only be a quick tap.



Press [Volume Up] on the side of the headset to increase the volume level and [Volume Down] to decrease the volume level.



At very high volumes, prolonged listening to the headset can damage your hearing.

Switching on the microphone

Press and hold [Volume Up] or [Volume Down] to switch off the headset's microphone. To switch it back on, press and hold either one again.

Transferring a call from the phone to the headset

If you answer the call with your phone, you can transfer the call to the headset by pressing the Multi-Function button.

Turning the indicator light on or off

You can deactivate the use of the indicator light in Standby mode and in Active mode.

Press and hold [Volume Up] and [Volume Down] to turn the indicator light on or off.

Using enhanced features

Enhanced features are available for phones that support the Hands-free profile and enhanced features.

Rejecting a call

When you receive a call, press and hold the Multi-Function button.

Depending on your phone's setting or type, you may only be able to mute the ringer or this feature may not be supported.

Placing a call on hold

While you are on a call, press and hold the Multi-Function button.

To retrieve the call, press and hold the Multi-Function button again.

Depending on your phone, this feature is not supported.

· Answering a second call

When your phone notifies you of another incoming call while you are on a call, press and hold the Multi-Function button to answer the second call.

You can switch between calls by pressing and holding it. Depending on your phone, this feature is not supported.

APPENDIX

Frequently asked questions

How far away from my phone will the headset work?	The operating range is typically up to 30 feet (10 metres).
Will the headset work with my cordless phone at home?	The headset is not designed for use with cordless phones.
Will the headset work with laptops, PCs, and PDAs?	The headset will work with devices that are compliant with Bluetooth version 1.1 or higher and support the Headset and/or Hands-free profile(s).
Will anything cause interference with my conversation when I'm using the headset?	Appliances such as cordless phones and wireless networking equipment may cause interference with your conversation. To reduce any interference, keep the headset away from other devices that use or produce radio waves.

Will the headset interfere with my car's electronics, radio, or computer?	The headset produces significantly less power than a typical mobile phone. It also only emits signals that are in compliance with the international Bluetooth standard. Therefore, you should not expect any interference with standard consumer-grade electronics equipment.
Can other Bluetooth phone users hear my conversation?	When you pair the headset to your Bluetooth phone, you are creating a private link between only these two Bluetooth devices. The wireless Bluetooth technology used in the headset is not easily monitored by third parties, because Bluetooth wireless signals are significantly lower in radio frequency power than those produced by a typical mobile phone.
How do I take care of the headset?	To clean the headset, use a clean, soft cloth that is slightly damp.
Does not the headset fully charge?	The headset and the travel adapter may not have been connected properly. Separate the headset from the travel adapter and then reconnect and charge the headset.

Certification and Safety approvals

Bluetooth

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Samsung is under license. Other trademarks and trade names are those of their respective owners.

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Users are not permitted to make changes or modify the device in any way.

Changes or modifications not expressly approved by Samsung will void the user's authority to operate the equipment.

UL certified travel adapter

The travel adapter for this headset has met UL 1310 safety requirements.

Please adhere to the following safety instructions per UL guidelines.

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTATED IN A VERTICAL OR HORIZONTAL OR FLOOR MOUNT POSITION.

Warranty and parts replacement

Samsung warrants this product as free of defects in material, design and workmanship for the period of one year from the original date of purchase*.

If during the period of warranty this product proves defective under normal use and service you should return the product to the retailer from whom it was originally purchased or qualified service center. The liability of Samsung and its appointed maintenance company is limited to the cost of repair and/or replacement of the unit under warranty.

- The warranty is limited to the original purchaser
- A copy of your receipt or other proof of purchase is required for a proper warranty service
- · The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation modification, or repair by unauthorised third parties
- The responsibility of Samsung products shall be limited to the repair or replacement of the product at its sole discretion

Depending on your country, the length of warranty may vary.

- Specifically exempt from any warranty are limited-life consumable components such as batteries and other accessories
- Samsung is not liable to for any incidental or consequential damages arising from the use or misuse of any Samsung product
- This warranty gives you specific rights and you may have other rights which vary from area to area
- Unless otherwise instructed in the User Guide, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on the unit, whether in or out of warranty. It must be returned to the purchase point, factory or authorised service agency for all such work
- Samsung will not assume any responsibility for any loss or damage incurred in shipping. All repair work on Samsung products by unauthorised third parties voids any warranty

Correct disposal of this product



(Waste Electrical & Electronic Equipment)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.