

MOBILE ENHANCEMENT

World Wide Web http://www.samsungmobile.com Printed in Korea Code No.: GH68-12948A

3/2006. Rev.1.0



Bluetooth Headset WEP430

MOBILE ENHANCEMENT

Contents

BEFORE USING YOUR HEADSET	
Checking phone compatibility	3
Checking the accessories	4
Your headset overview	4
Charging the headset	
Storage of the headset	
BASIC OPERATIONS	
Turning the headset on/off	_
Pairing with your Bluetooth phone	9
Making a call	
Ending a call	
Answering a call	
Switching on the microphone	
Transferring a call from the phone to the headset	
Turning the indicator light on or off	
Using enhanced features	15
APPENDIX	
Frequently asked questions	. 17
Certification and Safety approvals	
UL certified travel adapter	
Warranty and parts replacement	
Correct disposal of this product	
correct disposar or this product infilinitianinininininininininini	27

Thank you for purchasing the Samsung Bluetooth Mono Headset WEP430. We hope you will be delighted with its operation.

Please read this user's guide to get started, and to make the best use of the headset's many features.



Safety precautions

- Never disassemble or modify your headset for any reason. Doing this may cause the headset to malfunction or become combustible. Bring the headset to an authorized service center to repair it or replace the battery.
- When you are driving a car, driving is your first responsibility.
- When using your headset while driving, follow local regulations in the country or region you are in.

BEFORE USING YOUR HEADSET

8

Checking phone compatibility

Your headset is compatible with most Bluetooth* phones that are compliant with Bluetooth version 1.1 or higher and support the Headset and/or Hands-Free Profile(s). Ensure that your phone has Bluetooth capability by visiting your phone manufacturer's web site.



Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your headset.

^{*} Bluetooth is a radio technology developed to connect devices, such as mobile phones and headsets, without wires or cords over a short distance of approximately 10 meters. More information is available at www.bluetooth.com.

R Checking the accessories

Make sure you have the following items with your headset: Travel Adapter, User's Guide, Earpiece Cover



The items supplied with your headset may vary, depending on your country or service provider.



Your headset overview

Charging the headset

Your headset uses a rechargeable battery. You must charge the battery fully before using the headset for the first time.

1 Plug the travel adapter into the jack on the headset.

- 2 Plug the travel adapter into an electrical outlet.
 - Charge the headset until the red light on the headset turns to blue.
 - The headset will be fully charged in approximately 2 hours and 30 minutes.

3 Remove the travel adapter from the headset.



Do not attempt to charge the headset with anything other than the travel adapter provided. Using unauthorized travel adapter may damage the headset.



The headset is not able to operate while charging. Try connecting after charging is completed.

Storage of the headset

- Always store the headset with the power off and make sure it is safely protected.
- Avoid storage at high temperatures (above 50° C / 122° F), such as in a hot vehicle or in direct sunlight. Storage at high temperatures can damage performance and reduce battery life.
- Do not expose the headset or any of its supplied parts to rain or other liquids.

BASIC OPERATIONS

Turning the headset on/off

То	Press and hold	You will hear	You will see
turn the headset on	the Multi-Function button for 4 seconds until you see 4 blue flashes on the indicator light.	a tone.	the indicator light flashes while the power is on (see Meaning of the indicator light).
turn the headset off	the Multi-Function button for 4 seconds until you see blue and red flashes on the indicator light.	series of 2 tones.	the indicator light stops flashing.

Meaning of the indicator light

Light	Tone	Status
Flashes in blue every 8 seconds.	Quick series of 2 tones. (Active mode starts.)	The headset is in Active mode. • The headset has an active call in progress. • You can talk up to 5 hours 30 minutes.*
Flashes in blue every 3 seconds.	Quick series of 2 tones. (Standby mode starts.)	The headset is in Standby mode. The headset is waiting for a call. The headset can be in Standby mode up to 70 hours.*
Flashes in red.	5 tones every 20 seconds.	The battery of the headset is low. • There is less than 10% of battery power left. Recharge the battery.

^{*} Depending on the phone type and usage, the actual time may vary.

Pairing with your Bluetooth phone

Pairing will create a unique and encrypted wireless link between two Bluetooth enabled devices, such as your Bluetooth phone and Bluetooth headset.



When you turn on your headset for the first time, the headset proceeds into Pairing mode so that you can immediately pair it with other devices.

- Ensure that the headset is off (see **Turning the headset** on/off).
- 2 Press and hold the Multi-Function button until the blue indicator light stays on after blinking.

- **3** Set your Bluetooth phone to discover the headset by following your phone's guide.
 - Typically, the steps involve going to a 'Settings,' 'Connection', or 'Bluetooth' menu on your phone and then selecting the option to discover Bluetooth devices.
- 4 Your phone will find the Samsung WEP430 headset and ask if you want to pair with it. Confirm this by pressing the Yes or OK key.
- 5 Enter a passkey or PIN, 0000 (4 zeros), then press the Yes or OK key.



If pairing was successful, the indicator light will flash in blue 10 times rapidly before going to flashing every 3 seconds. If unsuccessful, the light remains on, and you will need to re-attempt pairing.

Wearing the headset

Wear the headset on your ear. In general, you will get better performance when there are no obstructions (including parts of your body) between the headset and the phone.

You can replace the original earpiece cover with the supplied loop earpiece cover. Depending on what ear you are going to wear the headset, simply adjust the loop accordingly.

Making a call

Making a voice activated call

If the voice recognition feature is on, you can make a voice activated call.

- 1 Press and hold the Multi-Function button. You will hear the voice-activation tone.
- **2** Say the name of the person you wish to call. Depending on your phone, this feature is not supported.

Redialing the last number

Press the Multi-Function button to dial the last dialed or received number.



Depending on your phone, redialing the last number may vary.

Press the Multi-Function button.

Answering a call

When a call comes in, the headset sounds the ring tone and flashes the blue indicator twice. Press the Multi-Function button.



Do not hold the Multi-Function button down too long when making a call with your voice, ending, or answering a call. This should only be a quick tap.



Adjusting the volume

Press [Volume Up] on the side of the headset to increase the volume level and [Volume Down] to decrease the volume level.



At very high volumes, prolonged listening to the headset can damage your hearing.



Switching on the microphone

Press and hold [Volume Up] or [Volume Down] to switch off the headset's microphone. To switch it back on, press and hold either one again.



Transferring a call from the phone to the headset

If you answer the call with your phone, you can transfer the call to the headset by pressing the Multi-Function button.

Turning the indicator light on or off

You can deactivate the use of the indicator light in Standby mode and in Active mode.

Press and hold [Volume Up] and [Volume Down] to turn the indicator light on or off.

8 Using enhanced features

Enhanced features are available for phones that support the Hands-Free Profile and enhanced features.

Rejecting a call

When you receive a call, press and hold the Multi-Function button.

Depending on your phone's setting or type, you may only be able to mute the ringer or this feature may not be supported.

· Placing a call on hold

While you are on a call, press and hold the Multi-Function button.

To retrieve the call, press and hold the Multi-Function button again.

Depending on your phone, this feature may not be supported.

Answering a second call

When your phone notifies you of another incoming call while you are on a call, press and hold the Multi-Function button to answer the second call.

You can switch between calls by pressing and holding it. Depending on your phone, this feature may not be supported.

APPENDIX

§ Frequently asked questions

How far away from my phone will the headset work?	The operating range is typically up to 30 feet (10 meters).		
Will the headset work with my cordless phone at home?	The headset is not designed for use with cordless phones.		
Will the headset work with laptops, PCs, and PDAs?	The headset will work with devices that are compliant with Bluetooth version 1.1 or higher and support the Headset and/or Hands-Free Profile(s).		
Will anything cause interference with my conversation when I'm using the headset?	Appliances such as cordless phones and wireless networking equipment may cause interference with your conversation. To reduce any interference, keep the headset away from other devices that use or produce radio waves.		

Will the headset interfere with my car's electronics, radio, or computer?	The headset produces significantly less power than a typical mobile phone. It also only emits signals that are in compiliance with the international Bluetooth standard. Therefore, you should not expect any interference with standard consumer-grade electronics equipment.
Can other Bluetooth phone users hear my conversation?	When you pair the headset to your Bluetooth phone, you are creating a private link between only these two Bluetooth devices. The wireless Bluetooth technology used in the headset is not easily monitored by third parties, because Bluetooth wireless signals are significantly lower in radio frequency power than those produced by a typical mobile phone.
How do I take care of the headset?	Wipe it with a soft cloth.
Does the headset fully charge?	The headset and the travel adapter may not have been connected properly. Separate the headset from the travel adapter and then reconnect and charge the headset.



Certification and Safety approvals

Bluetooth

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Samsung is under license. Other trademarks and trade names are those of their respective owners.

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Users are not permitted to make changes or modify the device in any way.

Changes or modifications not expressly approved by Samsung will void the user's authority to operate the equipment.

Industry Canada

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC:" before the certification/registration number only signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

UL certified travel adapter

The travel adapter for this headset has met UL 1310 safety requirements.

Please adhere to the following safety instructions per UL quide-lines.

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTATED IN A VERTICAL OR HORIZONTAL OR FLOOR MOUNT POSITION.

Warranty and parts replacement

Samsung warrants this product as free of defects in material, design and workmanship for the period of one year from the original date of purchase*.

If during the period of warranty this product proves defective under normal use and service you should return the product to the retailer from whom it was originally purchased or qualified service center. The liability of Samsung and its appointed maintenance company is limited to the cost of repair and/or replacement of the unit under warranty.

- The warranty is limited to the original purchaser
- A copy of your receipt or other proof of purchase is required for a proper warranty service
- The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation modification, or repair by unauthorized third parties
- The responsibility of Samsung products shall be limited to the repair or replacement of the product at its sole discretion

^{*} Depending on your country, the length of warranty may vary.

- Specifically exempt from any warranty are limited-life consumable components such as batteries and other accessories
- Samsung is not liable to for any incidental or consequential damages arising from the use or misuse of any Samsung product
- This warranty gives you specific rights and you may have other rights which vary from area to area
- Unless otherwise instructed in the User Guide, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on the unit, whether in or out of warranty. It must be returned to the purchase point, factory or authorised service agency for all such work
- Samsung will not assume any responsibility for any loss or damage incurred in shipping. All repair work on Samsung products by unauthorised third parties voids any warranty



Correct disposal of this product



(Waste Electrical & Electronic Equipment)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.