



**MOBILE ENHANCEMENT**

World Wide Web  
<http://www.samsungmobile.com>

Printed in Korea  
Code No.:GH68-xxxxxA  
EU A. xx/2009. Rev. 1.0



## **Safety approvals**

### **FCC**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Users are not permitted to make changes or modify the device in any way.

Changes or modifications not expressly approved by Samsung will void the user's authority to operate the equipment.

### **Industry Canada**

IC ID: 649E-WEP470

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must

accept any interference, including interference that may cause undesired operation of the device.

The term "IC:" before the certification/registration number only signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.



**SAMSUNG**

English / Français / Deutsch / Nederlands



HEADSET

WEP470

MOBILE ENHANCEMENT

<b>English</b> .....	<b>1</b>
<b>Français</b> .....	<b>18</b>
<b>Deutsch</b> .....	<b>37</b>
<b>Nederlands</b> .....	<b>56</b>

# Contents

## ***Getting started***

Your headset overview .....	3
Button functions.....	4
Charging the headset.....	4
Wearing on the headset.....	6

## ***Using your headset***

Turning the headset on or off .....	7
Pairing and connecting the headset.....	8
Using call functions.....	9

## ***Appendix***

Frequently asked questions.....	12
Warranty and parts replacement.....	14
Correct disposal of this product .....	15
Correct disposal of batteries in this product.....	16
Specifications.....	17

Take the time to read through this user's guide before you start to use WEP470 Bluetooth Headset.

Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide—Bluetooth QD ID: B0xxxxx

More information about Bluetooth is available at [www.bluetooth.com](http://www.bluetooth.com).



### Safety precautions



- Never disassemble or modify your headset for any reason. Doing this may cause the headset to malfunction or become combustible. Bring the headset to an authorised service centre to repair it or replace the battery.
- When using your headset while driving, follow local regulations in the country or region you are in.
- Avoid storage at high temperatures (above 50° C/122° F), such as in a hot vehicle or in direct sunlight, as this can damage performance and reduce battery life.
- Do not expose the headset or any of its supplied parts to rain or other liquids.




At very high volumes, prolonged listening to the headset can damage your hearing.

## Getting started

This section explains what to remember for the proper use of your Bluetooth headset.

### Your headset overview



Make sure you have the following items with your headset :  
Charger, User guide.

The items supplied with your headset may vary depending on your region.



## Button functions

### **Talk button**

- Press and hold to turn the headset on or off.
- Press to make or answer a call.
- Press to end a call.
- Press and hold to enter Pairing mode

### **+/- Volume up/down buttons**

- Press to adjust the volume.

### **Power switch**

- Slide the switch to turn the headset on or off.

## Charging the headset

This headset has a rechargeable internal battery which is non-removable. Ensure that you fully charge the battery before using the headset for the first time.

- 1** Plug the charger into the charger jack on the headset.

- 2** Plug the charger into a power outlet. During charging, the indicator light will turn red.  
If charging does not begin, unplug the charger and plug it in again.



- 3** When the headset is fully charged, the indicator light changes to blue. Unplug the charger from the power outlet and the headset.



- Use only a Samsung-approved charger. Unauthorised chargers may cause an explosion or damage to the headset.
- The battery will gradually wear out while charging or discharging because it is a consumable part.
- The headset is not able to operate while charging. Try connecting after charging is completed.

## When the battery power is low

The headset beeps and the indicator light flashes red. Recharge the battery. If the headset powers off during a call, the call will be automatically transferred to the phone.

## Wearing on the headset

Place the headset on your ear.

Depending on what ear you are going to wear the headset, simply adjust the ear hook accordingly.



▲ Left



▲ Right

## Using your headset

This section explains how to turn the headset on, pair and connect with the phone, and use various functions.



- Activated functions and features may differ depending on the types of your phone.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your headset.

### Turning the headset on or off

- To turn the headset on, press and hold the talk button until the blue indicator light flashes 4 times.
- To turn the headset off, press and hold the talk button until both blue and red indicator lights flash.

## Pairing and connecting the headset

Pairing will create a unique and encrypted wireless link between two Bluetooth enabled devices, such as a Bluetooth phone and a Bluetooth headset. To use the headset with other Bluetooth devices, both devices must be paired. When trying to pair the two devices, keep the headset and the phone reasonably close together. After pairing, you can connect the two devices.

### Pairing and connecting the headset with a phone

- 1 Enter Pairing mode.
  - Turn on the headset with pressing and holding the talk button until the indicator light turns blue and stays lit after blinking.
  - When you turn on the headset for the first time, it automatically enters Pairing mode.
- 2 Activate the Bluetooth feature on your phone and search for the headset (see your phone's user guide).
- 3 Select the headset (Samsung WEP470) from the list of devices found by your phone.
- 4 Enter the Bluetooth PIN (0000, 4 zeros) to pair and connect the headset to your phone.

## Disconnecting the headset

To disconnect the headset from your phone,

- Turn off the headset
- Use the Bluetooth menu of your phone

## Reconnecting the headset

When the headset is paired with a phone, it will attempt to automatically reconnect each time you turn it on.

If the headset does not attempt to automatically reconnect,

- Press the talk button.
- Use the Bluetooth menu of your phone

## Using call functions

### Making a call

#### Redialling the last number

Press the talk button to redial the last number.

For some phones, pressing the key opens the call log list. Press the talk button to dial the selected number.

### **Dialling a number by voice**

Press and hold the talk button to dial a number by voice, and say a name.

### **Answering a call**

Press the talk button to answer a call when you hear incoming call tones.

### **Ending a call**

Press the talk button to end a call.

### **Rejecting a call**

Press and hold the talk button to reject a call when a call comes in.

### **Using options during a call**

You can use the following functions to control your call during a call.

#### **Muting the microphone**

Press and hold the volume up/down buttons to turn the microphone off so that the person with whom you are speaking cannot hear you. Press and hold the volume up/down buttons again to turn the microphone back on.

**Transferring a call from the phone to the headset**

Press the talk button to transfer a call from the phone to the headset.

**Placing a call on hold**

Press and hold the talk button to place the current call on hold.

**Answering a second call**

Press the talk button to end the first call and answer a second call when you hear call waiting tones.

Press and hold the talk button to place the first call on hold and answer a second call when you hear waiting tones.

To switch between the current call and the held call, press and hold the talk button.



## Appendix

### Frequently asked questions

<b>Will my headset work with laptops, PCs, and PDAs?</b>	Your headset will work with devices that support your headset's Bluetooth version and profiles. For specifications, see page 17.
<b>Will anything cause interference with my conversation when I am using my headset?</b>	Appliances such as cordless phones and wireless networking equipment may cause interference with your conversation, usually adding a crackling noise. To reduce any interference, keep the headset away from other devices that use or produce radio waves.
<b>Will my headset interfere with my car's electronics, radio, or computer?</b>	Your headset produces significantly less power than a typical mobile phone. It also only emits signals that are in compliance with the international Bluetooth standard. Therefore, you should not expect any interference with standard consumer-grade electronics equipment.

<b>Can other Bluetooth phone users hear my conversation?</b>	When you pair your headset to your Bluetooth phone, you are creating a private link between only these two Bluetooth devices. The wireless Bluetooth technology used in your headset is not easily monitored by third parties because Bluetooth wireless signals are significantly lower in radio frequency power than those produced by a typical mobile phone.
<b>The sound is echoing while talking.</b>	Adjust the speaker volume, or move to another area and try again.
<b>How do I take care of my headset?</b>	Wipe it with a soft dry cloth.
<b>The headset does not fully charge.</b>	The headset and the charger may not have been connected properly. Separate the headset from the charger, reconnect, and charge the headset.

## Warranty and parts replacement

Samsung warrants this product as free of defects in material, design and workmanship for the period of one year from the original date of purchase.(Depending on your country, the length of warranty may vary.)

If during the period of warranty this product proves defective under normal use and service you should return the product to the retailer from whom it was originally purchased or qualified service centre. The liability of Samsung and its appointed maintenance company is limited to the cost of repair and/or replacement of the unit under warranty.

- The warranty is limited to the original purchaser
- A copy of your receipt or other proof of purchase is required for a proper warranty service
- The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation, modification, or repair by unauthorised third parties
- Specifically exempt from any warranty are limited-life consumable components such as batteries and other accessories
- Samsung will not assume any responsibility for any loss or damage incurred in shipping. All repair work on Samsung products by unauthorised third parties voids any warranty

## Correct disposal of this product



(Waste Electrical & Electronic Equipment)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

## Correct disposal of batteries in this product



(Applicable in the European Union and other European countries with separate battery return systems.)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.

---

The rechargeable battery incorporated in this product is not user replaceable. For information on its replacement, please contact your service provider.

---

## Specifications

Item	Specifications and description
Bluetooth version	2.1+EDR
Support Profile	Headset Profile, Hands-Free Profile
Operating range	Up to 30 feet (10 metres)
Standby time	Up to xxx hours*
Talk time	Up to x hours*
Charging time	Approximately x hours*

\* Depending on the phone type and usage, the actual time may vary.



## Declaration of Conformity (R&TTE)

We,

**Samsung Electronics**

declare under our sole responsibility that the product

### **Bluetooth Headset : WEP470**

to which this declaration relates, is in conformity with the following standards and/or other normative documents.

SAFETY	EN
EMC	EN
	EN
	EN
	EN
RADIO	EN

We hereby declare that [all essential radio test suites have been carried out and that] the above named product is in conformity to all the essential requirements of Directive 1999/5/EC.

which will be made available upon request.

*(Representative in the EU)*

Samsung Electronics Euro QA Lab.  
Blackbushe Business Park, Saxony Way,  
Yateley, Hampshire, GU46 6GG, UK\*

2009.XX.XX



Yong-Sang Park / S. Manager

(place and date of issue)

(name and signature of authorised person)

\* It is not the address of Samsung Service Centre. For the address or the phone number of Samsung Service Centre, see the warranty card or contact the retailer where you purchased your product.