



Toys R Us

Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

6+

FAST LANE is a mark of Geoffrey, Inc., a subsidiary of Toys "R" Us, Inc. © Copyright 2000 Geoffrey, Inc. Made in China. Distributed in the United States by Toys "R" Us, Inc. Wayne, NJ 07470. Distributed in Australia by Toys "R" Us (Australia) Pty Ltd., Regent Park NSW 2143. www.toysrus.com

ITEM #99283 O.L. NO. 3990

OPERATING INSTRUCTIONS:
BATTERY INSTALLATION

TRANSMITTER:

- Slide to open the battery cover at the back of the transmitter and put a 9-volt battery inside following the engraved signs. (See Diagram 1)
- Replace the battery cover.




DIAGRAM 1

BATTERY LOADING:
(FOR MAXIMUM PERFORMANCE, USE ALKALINE BATTERIES)

Remember to take out all batteries from the vehicle and transmitter after playing.

- Do not mix old and new batteries.
- Do not mix alkaline, standard (Carbon-Zinc), or rechargeable (Nickel-Cadmium) batteries.

CAR:

- Push the ON/OFF to "OFF" position. (see diagram 2)
- Locate the battery compartment. (see diagram 2)
- Insert 4 "AA" batteries into the battery compartment follow the "ARROW" sign. Make sure (+) (-) polarity is correct. (see diagram 2)




DIAGRAM 2

SETTING UP YOUR VEHICLE

- Build up the antenna by inserting the cable into the antenna tube (included) completely and plug the tube into the vehicle securely. (see diagram 3)




DIAGRAM 3

OPERATION

- Push the vehicle ON/OFF switch to the "ON" position (see diagram 5).
- Operate the vehicle with the transmitter. (see diagram 7)
- Turn OFF the vehicle and the transmitter after playing and remove all batteries from the transmitter and the car.
- To adjust steering alignment, adjust the "Steering Alignment Lever" on the underside of the vehicle when the vehicle does not run straight forward. (see diagram 6)




DIAGRAM 5



DIAGRAM 6




DIAGRAM 7

PERFORMANCE TIPS:

- Operate your vehicle in a safe place. Do not drive in streets. Avoid driving through sand, mud, and water, which can impair the performance of your car.
- Do not leave your transmitter or car near sources of heat or under direct sunlight for long periods of time.
- Do not expose your transmitter or car to humidity for long periods of time as dampness can damage interior mechanism.
- Clean the toy vehicle regularly with a slightly damp cloth.
- When the vehicle slows down or begins to move erratically, replace with fresh batteries.
- Concrete walls, metal posts, wire fence, and other electrical appliances and machines can interfere with the transmission signal of your transmitter and result in erratic performance of your car. In this case, change to a different location.
- If another radio control car or CB radio is operating at your same location, they will interfere with the performance of your car.

BATTERY CAUTIONS

- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before recharging.
- Rechargeable batteries are to be recharged under adult supervision.
- Different types of batteries, new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.

- The supply terminals are not to be short-circuited.
- This toy is not intended for children under 3 years old.

FCC NOTE:
THE ANTENNA PROVIDED IS A UNIQUE ANTENNA. BY INSTALLATION OF UNAUTHORIZED ANTENNA TO THIS EQUIPMENT, SUCH UNAUTHORIZED INSTALLATION COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ATTENTION PARENTS:
IT IS RECOMMENDED THAT THIS TOY AND ALL ACCESSORIES BE PERIODICALLY EXAMINED FOR POTENTIAL HAZARDS AND THAT ANY POTENTIALLY HAZARDOUS PARTS BE REPAIRED OR REPLACED.

24014 65-3990-1S0-0100 520mm x 120.5mm



Toys R Us

No mezcles pilas nuevas y usadas. No mezcles pilas alcalinas, estándar (carbono-zinc) o recargables (níquel cadmio).

6+

FAST LANE es una marca de Geoffrey, Inc., a subsidiary of Toys "R" Us, Inc. © Copyright 2000 Geoffrey, Inc. Made in China. Distributed in the United States by Toys "R" Us, Inc. Wayne, NJ 07470. Distributed in Australia by Toys "R" Us (Australia) Pty Ltd., Regent Park NSW 2143. www.toysrus.com

Artículo: 99283 O.L. NO. 3990

COLOCACION DE LAS PILAS

TRANSMISOR:

- Abra la tapa del compartimento para baterías que se encuentra en la parte trasera del transmisor y coloque una batería de 9 V respetando la polaridad que designan las marcas (ver diagrama 1).
- Vuelva a colocar la tapa en su sitio.




DIAGRAMA 1

INSTALACION DE LAS BATERIAS
(PARA UN RENDIMIENTO OPTIMO, UTILICE BATERIAS ALCALINAS)

No olvide retirar todas las baterías del vehículo y del transmisor después de jugar.

- No mezcle baterías nuevas y usadas.
- No mezcle baterías alcalinas y estándar (carbono-zinc) o recargables (níquel-cadmio).

VEHICULO:

- Colocar el interruptor ON/OFF en posición "OFF". (ver diagrama 2)
- Localizar el compartimento de las pilas. (Ver el Diagrama 2)
- Coloque 4 pilas tipo R6 "AA" en el compartimento de las pilas siguiendo el símbolo de la "FLECHA". Asegure que las polaridades (+) (-) están correctamente. (ver diagrama 2)




DIAGRAMA 2

MONTAJE DE SU VEHICULO

- Coloque la antena pasando el cable a través del tubo incluido y conectelo en el coche firmemente. Sino el vehículo no funcionará. (ver diagrama 3)




DIAGRAMA 3

FUNCIONAMIENTO

- Coloque el interruptor ON/OFF del vehículo en la posición "ON" (ver diagrama 5).
- Dirija el vehículo con el mando de control. (ver diagrama 7)
- Apague el interruptor del vehículo después de jugar y retire todas las pilas del mando de control y del coche.
- Para ajustar la alineación de la dirección, ajuste con la palanca situada bajo el vehículo cuando éste no circula en dirección recta. (ver diagrama 6).




DIAGRAMA 5



DIAGRAMA 6




DIAGRAMA 7

CONSEJOS DE FUNCIONAMIENTO

- Circule con su vehículo en lugares seguros. No conduzca por calles. Evite circular por arena, barro y agua, ya que reducirían el funcionamiento del coche.
- No deje el mando de control o el coche cerca de fuentes directas de calor o bajo los rayos directos del sol durante largos periodos de tiempo.
- No exponer su mando de control o coche a la humedad ya que ésta podría dañar el mecanismo interior del vehículo.
- Limpie el vehículo regularmente con un paño ligeramente humedecido.
- Cuando el vehículo se mueva lentamente o sin control, cambiar las pilas por otras nuevas.
- Algunos muros, postes metálicos, rejas metálicas y otro aparatos eléctricos y maquinarias pueden interferir en la señal de radio control y conlleva un descontrol. En este caso cambie a otro lugar más apartado.
- Si otro coche de radio control o CD está funcionando cerca, pueden haber interferencias en el funcionamiento de su coche.

PILAS PRECAUCIONES

- Las pilas no-recargables no deben ser recargadas.
- Las pilas recargables deben ser retiradas del juguete antes de ser recargadas.
- Las pilas recargables solo pueden recargarse bajo la supervisión de un adulto.
- Los distintos tipos de pilas o pilas nuevas con usadas no deben ser mezcladas.
- Solo pilas del mismo tipo o equivalente son recomendadas.
- Las pilas deben ser colocadas correctamente según las polaridades.
- Las pilas gastadas deben ser retiradas del juguete.

- Los terminales de las pilas no deben ser cortocircuitados.
- Este juguete no es adecuado para niños menores de 3 años.

NOTA DE FCC:
LA ANTENA QUE SE SUMINISTRA ES EXCLUSIVA. EN CASO DE INSTALAR UNA ANTENA NO AUTORIZADA EN ESTE EQUIPO, PODRÍA QUEDAR ANULADA LA AUTORIDAD DEL USUARIO PARA OPERAR EL MISMO.

EL FABRICANTE NO SE HACE RESPONSABLE DE LAS INTERFERENCIAS DE RADIO O TELEVISION PROVOCADAS POR LAS MODIFICACIONES NO AUTORIZADAS A LAS QUE SE HAYA SOMETIDO ESTE EQUIPO. DICHAS MODIFICACIONES PUEDEN ANULAR LA AUTORIDAD DEL USUARIO PARA OPERAR EL EQUIPO.

ATENCIÓN A LOS PADRES:
SE RECOMIENDA EXAMINAR ESTE JUGUETE Y TODOS LOS ACCESORIOS REGULARMENTE CON EL FIN DE EVITAR POSIBLES PELIGROS. TAMBIÉN, SE RECOMIENDA SUSTITUIR O REPARAR LAS PIEZAS QUE PUEDAN ENTRAÑAR ALGÚN TIPO DE PELIGRO.