

## INSTRUCTION MANUAL

### ATTENTION PARENTS

It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous part be repaired or replaced.

### BATTERY INSTALLATION

#### HOW TO INSTALL BATTERY IN VEHICLE

1. Make sure the "ON/OFF" switch at the underside of the vehicle is at the "OFF" position. (See Diagram #1)
2. UNSCREW to open the battery compartment. (See Diagram #1)
3. Insert 3 "AAA" batteries by matching the (+) and (-) signs as shown in the diagram. (See Diagram #2)
4. Replace the battery cover and tighten the screw to secure the battery cover.

ON/OFF switch




DIAGRAM #1




DIAGRAM #2

#### HOW TO INSTALL BATTERY IN TRANSMITTER

1. Remove battery cover and install 2 "AA" batteries by matching the (+) and (-) signs as shown in the diagram. (See Diagram #3)
2. Replace the battery cover.
- Note: Remove all batteries after you have finished using your vehicle.




DIAGRAM #3

### HOW TO PLAY

1. Turn the vehicle on by pushing the cable through the antenna. The antenna will vibrate and the vehicle will start to move. When the vehicle will not work, (See Diagram #4)
2. Push the ON/OFF switch to the "ON" position of the vehicle. (See Diagram #5)





DIAGRAM #4



3. Operate the vehicle with the transmitter. Functions include: Forward, Reverse, Right, Stop. (See diagram 6)
4. Turn OFF the vehicle after playing and remove all batteries from the transmitter and the car.




DIAGRAM #6

### FRONT WHEELS STEERING ADJUSTMENT

5. If the vehicle does not run straight forward, adjust the lever for satisfactory alignment on the underside of the vehicle. (See Diagram #7)
6. If the vehicle runs towards left, turn "Steering Alignment Lever" towards "R".
7. If the vehicle runs towards right, turn "Steering Alignment Lever" towards "L".



DIAGRAM #7

### BATTERY CAUTIONS

1. For maximum performance, use alkaline batteries.
2. Do not mix old and new batteries.
3. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
4. Do not recharge non-rechargeable battery.
5. Ensure batteries are inserted with the correct polarity.
6. Remove batteries when toy is not in use.
7. Dispose of used batteries in accordance with the maker's recommendation.
8. Rechargeable batteries should only be charged under adult supervision.
9. Rechargeable batteries from toy before charging.
10. The supply terminals are not to be short-circuited.
11. The antenna wires are not to be inserted into socket outlet.

**NOT SUITABLE FOR CHILDREN UNDER 3 YEARS OF AGE, DUE TO SMALL PARTS.**

**PLEASE NOTE:**  
THE ANTENNA PROVIDED IS A UNIQUE ANTENNA. BY INSTALLATION OF UNAUTHORIZED ANTENNA TO THIS EQUIPMENT, SUCH UNAUTHORIZED INSTALLATION COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

**THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY THIS EQUIPMENT. SUCH INTERFERENCE, IF ANY, SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.**

### ATTENTION PARENTS:

IT IS RECOMMENDED THAT THIS TOY AND ALL ACCESSORIES BE PERIODICALLY EXAMINED FOR POTENTIAL HAZARDS AND THAT ANY POTENTIALLY HAZARDOUS PARTS BE REPAIRED OR REPLACED.

### ATENCIÓN PARA LOS PADRES

Se recomienda que este juguete y sus accesorios sean examinados periódicamente para evitar problemas o daños en piezas para que puedan ser reparados o reemplazados.

### COLOCACIÓN DE LAS PILAS

#### COMO COLOCAR LAS PILAS EN EL VEHICULO

1. Asegure que el interruptor "ON/OFF" está en la posición "OFF". (Ver Diagrama #1)
2. Desatornille y quite la tapa del compartimiento de las pilas. (Ver Diagrama #1)
3. Inserte 3 pilas tipo "AAA" en el compartimiento de las pilas. (Ver Diagrama #2)
4. Reemplace la tapa del compartimiento de pilas y apriete el tornillo firmemente para cerrar.

Interruptor "ON/OFF"




DIAGRAM #1




DIAGRAM #2

#### COMO COLOCAR LAS PILAS EN EL MANDO DE CONTROL

1. Quite la tapa del compartimiento de las pilas y coloque 2 pilas tipo "AA" dentro siguiendo el símbolo gráfico. (Ver Diagrama #3)
2. Coloque la tapa del compartimiento de las pilas.
- Note: Retire las pilas después de usar el vehículo.




DIAGRAM #3


### COMO JUGAR

#### COMIENZO DEL JUEGO

1. Coloque la antena pasando el cable al tubo incluido y conéctelo en el coche firmemente. (Ver Diagrama #4)
2. Empuje el interruptor ON/OFF del vehículo en la posición "ON". (Ver Diagrama #5)



DIAGRAM #4



2. Dirija el vehículo con el mando de control. (Ver Diagrama #6)
3. Apague el interruptor del vehículo después de jugar y retire todas las pilas del mando de control y del coche.




DIAGRAM #6

5. Si el vehículo no corre en dirección recta hacia delante, ajuste la palanca para un alineamiento satisfactorio en la parte inferior del vehículo. (Ver Diagrama #7)
6. Si el vehículo corre a la izquierda, gire la "palanca de alineamiento de dirección" hacia la posición "R".
7. Si el vehículo corre a la derecha, gire la "palanca de alineamiento de dirección" hacia la posición "L".



DIAGRAM #7

### PILAS PRECAUCIONES

1. Para un funcionamiento óptimo, use pilas alcalinas.
2. No deben mezclarse diferentes tipos de pilas, ni pilas nuevas con pilas usadas.
3. No mezclar pilas alcalinas con pilas estándar (carbón-zinc) o recargables.
4. No se deben recargar pilas no recargables.
5. Retire las pilas usadas del vehículo cuando no se use durante un periodo prolongado.
6. Extraiga las pilas del juguete cuando no se use durante un periodo prolongado.
7. Se deben quitar las pilas expuestas del juguete y tiradas en un contenedor apropiado.
8. Las pilas recargables solamente se cargan solamente por un modelo.
9. Se deben quitar las pilas del juguete antes de cargarlas.
10. Los terminales de suministro no deben ser cortocircuitados.
11. Los cables de antena no deben instalarse en la salida del enchufe.

**NO RECOMENDADO PARA NIÑOS MENORES DE 3 AÑOS. CONTIENE PIEZAS PEQUEÑAS QUE PUEDEN SER INGERIDAS.**



ESPAÑOL

IMPRESO EN CHINA  
O.I. NO.4519



ENGLISH

PRINTED IN CHINA  
O.I. NO.4519

SIZE: 210 X 297MM PN#65-4519-000-0100