

BATTERY INSTALLATION

(For maximum performance, use alkaline batteries)

Remember to take out all batteries from vehicle and transmitter after playing.

1. Do not mix old and new batteries.

2. Do not mix alkaline, standard (Carbon-Zinc), or rechargeable batteries.

ATTENTION PARENTS

It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

HOW TO INSTALL BATTERY IN VEHICLE

1. Turn over the vehicle and push the ON/OFF to "OFF" position. (See Diagram #1)
2. Open the battery cover. (See Diagram #1)
3. Follow the "arrow" sign and insert the battery pack into the battery compartment. Make sure the (+) (-) polarity is correct. (See Diagram #2)
4. Replace the battery cover.

How to install batteries in Transmitter

1. Slide open the battery cover at the back of the transmitter and insert 2 x AA battery into the battery compartment according to polarity (+) and (-). (See Diagram #3)
2. Replace the battery cover.

Note: Remove battery after you have finished using your vehicle




DIAGRAM 1



DIAGRAM 2




DIAGRAM 3




DIAGRAM 4




DIAGRAM 5

EZTEC®
www.ez-tec.com

EZ-TEC® IS A REGISTERED TRADEMARK OWNED BY SCIENTIFIC TOYS, LTD.
© 2009 SCIENTIFIC TOYS LTD. 1108, TOWER B,
14 SCIENCE MUSEUM ROAD, TSIMSHATSUI, HONG KONG.
PRINTED IN CHINA
O.I. NO.4598

CE 0681

SIZE: 210 X 148.5MM PN#65-4598-000-0100

How to Play

1. Build up antenna by passing the cable through the antenna tube provided and plug into the vehicle tightly. Otherwise, the vehicle will not work. (See Diagram #4)
2. Slide the Power switch to ON position to turn on the transmitter and vehicle. (See Diagram #5)
3. After playing, slide the Power switch to OFF position to turn off the transmitter

Driving Forward

Press the FORWARD trigger at the back of transmitter for forward running. (See Diagram #6)

Driving in Reverse

Press the REVERSE trigger at the back of transmitter for reverse running. (See Diagram #7)

Steering Operation

To make left or right hand turns while driving forward, swing the transmitter to left or right while pressing the FORWARD trigger at the same time. (See Diagram #8)

To make left or right hand turns while driving reverse, swing the transmitter to left or right while pressing the REVERSE trigger at the same time. (See Diagram #9)

Front wheels steering adjustment

5. If the vehicle does not run straight forward, adjust the lever for satisfactory alignment on the underside of the vehicle. (See Diagram #10)
6. If the vehicle runs towards left, turn "Steering Alignment Lever" towards "R".
7. If the vehicle runs towards right, turn "Steering Alignment Lever" towards "L".

Stop Operation

To stop, release both FORWARD & REVERSE triggers.




DIAGRAM 6




DIAGRAM 7

BATTERY CAUTIONS

1. For maximum performance, use alkaline batteries.
2. Do not mix old and new batteries.
3. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries
4. Do not recharge non-rechargeable battery.
5. Ensure batteries are inserted with the correct polarity.
6. Remove batteries when toy is not in use.
7. Remove exhausted batteries from toy and dispose of in accordance with the makers recommendation
8. Rechargeable batteries should only be charged under adult supervision.
9. Remove rechargeable batteries from toy before charging.
10. The supply terminals are not to be short-circuited.
11. The antenna wires are not to be inserted into socket outlet.

NOT SUITABLE FOR CHILDREN UNDER 3 YEARS OF AGE, DUE TO SMALL PARTS.




DIAGRAM 8




DIAGRAM 9




DIAGRAM 10