

ITEM #:  
 PRODUCT DESCRIPTION: ROVE SOUND BOTTLE INSTRUCTIONS & FEATURES


CMYK %:  
 PANTONE:  
 COATING:  
 PAPER TYPE: COLOR BOX  
 BOX DIMS: 8.5”(L) X 5.5”(W)  
 DESIGNER NAME: LOUIS LI  
 RELEASE DATE:  
 BLACK OVER PRINT, PHOTO ARE FINAL ART  
 THIS FILE HAS NOT BEEN TRAPPED  
 CREATED BY TABLETOPS UNLIMITED  
 ©TABLETOPS UNLIMITED 2018  
 DIE LINES DO NOT PRINT

# FRONT

**CAUTION**

1. Charge the speaker completely before initial use.
2. Bottle and lid are dishwasher safe. To clean the speaker, wipe with a damp cloth.
3. Keep wireless speaker away from chemicals, strong magnetic or electrical fields, and heating devices.
4. Avoid dropping wireless speaker or forceful impact with hard objects. Do not attempt to play music submerged underwater. If speaker is fully submerged in water, shake remaining water out after retrieving it.
5. DO NOT attempt to disassemble wireless speaker.
6. Cover the USB port properly to protect the speaker from irreparable internal water damage.
7. Recycle battery according to local regulations.

**EACH BUTTON HAS MULTIPLE FUNCTIONS:**



**POWER**

1. Press and hold **⏻** to turn the wireless speaker **ON**. It will make an ON sound when activated.
2. To turn the wireless speaker **OFF**, press and hold the same button until it makes an OFF sound.

**PAIR WITH SMARTPHONE OR TABLET**

1. Turn on your smartphone or tablet, select your Bluetooth® options, then select **SOUND BOTTLE**. Speaker will make a sound when paired.

**PLAY MUSIC**

1. Select your desired smartphone or tablet music app. Press **▶** once to **PLAY** music from your smartphone or tablet on the wireless speaker. To **STOP**, press **||** once.
2. To play the **NEXT TRACK** on your playlist, press and hold **VOL +** button.
3. To play the **PREVIOUS TRACK**, press and hold **VOL -** button.


**VOLUME CONTROL**

1. To **INCREASE VOLUME**, press **VOL +** button. The speaker will make a sound when maximum volume is reached.
2. To **DECREASE VOLUME**, press **VOL -** button.

**PHONE CALLS**

1. To **ANSWER** a phone call while listening to music, press **▶ || / ⏻** button.
2. To **DECLINE** a phone call, press and hold **▶ || / ⏻** button.
3. To **END A PHONE CALL**, press **▶ || / ⏻** button.

# BACK



Bluetooth Version	JL 4.2	Charging Power	DC 5V/1A
Working Volume	3.4-4.2V	Material	TRITAN®
Battery Life	2-4 Hours	Support for hands-Free Mode	Yes
Charging Time	1-2 Hours	Answer / End Calls	Yes
Waterproof	Yes	Support for FM	No
Microphone	Yes	Name	Sound Bottle
Low Power Warning	Blinking Lights	Capacity	24oz. / .72L
Distance	11Yards	Main Material	Polypropylene
Charging Method	Micro USB	High	590mm
Rated Power	3W	Diameter	740mm

8.5"X5.5"

## **FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

## **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.