

Turning Power On and Off

Turning Power On

Hold down for at least one second.

Turning Power Off

On the stand-by screen: Hold down for at least one second.

Checking Your Own Phone Number and E-mail Address

On the stand-by screen: Press . ▶ Press .

Making and Answering a Call

Making a Call

On the stand-by screen: Enter the phone number you want to call. ▶ Press .

- To adjust the earpiece volume: Use .
- To end a call: Press .

Answering a Call

When the phone starts ringing, press .

- To adjust the earpiece volume: Use .
- To end a call: Press .

Storing and Recalling a Memory Dial Data

▼ Storing Data

On the stand-by screen: Hold down for at least one second. ▶ Use to select the Memory Dial record you want to edit and press . ▶ Enter the data.
▶ Press when finished.

▼ Recalling Data

On the stand-by screen: Press . ▶ Use to select the Memory Dial record you want to recall. ▶ Press .

Using the Camera

▼ Taking a Snapshot

On the stand-by screen: Press for at least one second. ▶ Use to select フォト(壁紙モード) and press . ▶ Press or to take a snapshot. ▶ Press or to store the photo.

- To switch from Photo mode to Movie mode: Press .


▼ Recording a Movie

On the stand-by screen: Press for at least one second. ▶ Use to select ムービー and press . ▶ Press or to start recording. ▶ Press or to stop recording. ▶ Press or to store the movie.

- To pause recording: Press .
- To switch from Movie mode to Photo mode: Press .

Making an International Call

Ex. To Call 212-123-△△△△ in the USA



English Voice Mail Answering Messages

You can configure Voice Mail to play operation instructions and answering messages in English.

On the stand-by screen: Press . ▶ Press . ▶ Press . ▶ Press . ▶ Press .

Other Features

▼ Silent Mode

On the stand-by screen: Hold down for at least one second.

- To disable Silent Mode: After the above operation, hold down for at least one second.

▼ Easy Voice Recording

On the stand-by screen: Hold down for at least one second.

- To disable Easy Voice Recording: After the above operation, hold down for at least one second.

For inquiries please contact

au Customer Service Center (General Information)

- If you are calling from a landline phone: 0077-7-111 (toll free)
- If you are calling from an au mobile phone: 157 (toll free)