

# Shark®

## PRO Spray Mop



Quick Start Guide



### 1. Ergonomic Handle

- Rubber Grip
- One touch Spray

### 2. Shark Gentle Cleanser

- Safe for kids and pets
- No stick residue & great fresh scent

### 3. Illuminated Spray

- LED light shows solution
- Brightens hard to see areas

### 4. Extra Long Scrubbing Surface

- Multi-purpose cleaning
- Eliminate tough messes

### 5. Ultra Maneuverable Head

- 180° spray
- Gets in hard to reach areas

# Getting Started:

## READY

### 1) Assemble Unit

- Line up the 2 sections of the pole and snap permanently into place.



### 2) Add Batteries

- Open battery door and carefully insert 4 non-rechargeable AA batteries.
- Close the battery door securely until you here a “click”.



## SET

### 3) Attach Pad

- Attached your Shark Washable Microfiber Cleaning pad to the bottom of the mop head.
- If you are using a Shark 1 time use pad, make sure you attach the pad with the printing side facing the bottom of the mop head.



### 4) Add Cleaning Solution

- Remove your refillable bottle.
- Add water to the line where it indicates “Water” on your refillable bottle.
- Add the Shark Gentle Cleanser Concentrate the remaining of the way and fill to where it indicates “Cleanser”.
- If using Shark Professional Hardwood Cleanser, there is no need to add any water – this cleaning solution comes ready to use.



Solution

Gentle Cleaner Concentrate

Water

water fill line

## GO

### 5) Being Cleaning

- Use your Shark Pro Spray mop throughout your house and on all floor types.
- For tough spots – simply flip the mop head and use



### 6) Discard Pad

- Simply toss your reusable pad in the wash or throw your 1 time use pad in the trash.

