

Romantic lighting Bluetooth speaker



User Manual

Thank you for choosing us. Please read this user manual before using the speaker.

Packing list



The speaker



user manual



USB data cable

Specifications:

Charging Input:DC5V-- 1000mAh

Battery Capacity:Polymer Lithium Battery, 3.7V/4000mAh

Charging Time:4-5 Hours

Speaker Specifications: ϕ 66*35mm (Power: 4 Ω 5W)

Frequency Range:70Hz-20KHz

Distortion: \leq 0.5%

Whole Signal to Noise Ratio: \geq 65dB

Main Material:ABS/Silicone



Size: ϕ 88*141mm

Weight:About 345G









Playing time:22 hours (playing Bluetooth music only)

Lighting time:8 hours on high brightness. 150 hours on low brightness.

Button Functions:



Button Icon

	Power switch (long press for 3s)		clock set
	Bluetooth switch Mode switch Play/Pause Answer/Hang up		Alarm set
	Volume Up Next clock time setting alarm setting		Alarm switch
	Volume down previous clock time setting alarm setting		sleep light Long press to cancel

Charging

Please make sure the speaker is fully charged in first use. The light and display will Flash, indicating that the speaker needs to be recharged. Charge the speaker with the provided USB cable which is compatible with any computer or cell phone charger. The charge indicator light will be red while charging, then when the battery is fully charged it will turn off.

Switch


Long press the switch on the speaker base for 3s to turn it on , and long press again to turn it of. When the speaker is on, the screen will display time and start the bluetooth mode.

Notice: The clock and alarm function are only available once the speaker is turned on. Turning off the speaker will preserve the battery life .



Reset


When the speaker has no reaction for any instruction, please stir “reset “ on the speaker base for 8 seconds with a thin needle, and the speaker will restart.

Display function







Calendar and clock setting

Click the clock setting button “” on the bottom to activate the calendar and clock settings. The display will flash indicating the current option being set in the order of: year, month, day, and time. In each case press “+” “-” to adjust the right number. Press “” to exit after setting each option.





Alarm Setting

Click the alarm setting button “” on the bottom to activate the alarm. The display will flicker to show which numbers are being changed, click “+” “-” to adjust the clock number you want to set, click “”, turn to the minute setting, then adjust the minute number you want, click “”, then the alarm setting is finished.



Alarm switch and light switch

Press the alarm switch button “” on the bottom to turn on the alarm. The alarm symbol on the lower right corner will light up showing that the alarm is active.

When the alarm ring up, the wake up light will be on. Press the “” button on the top of the speaker to turn off the alarm and light. Press the alarm switch button again to cancel the alarm.

Speaker function:

Bluetooth Mode:

First turn on the speaker. Then press and hold the “▶||” button for 3 seconds to enter bluetooth detect mode. The Bluetooth indicator character “BT” will flash rapidly when in bluetooth detect mode for 10 minutes. During this time you should connect the bluetooth speaker to your bluetooth enabled device.

Bluetooth connection:

Step 1: Open the Bluetooth setting on your phone or tablet and click “search device”. iPhones will search for Bluetooth devices automatically.

Step 2: You have found the Bluetooth speaker when the screen displays the character “Lightspeaker1”, click on it in your device to pair the connection.

Step 3: Enter “0000” and click OK if there’s a prompt that requires you to enter a password.

Step 4: The phone or tablet will indicate when the pairing is successful. The “BT” character on the display of the speaker will stop flickering.

Music Playing

Open the player device when the connection is successful. Click to play music, and the Bluetooth speaker will play the music.

You can operate the player with the buttons on the Bluetooth speaker:

Short press “▶||” to play/pause.

Short press “+” to play the next song and long press to volume up.

Short press “-” to play the previous song and long press to volume down.

Bluetooth Hands free Call

Answer and hang up the phone:

There will be an alert sound from the speaker when there is a phone call. Click “▶||” to answer the call, and click “▶||” again to hang up.

In Bluetooth mode, when you long press “▶||” it will be switched to the TF card mode.

TF Card Mode

Insert the TF card when the speaker is turned on. The speaker will enter itself into the TF card mode. It can play the music (MP3/WMA/APE format) from your TF card.

You can operate the player with the buttons on the Bluetooth speaker:



short press “▶||” to play/pause.

Short press “+” to play the next song and long press to volume up.
Short press “-” to play the previous song and long press to volume down.
In TF mode, the display can only show the playing time of songs but not the clock.




Bluetooth pairing and connection

1. If the speaker has been connected with Bluetooth devices before, it will connect with the last Bluetooth device automatically once it is turned on.
2. Other phones or tablets can not be connected with the Bluetooth speaker when the speaker is being connected with a phone or tablet.
3. The phone or tablet can not be connected with the Bluetooth speaker if it is connected with other Bluetooth devices. You should turn off your Bluetooth connection and connect your phone with the Bluetooth speaker again.

Lamp Function

Slide the switch of the speaker on the bottom. Turn on the speaker, and the lamp will light on in the dimmest grade. The brightness can be adjusted by clicking the lamp button “”. The brightness has four grades: micro brightness, low brightness, high brightness, and colorful light. Long press “” to turn on or off the lamp.

Sleep Light Function

Click the button “” on the bottom, and the the symbol “” on the screen will be lighted up, it means the sleep mode is on. Orderly click to set different sleep time, there are 8 sections: 10, 20, 30, 40, 50, 60, 90, 120min. The speaker will turn off the light and music automatically in the corresponding time, it can be used for timing for dressing mask, voga and so on, and can be used as music light before deep sleep. Long press “” to turn off this function.

Frequently Asked Questions

Questions	Solutions
Unsuccessful pairing and connection repeatedly	<ol style="list-style-type: none">1.Check the speaker and make sure it is in the searching state or reboot the speaker.2. Connection is difficult when there are too many Bluetooth devices nearby. Turn off other Bluetooth devices.3.Turn off the Bluetooth device that was connected with the Bluetooth speaker last time, and reconnect the speaker .
Muted or distorted sound	<ol style="list-style-type: none">1.Check the volume of your phone or the speaker, and adjust the volume.2.The battery is low. Please charge it.
Choppy music play	<ol style="list-style-type: none">1. Check if the device is beyond the effective connection distance.2. Check if there is any obstacle between the speaker and your device.
The indicator not shining in Bluetooth mode	<ol style="list-style-type: none">1.The battery is low. Please charge it.2.Please reboot the speaker.

Precautions

- 1.Please store and use the product in room temperature environment.
- 2.Do not expose this product in rain or wet conditions.
- 3.Do not drop or bump this product.
- 4.Do not disassemble, repair, or modify the product.
- 5.Please use the power charge with rated voltage for the speaker.
- 6.It may cause hearing damage if playing music in high volume for a long time. Consider avoiding excessively high volume when playing music for a long time.
- 7.Disassemble this product will invalidate the warranty.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.