

COBY®

 **Bluetooth®**

Model No.: CVBT10



Instruction Manual

↘ Safety information

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects

- have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Do not expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.
 16. To completely disconnect this apparatus from the AC Mains, disconnect the power supply cord plug from the AC receptacle.
 17. The mains plug of the power supply cord shall remain readily operable.
 18. Do not expose batteries to excessive heat such as sunshine, fire or the like.

Warnings and Precautions

WARNING: To prevent fire or shock hazards, do not expose this unit to rain or moisture.

WARNING: Do not place the unit on top of any soft, porous, or sensitive surfaces to avoid damaging the surface. Use a protective barrier between the unit and surface to protect the surface.

WARNING: Where the mains plug or appliance coupler is used as the disconnect device, such disconnect device shall remain readily operable.

Note: This device uses an internal rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead after several attempts to charge, please contact **COBY** for support.

Never disassemble the unit or attempt to remove the battery as that could cause leakage of an electrolytic substance.

FCC Warnings

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.



The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks is under license.

Thank you for purchasing the CVBT10 Stereo Headset with Bluetooth Wireless technology; we encourage you to read this quick installation guide thoroughly to get the most of this innovative wireless headset.

Contents


Headset

USB cable with one ferrite core

User manual

Functions:

1. Previous track
2. Play/pause button
3. Next track
4. USB interface for charging
5. Volume up (+)
6. Volume down (-)
7. Power on/off button
8. Microphone



Status indicator:

Alternating Blue and Red LEDs indicate headset has entered into the pairing mode and ready to be paired for the first time.

Blue LED flashing slowly indicates the device is powered on and/or connected to a device.

Solid red LED indicates the battery is charging. When the battery has reached full capacity, the solid red LED will go off.

Charging your headset

Use the supplied USB cable to charge the battery directly from your PC. The Red LED indicator will illuminate.

Make sure that your CVBT10 headset is fully charged before using it for the first time.

The headset battery has to be initially charged for at least 4 hours. Thereafter, the battery will take approximately 2 to 3 hours to recharge.

Pairing a Bluetooth Device

Pairing the CVBT10 headphones with a Bluetooth enabled device. (Smartphone, Computer, Tablet etc)

1. Make sure to power the CVBT10 off.
2. Activate the bluetooth feature function on your native device to begin setup.
3. The "Search new device" screen will be displayed.
4. Place both devices no more than 3 feet away from each other.
5. Press and CONTINUE to HOLD the power button until the Blue/Red Led indicator starts blinking alternately, this indicates that the headset has entered pairing mode.
6. As soon as the system detects the new device in your dialog box, select the icon that reads "CVBT10"
7. The software may activate the passkey window and ask you to enter the PIN code = "0000"(4 zero). Otherwise, the wireless connection will be established automatically with the remote device.
8. If the pairing is successful, the Blue LED will start blinking slowly. If after 60 seconds the pairing process fails, please

repeat steps 1 through 7 described above.

9. The headset will go automatically into standby mode after a short period of inactivity.

Answering and ending a call using your mobile phone

When there is an incoming call, the headset will ring.

Briefly press the power button to answer an incoming call. You may also press the answer button on your cellular phone to receive the call in your headset. Music playback pauses temporarily. To end a call simply tap the power button once again.

Likewise, you may also end the call directly using your cell phone. As soon as your hang up, music playback resumes automatically.

Likewise, you may also end the call directly using your cell phone. As soon as your hang up, music playback resumes automatically.

Specifications:**Mic. Spec.:**

Microphone Unit: \varnothing 6*5mm

Directivity: omnidirectional

S.P.L: -58 \pm 2dB

Impedance: \leq 2.2K Ω

Frequency response: 20Hz-20,000Hz

Operating Voltage: 4.5V

Speaker Spec.:

Speaker diameter: \varnothing 40mm

Impedance: 32 Ω

S.P.L: 118 \pm 3dB S.P.L at 1KHZ

Rated power: 20mW

Aggregate capability: 50mW

Frequency response: 20Hz-20,000Hz

Power:

Battery type: Built-in 360mAh Lithium-polymer rechargeable battery

Charging connector type: Micro USB 5V/1A

Run time: Up to 10 hours of talking or music playback time

Standby time: Up to 10 hours

Charging time: 2 hours

Operating Temperature: -10 $^{\circ}$ C - 45 $^{\circ}$ C

Storage Temperature: -25 $^{\circ}$ C - 60 $^{\circ}$ C

Troubleshooting & Support

If you have a problem with this device, please read the troubleshooting guide below and check our website at www.cobyusa.com for Frequently Asked Questions (FAQs) and firmware updates. If these resources do not resolve the problem, please contact Technical Support.

Address
COBY Electronics Corporation
Technical Support
150 Knowlton Way
Savannah, GA 31407

Email
techsupport@cobyusa.com

Web
www.cobyusa.com

Phone
800-727-3592: Weekdays: 8:30AM-9:00PM EST
Saturdays: 9:00AM-5:30PM EST

1. Cannot turn the unit on.
Ensure that the Li-battery of headset is fully charged thru a USB cable connect to an AC power or PC(PC must not be in sleep mode).
2. The LED indicator not lighting up when charging
- Please make sure the USB charging cable is connected properly with the headset.
- If you haven't used the headset in a long time, the battery may be too low for the LED indicator to light up. You'll need to charge the headset for 30 minutes, then you'll see the LED indicator light up red.
3. The headset is not pairing with my mobile phone

- Is Bluetooth enabled on your mobile phone?
 - Try to pair the devices again. Please switch off headset and follow the instructions (Please refer to "Pairing a Bluetooth device")
4. Music is playing out of the speaker on my phone instead of the headset
- Some mobile phones, when they are playing music, the music will be transmitted through the speaker of the mobile phone. You may have to choose "transmit the sound through Bluetooth" in the settings.
 5. I'm trying to make a phone call, but can't hear the other person's voice
- Please make sure the headset has been switched on.
- Make sure the volume is not at the lowest setting or muted.
- Make sure that the headset is properly connected to the Bluetooth device.
- Make sure the distance between the headset and the mobile phone is in the proper range.
 6. During a phone call, the other person's voice is not clear
- Make sure that you have a good signal on your mobile phone.
- Make sure the headset is in the proper range of the native device.

COBY®

 **Bluetooth®**

Model No.: CVBT20



Instruction Manual

↘ Safety information

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects

have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

15. Do not expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.
16. To completely disconnect this apparatus from the AC Mains, disconnect the power supply cord plug from the AC receptacle.
17. The mains plug of the power supply cord shall remain readily operable.
18. Do not expose batteries to excessive heat such as sunshine, fire or the like.

Warnings and Precautions

WARNING: To prevent fire or shock hazards, do not expose this unit to rain or moisture.

WARNING: Do not place the unit on top of any soft, porous, or sensitive surfaces to avoid damaging the surface. Use a protective barrier between the unit and surface to protect the surface.

WARNING: Where the mains plug or appliance coupler is used as the disconnect device, such disconnect device shall remain readily operable.

Note: This device uses an internal rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead after several attempts to charge, please contact **COBY** for support.

Never disassemble the unit or attempt to remove the battery as that could cause leakage of an electrolytic substance.

FCC Warnings

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.



The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks is under license.

Thank you for purchasing the CVBT20 Stereo Headset with Bluetooth Wireless technology; we encourage you to read this quick installation guide thoroughly to get the most of this innovative wireless headset.

Contents:


Headset

USB cable with one ferrite core

User manual

Functions:

1. Volume up (+)
2. Volume down (-)
3. Power on/off button
4. Microphone
5. Previous track
6. Play/pause button
7. Next track
8. USB interface for charging



Status indicator:

Alternating Blue and Red LEDs indicate headset has entered into the pairing mode and ready to be paired for the first time. Blue LED flashing slowly indicates the device is powered on and/or connected to a device. Solid red LED indicates the battery is charging. When the battery has reached full capacity, the solid red LED will go off.

Charging your headset:

Use the supplied USB cable to charge the battery directly from your PC. Make sure that your CVBT20 headset is fully charged before using it for the first time. The headset battery has to be initially charged for at least 4 hours. Thereafter, the battery will take approximately 2 to 3 hours to recharge.

Pairing the CVBT20 headphones with a Bluetooth enabled device. (Smartphone, Computer, Tablet etc)

1. Make sure to power the CVBT20 off.
2. Activate the bluetooth feature function on your native device to begin setup.
3. The "Search new device" screen will be displayed.
4. Place both devices not more than 3 feet away from each other.
5. Press and CONTINUE to HOLD the power button until the Blue/Red Led indicator starts blinking alternately, this indicates that the headset has entered pairing mode.
6. As soon as the system detects the new device in your dialog box, select the icon that reads "CVBT20".
7. The software may activate the passkey window and ask you to enter the PIN code ="0000" (4 zeros). Otherwise, the wireless connection will be established automatically with the remote device.
8. If the pairing is successful, the Blue LED will start blinking slowly. If after 60 seconds the pairing process fails, please repeat steps 1 through 7 described above.

9. The headset will go automatically into standby mode after a short period of inactivity.

Answering and ending a call using your mobile phone

When there is an incoming call, the headset will ring. Briefly press the power button to answer an incoming call. You may also press the answer button on your cellular phone to receive the call in your headset. Music playback pauses temporarily. To end a call simply tap the power button once again. Likewise, you may also end the call directly using your cell phone. As soon as your hang up, music playback resumes automatically.

Specifications:**Mic. Spec.:**

Microphone Unit: \varnothing 6*5mm
 Directivity: omnidirectional
 S.P.L: -58 ± 2 dB
 Impedance: ≤ 2.2 K Ω
 Frequency response: 20Hz-20,000Hz
 Operating Voltage: 4.5V

Speaker Spec.:

Speaker diameter: \varnothing 40mm
 Impedance: 32 Ω
 S.P.L: 118 ± 3 dB S.P.L at 1KHZ
 Rated power: 20mW
 Aggregate capability: 50mW
 Frequency response: 20Hz-20,000Hz

Power:

Battery type: Built-in 400mAh Lithium-polymer rechargeable battery
 Charging connector type: Micro USB 5V/1A
 Run time: Up to 10 hours of talking or music playback time
 Standby time: Up to 100 hours
 Charging time: 2 hours
 Operating Temperature: -10°C - 45°C
 Storage Temperature: -25°C - 60°C

Troubleshooting & Support

If you have a problem with this device, please read the troubleshooting guide below and check our website at www.cobyusa.com for Frequently Asked Questions (FAQs) and firmware updates. If these resources do not resolve the problem, please contact Technical Support.

Address
COBY Electronics Corporation
Technical Support
150 Knowlton Way
Savannah, GA 31407

Email
techsupport@cobyusa.com

Web
www.cobyusa.com

Phone
800-727-3592: Weekdays: 8:30AM-9:00PM EST
 Saturdays: 9:00AM-5:30PM EST

1. Cannot turn the unit on.
Ensure that the Li-battery of headset is fully charged thru a USB cable connect to an AC power or PC (PC must not be in sleep mode).
2. The LED indicator not lighting up when charging
 - Please make sure the USB charging cable is connected properly with the headset.
 - If you haven't used the headset in a long time, the battery may be too low for the (LED indicator to light up. You'll need to charge the headset for 30 minutes, then you'll see the LED indicator light up red.
3. The headset is not pairing with my mobile phone
 - Is Bluetooth enabled on your mobile phone?
 - Try to pair the devices again. Please switch off headset and follow the instructions (Please refer to "Pairing a Bluetooth device"
4. Music is playing out of the speaker on my phone instead of the headset
 - Some mobile phones, when they are playing music, the music will be transmitted through the speaker of the mobile phone. You may have to choose "transmit the sound through Bluetooth" in the settings.
5. I'm trying to make a phone call, but can't hear the other person's voice
 - Please make sure the headset has been switched on.
 - Make sure the volume is not at the lowest setting or muted.
 - Make sure that the headset is properly connected to the Bluetooth device.
 - Make sure the distance between the headset and the mobile phone is in the proper range.
6. During a phone call, the other person's voice is not clear
 - Make sure that you have a good signal on your mobile phone.
 - Make sure the headset is in the proper range of the native device.