



## **HOW TO USE**

1. Startup: press and hold the camera button for 3 seconds to start the machine, and the indicator Bashes to the side recess. enter the search state.

enter the search state.

2. Bluetooth connection: open the mobile phone
Bluetooth search "VIP" and click the connection. After the
connection is successful, the indicator light goes out.

3. Photographing: when the remote control is connected with the mobile phone, click the photographing button, the indicator Bashes and takes pictures.


4. Shutdown without connection: when the remote control is in the state of no connection and no operation. it will automatically shut down for about 5 minutes. 5. Connected shutdown: when the remote control is connected with the mobile phone, it will enter the sleep state without operation for about 10 minutes, and then automatically shut down without operation for about 10

6. Sleep: after entering the sleep state, press the photo key to connect the mobile phone. 7. Shutdown: in the power on and sleep state, long press the photo key for 3 seconds, the indicator Bashes off and


8. Back connection function: the remote control has memory connection function. When the mobile phone Bluetooth is turned on, the remote control will automatically connect the matched mobile phone.

# Remove The Self Timer

Pull out the remote control from



**How To Replace The Battery** Push the battery back cover to open the remote control cover.




### Clip can rotation

Flip freely and shoot position of the handle horizontally and vertically to take photos from multiple angles, which is more free to take photos. to change to quadruped mode



# How to open itQuadruped

quadruped mode, pay attention to pull out the last section of the lever and adjust it until the quadruped is stable.



Quadruped **Product parameters**Width of holding mobile phone: 65-90mm When the self timer lever changes to the Supported mobile phone size: 4.7-7 inches

### Remote control parameters Button battery:Battery model: cr1620 button

battery (replaceable - as shown in Figure 2) Battery voltage: 3V Battery capacity: 70mAh Bluetooth version: 5.2 Bluetooth Name: VIP

## Solution to the case of failure of remote control to 1) Turn on the Bluetooth of the mobile phone and clear

Connect the Bluetooth remote control to the mobile some pairedEquipment.
2) Turn off and restart the phone.
3) Turn off and restart the Bluetooth remote control. . Enter the camera on the mobile phone or download 4) Turn on the Bluetooth connection again.
5) Turn on the mobile phone Bluetooth, turn on the remote control, and search the mobile phone 4. Click the remote control button to record the video 5. Click the button again to end the video recording interfaceWhen you get the VIP, click Connect, and the interface displays "connecting"When "connect / pair", press the remote control button continuously and quickly, Operating mode: that islt can be connected normally (Excitation is only required for the first connectionLive, automatic connection in the future, normal use)

# Remote control, effective distance 10m

For Android phones, press the remote control to add soundSolution to the problem of quantity / focus adjustment and / or no response.

1) Open the camera to enter the photographing

Set the volume key function to shutter (do not select zoom or zoom)Focus).
 The setting path of individual mobile camera is different, please find it yourself.

This remote control only supports the video recording function of mobile camera, and does not support the video recording function of live app.

Swipe left or find the camera settings.

Click the volume key function.

2. Quadruped mode 3. Handheld mode

#### 关于安卓系统手机个别出现按遥控器为加音 量/调焦距/或无反应的问题的解决方案。

2)向左滑动或者找到相机设置。 3)点击音量键功能。 4)将音量键功能设置为快门(不要选缩放或 者对焦)。

5)个别手机相机设置路径不同,请自行查找。

#### 本遥控器仅支持手机相机视频录制功能,暂不 支持直播APP录视频功能。

1.蓝牙遥控器连接手机

1) 打开相机进入拍照界面。

2.进入手机自带相机或者下载其他相机APP软件 3.切换到视频界面 4 单击谣控器按键进行视频录制 5.再单击按键结束视频录制

操作模式: 1.远程遥控,有效距离10米 2.四脚架模式 3.手持模式

This device complies with part 15 of the PCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ompliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the PCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

· Consult the dealer or an experienced radio/TV technician for help

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction