

Bluetooth Speaker User Manual

Thank you for purchasing our bluetooth speaker. Please read this manual carefully and keep it for future reference.

Features of the speaker:

1. Support wireless control through Bluetooth device
2. Support TWS: True wireless stereo
3. Support plug and play for TF card
4. 3.5mm line-in jack for wired devices
5. Built in rechargeable battery supports up to 10 hours playback (medium volume)
6. Two 6W speakers deliver deep and rich sound
7. Built-in Microphone for phone calls
8. Support MP3, WAV, APE, FLAC, WMA format of audio file TF card
9. Support FM radio

Operating Instructions:

1. Charging

With the speaker turned off, connect the Micro-USB connector of the charging cable to the DC5V input socket at the rear side of the speaker, and plug the USB connector of the charging cable to an external USB power supply socket with a minimum supply current of 1A. The external USB power supply can be the USB socket in your computer/laptop, the USB adaptor of most cellphone USB chargers with DC5V output, or the 5V USB port of a power socket etc.

When charging, the power indicator will be red.

2. On/Off

The On/Off slide button is at the rear side of the speaker. Slide to the on or off position to turn the speaker on or off

3. Bluetooth

Pairing – 1. Turn on speaker to enter Bluetooth mode directly. Then turn on your Bluetooth device (such as a mobile phone, laptop, PDA etc), search for Bluetooth equipment “F6”, and then pair up with the speaker. There will be a sound from the speaker when Bluetooth connection is established

Bluetooth phone call - When paired to your phone, press the  button to


answer incoming calls, and press the  button again can end the call; Press

 button and hold for 5 seconds can refuse the incoming calls; Press the



 button twice can call back to the last incoming call number.

Note: Please talk close to the microphone when making phone calls.



TWS Operation: Put the two F6 speakers together, and turn on speakers to enter

Bluetooth mode, then choose one of them to press  button and hold for 2 seconds, the two speakers will start automatically pair and enter TWS mode, the one which you chose to press will work as left channel.

Volume adjustment – When playing music and when making a phone call under

Bluetooth mode, the volume can be adjusted by pressing the  /  button. The volume can also be controlled from your Bluetooth device (cellphone, laptop, PDA etc.)

Track selection – When playing music in Bluetooth mode, a short press of

 /  buttons will jump to the previous track or next track. Track selection can also be done from your Bluetooth device.

4. AUX / Line in:

Insert the audio cable into the 3.5mm jack of speaker and connect the other side to your laptop / mobile phone / mp3 / mp4 / CD player etc to play music file from AUX/Line in.

5. TF Card:

The speaker supports plug and play for Micro SD card. Just plug in your TF Card into the speaker's Card slot and the speaker will play the music files automatically.

6. FM radio

Put the slide button on FM mode, then press  button and hold, speaker will start automatically searching FM channels and save channels. After finished

search, press  /  buttons can adjust channels, the volume can be

adjusted by pressing the  /  buttons.

7. Reset - If the speaker is not working normally, please turn on or powered on the speaker then speaker will reset.

Note:

1 If speaker is in lower power, machine will play warning tone for three times and then turn to sleep mode, please charge it then can work normally again

2. Due to the 2.4G radio interference, if the speaker can not paired or play music well, please turn on the speaker again or reconnected the Bluetooth device again.

8. Technical data

Power	Built-in 4000mA Li battery	
	External USB 5V supply	
	Working voltage : 3.2V-4.2V	
	Charging voltage: 5V 1000mA	
Technical	Frequency	100HZ-18KHZ
	SNR	≥85db
	Sensitivity Rate	80db
	THD	≤0.3%
Speaker	Φ 52mm 4 Ω 20 core	
RMS	6W*2	
Music format	MP3, WMA, WAV, APE, FLAC	
Speaker size	φ 205*57mm	
Weight	621g	

Trouble shooting:

1. Can't turn the speaker on:

Check if the battery is in low. Recharge and then try to turn on again

2. Can't charge the speaker:

Check the power supply is working and that the output of the power supply to the charge cable is 5V and > 1A.

Check that the charge cable and connectors of the cable are not damaged.

3. No sound:

Check the speaker is paired with the right Bluetooth device. If not, disconnect the Bluetooth connection and pair again to the right device.

Check the music format in the TF card.

Warning:

1. Do not use the product in high temperature; Always keep the product away from fire. For the sake of your safety, never throw the product into fire, which may cause explosion and personal injury.
2. Do not use the product close to high-voltage wire or electronic apparatus. Please take proper safety measures when using the product in terrible weather conditions.
3. Do not use near water or any high-humidity environment, which may cause destructive damage to the product
4. The product is not designed for use in or near any strong magnetic field, which may cause destructive damage to the product

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ABCD-F6