

(3)	M79 (MENU) key	Enters menu mode.
4	∽ (Up) key	In standby mode, shows the last numbers dialled. In the menu mode or within a list, moves the cursor up to select an item.
5	← (Down) key	In standby mode, shows the last numbers received. In the menu mode or within a list, moves the cursor down to select an item.
6	CLR (CLEAR) key	Clears your entry or corrects wrong item.
7	Digit keys	Enter phone numbers, alphanumeric information, etc.
8	(*) key	Enters \bigstar . Holding this key will show "+", which is used in placing international calls.
9	(#) key	Enters # . Holding this key will display "P", which is used for DTMF sending.

8

8