

Bluetooth Earphone

# User Manual

BRAND NAME:180s

MODEL NAME:180s-BT12

FCC ID:UHB180s-BT12

**Limited Warranty**  
**What Does This Warranty Cover?**  
 180cs warrants the Hi-Def BTH Bluetooth Ear Warmer to be free from defects in materials and workmanship under normal consumer usage for the period of six (6) months from date of purchase by the first consumer purchaser of this product.

**What Does This Warranty Not Cover?**  
**Normal wear and tear:** Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

**Batteries:** Only batteries in which the fully charged capacity falls below 75% of their rated capacity and batteries that have been covered by this limited warranty.

**Abuse and Improper Use:** Damage or defects that result from: (1) improper operation, storage, improper use or abuse, accident or neglect, such as physical damage (holes, cracks, etc.) to the surface of the product resulting from misuse; (2) contact with liquid, water, rain, extreme heat or cold, extreme humidity or heavy temperature, sand, dirt or the like; or (3) use of the Product for commercial purposes or subjecting the Product to abnormal usage or conditions; or (4) other acts which are not the fault of 180cs, are excluded from coverage.

**Use of Non-180cs Products and Accessories:** Defects or damage that result from the use of non-180cs branded or certified Products, Accessories, or other peripheral equipment are excluded from coverage.

**Unauthorized Service or Modification:** Defects or damages resulting from service, testing, adjustment, replacement, maintenance, alteration, or modification in any way by someone other than 180cs are excluded from coverage.

**Altered Products:** Products or Accessories with (1) serial numbers or date tags that have been removed, altered or obliterated; (2) broken seals or other clear evidence of tampering are excluded from coverage.

**Communication Services:** Defects, damages, or failures of Products or Accessories due to any communication service you may subscribe to or use with the Products or Accessories is excluded from coverage.

**Who Does This Warranty Cover?**  
 This warranty extends only to the first consumer purchaser and is not transferable.


**What Will 180cs Do?**  
 180cs, at its option, will, at no charge repair, replace, or refund the purchase price of any Products or Accessories that do not conform to this warranty. We may use functionally equivalent reconditioned/remanufactured/owner or new Products, Accessories, or parts.

**How to Obtain Warranty Service or Other Information?**  
 In the USA and Canada, call: 1-877-725-4366

You will receive instructions on how to ship the Products or Accessories, at your expense, to 180cs for repair or replacement. To obtain service, you must include: (1) a copy of your receipt, bill of sale, or other comparable proof of purchase; (2) a written description of the problem; and, (3) your shipping address, email address, and telephone number.

**What Other Limitations Are There?**  
 ANY IMPLIED WARRANTIES SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. OTHERWISE, THE REPAIR, REPLACEMENT OR REFUND AS PROVIDED UNDER THIS EXPRESS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL 180CS BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE), FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE INABILITY TO USE THE PRODUCT OR ACCESSORY TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you the specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.



Hi-Def BTH  
**Bluetooth Ear Warmer**

www.180cs.com

**Introduction**  
 Thank you for purchasing the 180cs Hi-Def BTH Bluetooth Ear Warmer! You now own the most innovative ear warmer on the planet! You can talk on the phone and listen to music in high definition comfortable as if surrounds your ears in warmth! So charge it up, call your friends, and treat your ears to your favorite tunes all while staying warm!

**Included in the box**  
 1x 180cs Hi-Def BTH Bluetooth Ear Warmer  
 1x USB charging cable  
 1x User Instruction manual

**Charging your 180cs Hi-Def BTH**  
 Your Hi-Def BTH Bluetooth Ear Warmer will need to be fully charged before first use. You will not be able to use it during the charging period. To charge your Hi-Def BTH, locate the 3.5mm connector inside the 3.5mm jack end of the USB charging cable into it (see fig. 1). Then plug the USB end of the charging cable into the USB port on your computer or other USB power source. The power button on the Hi-Def BTH will illuminate red to indicate that the device is charging. Once charging is complete you will see about 3.5 hours for full charge, the red light will turn off. Unplug the charging cable and you are ready to use your Hi-Def BTH!




Fig. 1: Insert here

**Battery Life**

- Charging time: about 3.5 hours
- Up to 9 hours of talk time on a full charge
- Up to 8 hours of listening time on a full charge
- Up to 100 hours of standby time on a full charge

**Power On/Off**  
 To turn off your Hi-Def BTH, locate the power button/indicator light at the center of the right ear piece. Press and hold the button down for 5-6 seconds. The indicator light will flash red once the device is on, then will flash blue. To turn off, hold the button down for 5-6 seconds. The indicator light will flash red once to indicate that the device has turned off.

**Pairing with another device**  
 To make calls or listen to music using your Hi-Def BTH, you must first pair it with your Bluetooth enabled smart phone, tablet, or computer. To pair Hi-Def BTH with a phone/tablet/computer, follow these steps:

1. Turn off all other paired Bluetooth devices.
2. Turn phone/tablet/computer Bluetooth function on and set to "Pair" or "Search for new devices".
3. With power off, hold Hi-Def BTH power button down for 8-10 seconds until indicator light flashes blue and red rapidly.
4. Once the phone/tablet/computer has found the Hi-Def BTH, it will appear on the screen as a new device and read "180cs Hi-Def BTH".
5. Click or tap on it and it will connect to the Hi-Def BTH and indicate the devices are now paired.
6. Once complete, the indicator light on the Hi-Def BTH will flash blue.

Once paired, you may now listen to music or make phone calls.

**Phone Operation**

- To answer an incoming phone call: Press button on Hi-Def BTH once
- To end a call and answer a new call: Double-press button on Hi-Def BTH
- To reject an incoming call while in call: Double-press button on Hi-Def BTH once
- All above listed functions can also be controlled on the phone itself
- All pairing and volume levels are controlled on the phone itself

**Music Operation**

- To play music: Select music on your device and press play
- To pause music: double play: Press button on Hi-Def BTH once. Press again to resume play
- To answer an incoming phone call during music play: Press button on Hi-Def BTH once (music will pause when the call comes in and resume play once the call is ended)
- All above listed functions can also be controlled on the phone/tablet/computer
- Volume and music track selection are controlled on the phone/tablet/computer

**Hi-Def BTH Specifications**

Bluetooth Version	V2.1 + EDR
Profiles	Headset, Handsfree, A2DP & AVRCP
Modulation	-FSK
Transmitter	Class 2
Effective Range	10 Meters/30 Feet
Frequency Range	2.402GHz - 2.480GHz
Frequency Response	20Hz - 20KHz

**Care and Maintenance**

- When not in use, store your Hi-Def BTH in a dry, room temperature place. Do not store your Hi-Def BTH in a parked car when extreme temperatures may occur
- Do not subject to extreme cold or heat for extended periods of time
- **Spot clean ONLY with a cloth and mild soap/water solution.**
- DO NOT submerge in water or get the device wet.
- Do not drop the ear warmer
- Do not disassemble the ear warmer

**Safety and General Information**

While driving, NEVER:

- Type or read texts
- Enter or review written data
- Use an internet browser
- Input navigation information
- Perform any activities that take your attention away from driving

While driving, ALWAYS:

- Keep your eyes on the road and hands on the wheel
- Obey local and federal traffic laws
- Use a hands free device for phone calls where required by local law
- Use voice activation features when possible

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.