



AirCard™ 800 Series

Wireless Network Card Quick Start Guide



2130707 Rev. 1.0 (June 2006)


www.sierrawireless.com

Your package contains the following:

- AirCard wireless network card (modem)
- Installation CD containing the AirCard connection manager software and Installation Guide
- This Quick Start Guide


This guide provides installation instructions for users of Windows® XP and 2000.

1



Please do not insert the AirCard modem into the PC Card slot before installing the software.

2




Insert the CD in the CD-ROM drive. If a menu does not appear automatically, select **Start > Run** and enter **d:\Setup.exe**, where **d** is your CD-ROM drive letter.

3


Select "notebook installation...", and then select "notebook software installation (XP, 2000)". This launches a program that guides you through installation of Watcher™ and the AirCard device drivers.

4




Hold the AirCard modem face down. Insert the SIM / USIM into the slot at the side of the AirCard modem, as shown in the illustration.

5




When prompted, insert the AirCard modem into the PC Card slot.

6

Launch Watcher from the Start menu or double-click the Watcher icon on your desktop . If you are prompted to configure a profile, select **Yes** and follow the account configuration instructions in step 6 below.

7

Select **Tools > Connections**. Click the  icon and select **WWAN profile**. From the Profile Name drop-down list, select the profile corresponding to your service provider, or enter a Profile Name and complete the fields. (If you do not know the APN, username, and/or password for your account, contact your service provider.)

If you want Watcher to run automatically when Windows starts up:

1. Select **Options > General**.
2. From the "Automatically run on Windows startup" drop-down list, select **Yes**.

The AirCard modem is now ready for use.

To access the Help system in Watcher, select **Help > Help topics**.

If you are using Microsoft® Internet Explorer® as your browser, you may need to configure it to use the AirCard modem. (See the Installation Guide on the CD.)