


1410 receiver operation manual

Date:2005-5-3



Operation description:

- Receiver Power input : 120Vac/60Hz.
1. First plug receiver plug to get electricity.
 2. Receiver there are three mode can be select:
 - I. Remote: that mean receiver are ready to get handset command control solenoid on/off.
 - II. OFF: receiver's solenoid always off.
 - III. ON: receiver's solenoid always on.
 3. Receiver learn ID code way: press receiver's learn button then receiver will beep, the after user press handset any button if receiver learn ok receiver will sound beep, beep.....
 4. User press handset button control solenoid on/off.
 - I. ON button: solenoid on.
 - II. OFF button: solenoid off.

This device complies with Part15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including.
Interference that may cause undesired operation.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH (MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.