


## Level3 Operation description

Date:2008-02-14

Author: Javy Huang

### ● LCD Diagram



### ● LCD Indicator:

1. Manual On Flame Icon: Indicates burner/valve in operation.
2. Manual On / OFF: Indicates the system ON / OFF.
3. Set Temperature: Indicates the required temperature.
4. Thermostat: Indicates the system activates the thermostat mode.
5. Flame: Indicates the flame function and burner/valve(High/Low).
6. Bullet point: Indicates the current setting of functions.
7. Level / Valve: Indicates the level of current function.
8. Fan: Indicates the fan function and level(Hi/Med/Lo/Off).
9. Aux1: Indicates the Aux1 function and level(Hi/Med/Lo/Off).
10. Aux2: Indicates the Aux1 function and level(Hi/Off).

11. Pilot: Indicates the pilot function and level(On/Off).
12. Level: Indicates the level of Pilot function.
13. Timer: Indicates the system activates the timer mode.
14. Timer Setting: Indicates the time of timer.
15. Child Proof: Lock-out operation of the appliance.
16. Low Battery: Battery power is low. Replace batteries within two weeks.
17. Room Temperature: Indicates CURRENT room temperature.

● **Button Description:**



- 1) Manual On: Press  once, unit comes on in System On.

The flame icon  **ON** appears on screen.




- 2) Manual Off: Press  once, unit comes on in System Off.

The flame icon  **ON** disappeared and **OFF** appears on screen.



- 3) Menu: Press  once, all of the functions will appear on



screen by different mode. Press  or  change the levels and

press  to confirm the setting.

- 4) Child Proof Lockout: To activate the child-proof lockout feature, press and hold



and



buttons,






“ ” will briefly

appear immediately on screen.

- 5) Initial Setting: the small button locate inside battery lid to enter the initial setting for C/F conversion and Swing Setting.

### ● Operation Description:

- 1) Low Battery (  ) will appear when battery power has dropped significantly.
- 2) The room temperature  always shows on screen, which range between 32 and 99 Fahrenheit.
- 3) The Child Proof (  ) will appear on screen if the “Lock-out” Feature is activation.

### ● Further Description

- 1) Radio Frequency range: 303.8MHZ
- 2) The remote receiver is Smart MOD.
- 3) The remote controller effective distance is above 40 feet.

### **FCC Compliance Statement:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may

cause undesired operation.

**Note:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

### **15.19 FCC Compliance Statement**

**This device complies with Part 15 of the FCC Rules.**

**Operation is subject to the following two conditions:**

**(1) This device may not cause harmful interference, and**

**(2) This device must accept any interference received, including interference that may cause undesired operation.**

### **15.21 Statement**

**Changes or modifications not expressly approved by the party responsible for**

**compliance could void the user's authority to operate the equipment.**