

# Quick Start Guide


## INSTEON® Micro Shutter

Model: 2444-222/2444-422/2444-522

### About INSTEON Micro Shutter

Congratulations on your purchase of the INSTEON® Micro Shutter! This compact module wires in behind an existing wall switch to give you complete—and completely hidden—remote control over your motorized window shutters.

**Note:** Installation should only be performed by a qualified electrician or a homeowner who is familiar and comfortable with electrical circuitry. If you have questions, consult an electrician or call the INSTEON Support Line at 800-762-7845.



### In the Box

- INSTEON Micro Shutter

### What's Needed

- Flathead screwdriver
- Phillips screwdriver
- Wire cutter/stripper
- Voltage meter

### Installing INSTEON Micro Shutter (Dual Momentary Switch)

- 1) Before installing, write down Micro Shutter's INSTEON I.D. (on sticker) for future reference.
- 2) Turn off breaker/fuse<sup>1</sup> and verify that the power is off.
- 3) Remove wallplate and unscrew existing switch.
- 4) Gently pull switch out of wall and disconnect wires.<sup>2</sup>
- 5) After ensuring that the wires are not touching, turn breaker back on.
- 6) Use a voltage meter to identify the fixture's Line, Load and Neutral wires.
- 7) Turn off breaker again.
- 8) Connect Micro Shutter wires as follows:

| Micro Shutter | House                   |
|---------------|-------------------------|
| Terminal #1   | Line (100-277VAC)       |
| Terminal #2   | Load (light, fan, etc.) |
| Terminal #3   | Neutral                 |
| Terminal #4   | Neutral                 |
| Micro Shutter | Switch                  |
| Yellow wire   | Momentary on/brighten   |
| Purple wire   | Momentary off/dim       |

- 9) Turn breaker back on.

*Connected load will turn on and Micro Shutter's LED will turn on green.*

- 10) Test connection by tapping Micro Shutter's on/off buttons.

*Connected load will turn on and off and Micro Shutter's LED will turn green (on) and red (off).*

<sup>1</sup> If multi-gang box, turn off all breakers/fuses that may be supplying power to the box.

<sup>2</sup> If the wires cannot be detached, cut wires where they enter the switch and strip ½" of insulation off the ends.

- 11) If you are planning to manually link Micro Shutter to any INSTEON controllers, do so now (see *Adding Micro Shutter as an INSTEON Responder* below).
- 12) Turn breaker off.
- 13) Place Micro Shutter in rear of wall box.
- 14) Remount switch in wall box.
- 15) Turn breaker back on.  
*Connected load will turn on at its previous state (prior to turning off breaker).*
- 16) Test installation by tapping switch on and off.  
*Connected load will turn on and off.*
- 17) Reinstall wallplate.

### Adding Micro Shutter as an INSTEON Responder

We recommend using INSTEON SmartLinc and the free INSTEON iOS/Android smartphone and tablet app or home automation software (such as HouseLinc) to add and monitor Micro Shutter on your home network. You can also add Micro Shutter to your network manually by following the instructions below. *Note: you must perform these steps before reinstalling the wall switch.*

- 1) Press and hold controller's ON/scene button until it beeps.  
*Controller's LED will start blinking green.*
- 2) Adjust load connected to Micro Shutter to desired brightness level.
- 3) Press and hold Micro Shutter's Set button until it double-beeps.  
*Controller will double-beep and its LED will stop blinking.*
- 4) Test link by tapping controller's ON/scene button on and off.  
*The load connected to Micro Shutter will turn on and off.*

### Adding Micro Shutter as an INSTEON Controller

We recommend using INSTEON SmartLinc and the free INSTEON iOS/Android smartphone and tablet app or home automation software (such as HouseLinc) to add and monitor Micro Shutter on your home network. You can also add Micro Shutter to your network manually by following the instructions below. *Note: you must perform these steps before reinstalling the wall switch.*

- 1) Press and hold Micro Shutter's Set button until it beeps.  
*Micro Shutter's LED will start blinking green.*
- 2) Adjust responder to desired state.
- 3) Press and hold responder's Set button until it double-beeps.  
*Micro Shutter will double-beep and its LED will stop blinking.*
- 4) Test link by tapping Micro Shutter's paddle top and bottom to turn on/off.  
*The responder turn on and off.*

### FCC Compliance

This device complies with FCC Rules Part 15. Operation is subject to two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference that may be received or that may cause undesired operation.

The digital circuitry of this device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio and television reception. However, there is no guarantee that interference will not occur in a particular installation. If

this device does cause such interference, which can be verified by turning the device off and on, the user is encouraged to eliminate the interference by one or more of the following measures:

- Re-orient or re-locate the receiving antenna of the device experiencing the interference.
- Increase the distance between this device and the receiver.
- Connect the device to an AC outlet on a circuit different from the one that supplies power to the receiver.
- Consult the dealer or an experienced radio/TV technician.

**WARNING!** Changes or modifications to this device not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Industry Canada Compliance

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of that device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## Owner's Manual and Tech Support

Owner's Manual and Quick Start Guide: <http://www.insteon.com/support>  
Call: INSTEON Support Line at 800-762-7845