

Setup Instructions



All the music you want. All over your house.

1

Set up your Sonos Multi-Room Music System.


Follow the instructions provided with your ZonePlayer(s).

Note: At least one ZonePlayer must be set up before the Sonos Wireless Dock can be added to your music system.

2

Add the Wireless Dock.

Select **Settings > Add a Sonos Component**.



Press and release the **Connect** button.



Note: During setup, you will be prompted to select an **Autoplay** zone. This is the zone that will automatically play audio if you start music directly from an iPod or iPod touch when it is seated in the wireless dock.