

SONY[®]

4-594-376-11(1)

In-car Bluetooth[®] Commander

Operating Instructions **GB**

Mode d'emploi **FR**

Manual de instrucciones **ES**



* 4 5 9 4 3 7 6 1 1 * (1)

RM-X7BT

RM-X7BT
4-594-376-11(1)

Table of Contents

Features	2
Guide to Parts and Controls . . .	3

Connection/Installation

Cautions	5
Parts List for Installation	5
Connection	6
Installation	7

Getting Started

Turning the Power on	9
Setting on the Car Audio Unit	9
Preparing a BLUETOOTH Device	10

Playback

Playing a BLUETOOTH Device	12
--------------------------------------	----

Handsfree via BLUETOOTH

Receiving a Call	13
Using Voice Recognition	14

Additional Information


Troubleshooting	16
---------------------------	----

Features

Bring your smartphone to easily control calls, music and more. This In-car Bluetooth® Commander for Smartphone has Sony's voice technology app activation and an intuitively designed keypad, so you can keep using your Smartphone without ever taking your eyes off the road. All you need to get started is an AUX input and USB power supply.

Guide to Parts and Controls

Adaptor



1 **MODE**

Switches between volume mode and zoom mode.

● **PAIRING**

Press and hold for 2 seconds to set pairing.

Press and hold for 7 seconds to reset pairing history and MODE setting of the adaptor.

2 **ZOOM/VOL (volume) indicator (white)**

Lights up when selecting zoom mode.

Flashes 4 times when completing to reset the adaptor.

3 **Receptor for the remote commander**

4 **LED indicator (blue)**

Flashes quickly in pairing standby mode.

Flashes slowly in BLUETOOTH standby mode.

Stays lit while connected using BLUETOOTH.

5 **MIC (microphone)**

Built-in microphone. It is not available when the external microphone is installed.

6 **AUDIO OUT jack**

Connects to the car audio unit with an AUX cable.


7 **USB port**

Connects to supply power to the adaptor.


8 **MIC-IN (microphone input) jack**

Installs the external microphone.

RM-X7S Remote commander



- 9** **◀▶**
Forward/reverse the track on the music app.
- 10** **N-Mark**
Touch with an Android smartphone to make a BLUETOOTH connection.
- VOICE**
Activate the Assistant for RM-X7BT function (only Android smartphones installed with the app) or the Siri function (iPhone only).
Press and hold for 2 seconds to activate voice dial (Android smartphones only).
- ☎ (call)**
Receive/end a call.
- 11** **▶||**
Play/pause the track on the music app.



- 13** **Ring**
When selecting VOL (volume) on the adaptor, you can adjust the volume on the smartphone.
When selecting ZOOM on the adaptor, you can use the zoom function on the "Waze" app (Android™ smartphone only).
For details, refer to the help of the application.
- 14** **Holder release button**
- 15** **Holder**

4_{GB}

Connection/Installation

Cautions

- It is extremely dangerous if the cord becomes wound around the steering column or gearstick. Be sure to keep it and other parts from interfering with your driving operations.
- Avoid installing the adaptor and remote commander in areas subject to dust, dirt, excessive vibration, or high temperature, such as in direct sunlight, on the dashboard or near heater ducts.
- The adaptor is controlled with infrared rays from the remote commander. The adaptor and remote commander are not connected with BLUETOOTH.
- Do not place obstacles between the adaptor and remote commander because it may interfere with communication with infrared rays.
- Do not cover the emitter on the remote commander with your fingers.
- It is recommended to place the adaptor near the operator as the microphone is installed to the adaptor.
- If your car's ignition has no ACC position, remove the USB cable each time you turn the ignition off to prevent battery drain.

Parts List for Installation

①



②



③



④



⑤




This parts list does not include all the package contents.


5_{GB}

Connection

Connecting to an AUX input jack/USB port in the console box



Connecting to an AUX input jack/USB port under the console panel



Notes


- Connect the adaptor with the AUX cable ① and USB cable ②.
- Install the adaptor to a site where it can receive the IR signal of the remote commander.

6_{GB}


Installation

Installing the lithium battery


- 1 Pull the remote commander while pressing the holder release button on the holder to remove from the holder.



- 2 Open the cover on the bottom of remote commander with a coin, etc.



- 3 Install the supplied lithium battery ③ to the remote commander.



Replacing the lithium battery of the remote commander

Under normal conditions, the battery will last approximately 1 year. (The service life may be shorter, depending on the conditions of use.)

When the battery becomes weak, the range of the remote commander becomes shorter.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replaced only with the same or equivalent type.


Notes on the lithium battery

- Keep the lithium battery out of the reach of children. Should the battery be swallowed, immediately consult a doctor.
- Wipe the battery with a dry cloth to ensure a good contact.
- Be sure to observe the correct polarity when installing the battery.
- Do not hold the battery with metallic tweezers, otherwise a short-circuit may occur.

Installing the remote commander

Before installing


- Make sure that the angle of slant at the holder or the direction of remote commander is suitable for the installation site. There are 4 grooves on the remote commander, and depending on the situation, you can install the remote commander four different ways.




- To prevent making unnecessary hole or attaching tape to an unsuitable site of the car, install the remote commander and adaptor to a site where they can definitely send and receive the IR signal.

- 1 Make a hole with a diameter of 2 mm on the installation site of your car.


- 2 Peel the tape on the bottom of the holder and attach it on the installation site. Fix the hole of the holder on the hole of the car.




- 3 Install the supplied screw ④ to the hole of the holder and secure it to the installation site.




- 4 Set the remote commander with the lithium battery to the holder. Insert the groove of the remote commander in the hook of the holder, and push the remote commander until it clicks.



Installing the adaptor

- 1 Attach the adaptor to the installation site using the supplied double-sided tape .



- 2 Connect the AUX cable and USB cable.

Note

Before attaching the tape, clean each installation site of the adaptor and remote commander with a dry cloth.

Getting Started

Turning the Power on

- 1 Turn the ignition on or set the ignition to ACC.
The adaptor turns on.

To turn the power off


Turn the ignition off.
The adaptor turns off.

Note

If your car's ignition has no ACC position, remove the USB cable each time you turn the ignition off to prevent battery drain.

Setting on the Car Audio Unit

- 1 Switch the source on the car audio unit to the AUX source. When connecting the adaptor to the car audio unit, the sound of the device connected to the adaptor is output from the speaker on the car audio unit.



For details, refer to the operating instructions supplied with the car audio unit.

NFC function, data communication can be achieved easily just by touching the relevant symbol or designated location on NFC compatible devices.

Preparing a BLUETOOTH Device


You can enjoy music, or perform handsfree calling depending on the BLUETOOTH compatible device such as a smartphone, cellular phone and audio device (hereafter "BLUETOOTH device" if not otherwise specified). For details on connecting, refer to the operating instructions supplied with the device.

Before connecting the device, turn down the volume of the car audio unit; otherwise, loud sound may result.

For a smartphone with Android OS 4.0 or lower installed, downloading the app "NFC Easy Connect" available at Google Play™ is required. The app may not be downloadable in some countries/regions.

- 1 Activate the NFC function on the smartphone.**
For details, refer to the operating instructions supplied with the smartphone.
- 2 Touch the N-Mark part of the remote commander with the N-Mark part of the smartphone.**



Make sure that  lights up on the adaptor.

To disconnect by One touch
Touch the N-Mark part of the remote commander with the N-Mark part of the smartphone again.

Connecting with a Smartphone by One touch (NFC)

By touching the N-Mark on the remote commander with an NFC* compatible smartphone, the adaptor is paired and connected with the smartphone automatically.


* NFC (Near Field Communication) is a technology enabling short-range wireless communication between various devices, such as mobile phones and IC tags. Thanks to the

Notes


- When making the connection, handle the smartphone carefully to prevent scratches.
- One touch connection is not possible when the adaptor is already connected to another NFC compatible device. In this case, disconnect the other device, and make connection with the smartphone again.

Pairing and connecting with a BLUETOOTH device


When connecting a BLUETOOTH device for the first time, mutual registration (called "pairing") is required. Pairing enables this adaptor and other devices to recognize each other.

- 1** Place the BLUETOOTH device within 1 m (3 ft) of this adaptor.
- 2** Press and hold PAIRING for 2 seconds.
 flashes quickly while the adaptor is in pairing standby mode.
- 3** Perform pairing on the BLUETOOTH device so it detects this adaptor.
- 4** Select [RM-X7BT] (your model name) shown in the display of the BLUETOOTH device.
 If your model name does not appear, repeat from step 2.

- 5** If passkey input is required on the BLUETOOTH device, input [0000].

When pairing is made,  flashes.

- 6** Select this adaptor on the BLUETOOTH device to establish the BLUETOOTH connection.

 lights up when the connection is made.

Notes

- While connecting to a BLUETOOTH device, this adaptor cannot be detected from another device. To enable detection, enter the pairing mode and search for this adaptor from another device.
- Depending on the status of the BLUETOOTH device, it may not be possible to obtain your model name.

To start playback

For details, see "Playing a BLUETOOTH Device" (page 12).

To cancel pairing

Perform step 2 to cancel the pairing mode after this adaptor and the BLUETOOTH device are paired.

Connecting with a paired BLUETOOTH device

To use a paired device, connection with this adaptor is required. Some paired devices will connect automatically.



Tips

- The adaptor remembers the 5 most recently paired devices.
- If the BLUETOOTH signal on, when the ignition is turned on, this adaptor automatically reconnects to the most recently connected smartphone.

Playback

Playing a BLUETOOTH Device


The adaptor supports various BLUETOOTH audio profiles. You can play contents on a connected device that supports BLUETOOTH A2DP (Advanced Audio Distribution Profile).




Notes



- The adaptor supports the SBC/AAC codec. The codec is automatically switched depending on the connected device.
- The remote commander may not work properly depending on the performance of the connected device or music app.
- As the music app operates with the HID (Human Interface Device Profile), connect a smartphone that supports HID or AVRCP.
- When connecting with HID, the software keyboard on a smartphone does not appear. If you use the software keyboard, deactivate HID on the smartphone.

- 1 Make BLUETOOTH connection with the audio device (page 11).

- 2** Make sure that  stays lit. If a connection has not been established, select [RM-X7BT] on the BLUETOOTH device.

- 3** Press  on the remote commander. Start audio playback with the music app on the connected BLUETOOTH device.

Note

Once the adaptor and the BLUETOOTH device are connected, you can control playback by pressing  and .


Handsfree via BLUETOOTH

You can operate a smartphone handsfree by simply speaking into the built-in microphone or an external microphone installed on the adaptor. Installing the external microphone helps increase voice recognition.

To use a smartphone, connect it with this adaptor. For details, see "Preparing a BLUETOOTH Device" (page 10).



Receiving a Call

- 1** Press  when a call is received with a ringtone. The phone call starts.

Note

The ringtone and talker's voice are output only from the speakers of the car audio unit.


To reject the call

Press and hold  for 2 seconds.

To end the call

Press  again.

To switch between handsfree mode and handheld mode

During a call, press and hold  to switch the phone call audio between the adaptor and smartphone.

Using Voice Recognition

You can control an application by voice command.

Note

For your safety, follow your local traffic laws and regulations, and do not operate the application while driving.

Using Assistant for RM-X7BT with an Android smartphone

By installing Assistant for RM-X7BT, you can use an Android smartphone handsfree by simply speaking into the microphone. For details, refer to the help of the application.

Downloading the app from Google Play is required.

Notes

- The app is an app for controlling Sony audio devices which are compatible with the app, by your Android smartphone.
- What you can control with the app varies depending on the connected device.

- To make use of the app features, see the details on your Android smartphone.
- For further details on the app, visit the following URL:
<http://s-assistant.sony.net/>

- 1 Activate the app function on the Android smartphone.**
- 2 Press VOICE.**
The voice command display appears.
- 3 After the Android smartphone beeps, speak into the microphone.**
The app starts responding.

To deactivate the app

Press VOICE.

Notes

- The Android smartphone may not recognize your voice depending on usage conditions.
- The Android smartphone may not recognize your voice under noisy conditions such as loud sound from the car audio, road noise or air conditioner noise.
- The app may not function properly, or the response time may lag in locations where mobile network signals are difficult to receive.
- If you play a track with an Android smartphone using the BLUETOOTH audio connection, when the track starts playback via BLUETOOTH, the app automatically quits.
- There is no audio sound while the app is activated.

Using Siri Eyes Free

Siri Eyes Free allows you to use an iPhone handsfree by simply speaking into the microphone. You can perform the handsfree registration for an iPhone that supports Siri Eyes Free. Availability is limited iPhone 4s or later. Make sure that your iPhone is running the latest iOS version.

1 Activate the Siri function on the iPhone.

For details, refer to the operating instructions supplied with the iPhone.

2 Press VOICE.

The voice command display appears.

3 After the iPhone beeps, speak into the microphone.

The iPhone beeps again, then Siri starts responding.

To deactivate Siri Eyes Free

Press VOICE.

Notes

- The iPhone may not recognize your voice depending on usage conditions.
- The iPhone may not recognize your voice under noisy conditions such as loud sound from the car audio, road noise or air conditioner noise.
- Siri Eyes Free may not function properly, or the response time may lag in locations where iPhone signals are difficult to receive.

- If you play a track with an iPhone using the BLUETOOTH audio connection, when the track starts playback via BLUETOOTH, Siri Eyes Free automatically quits.
- There is no audio sound while Siri Eyes Free is activated.

Additional Information

Troubleshooting

The following checklist will help you remedy problems you may encounter with your adaptor and remote commander.

Before going through the checklist below, check the connection and operating procedures.

If the problem is not solved, visit the support site on the reference guide (separate document).

General

No sound or the sound is very low.

- The volume of the connected device is very low.
 - Increase the volume of the connected device.
- Check that the adaptor is connected to the car audio unit with the AUX cable.
- Check that the source of the car audio unit is set to the AUX source.

The smartphone does not work.

- Check that the emitter on the remote commander is not covered with your fingers.
- Check that the adaptor is installed to a site where it can receive the IR signal of the remote commander.

- Check that the battery of remote commander becomes full.

NFC function

One touch connection (NFC) is not possible.

- If the smartphone does not respond to the touching.
 - Check that the NFC function of the smartphone is turned on.
 - Move the N-Mark part of the smartphone closer to the N-Mark part on this remote commander.
 - If the smartphone is in a case, remove it.
- NFC receiving sensitivity depends on the device. If One touch connection with the smartphone fails several times, make BLUETOOTH connection manually.

BLUETOOTH function

The connecting device cannot detect this adaptor.

- Before the pairing is made, set this adaptor to pairing standby mode.
- While connected to a BLUETOOTH device, this adaptor cannot be detected from another device.
 - Disconnect the current connection and search for this adaptor from another device.

No ringtone.

- Depending on the connecting device, the ringtone may not be sent properly.

The sound skips during playback of a BLUETOOTH audio device.

- Reduce the distance between the adaptor and the BLUETOOTH audio device.
- If the BLUETOOTH audio device is stored in a case which interrupts the signal, remove the audio device from the case during use.
- Several BLUETOOTH devices or other devices which emit radio waves are in use nearby.
 - Turn off the other devices.
 - Increase the distance from the other devices.
- The playback sound stops momentarily when the connection between this adaptor and the smartphone is being made. This is not a malfunction.








The connected BLUETOOTH audio device cannot be controlled.








- Check that the connected BLUETOOTH audio device supports HID or AVRCP.





A call is answered unintentionally.

- The connecting phone is set to answer a call automatically.

If these solutions do not help improve the situation, consult your nearest Sony dealer.







<http://www.sony.net/>

©2016 Sony Corporation Printed in China

