



Wireless Stereo Headset


Casque stéréo sans fil

Auriculares estéreo inalámbricos


4-540-944-11(1)

Reference Guide	US
Guide de référence	FR
Guía de referencia	ES

Location of the serial number label



To attach the earpads



- 1 Align the projection in the groove on the main part with the notch on the earpad.
- 2 Place your finger at the notch, and then press and move your finger around the skirt of the earpad once to mount the skirt to the groove on the main part.

Note

Be careful not to catch any foreign objects between the main part and the earpad. Keep metal objects away as they may stick to the speakers in the headset.



* 4 5 4 0 9 4 4 1 1 * (1)

MDR-XB950BT

©2014 Sony Corporation Printed in China

<http://www.sony.net/>

English

WARNING

To reduce the risk of electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Information

FOR UNITED STATES CUSTOMERS. NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF QUEBEC.
POUR LES CONSOMMATEURS AUX ÉTATS-UNIS. NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

This equipment must not be co-located or operated in conjunction with any other antenna or transmitter.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption ratio (SAR).

The BLUETOOTH word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.

The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.

Microsoft, Windows and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Mac and Mac OS are trademarks of Apple Inc., registered in the U.S. and other countries.


The aptX® mark and the aptX logo are trade marks of CSR plc or one of its group companies and may be registered in one or more jurisdictions.

Other trademarks and trade names are those of their respective owners.

Precautions

On BLUETOOTH communications

- BLUETOOTH wireless technology operates within a range of about 10 meters (30 feet). Maximum communication range may vary depending on obstacles (human body, metal, wall, etc.) or electromagnetic environment.
- The antenna is built into the unit as illustrated in the dotted line. The sensitivity of the BLUETOOTH communications will improve by turning the direction of the built-in antenna to the connected BLUETOOTH device. When obstacles are between the antenna of the connected device and the built-in antenna of this unit, noise or audio dropout may occur, or communications may be disabled.



- BLUETOOTH communications may be disabled, or noise or audio dropout may occur under the following conditions.

- There is a human body between the unit and the BLUETOOTH device.
This situation may be improved by placing the BLUETOOTH device facing the antenna of the unit.
- There is an obstacle, such as metal or wall, between the unit and the BLUETOOTH device.
- A device using 2.4 GHz frequency, such as a Wi-Fi device, cordless telephone, or microwave oven, is in use near this unit.
- Because BLUETOOTH devices and Wi-Fi (IEEE802.11b/g) use the same frequency (2.4 GHz), microwave interference may occur resulting in noise or audio dropout or communications being disabled if this unit is used near a Wi-Fi device. In such a case, perform the following.
 - Use this unit at least 10 meters (30 feet) away from the Wi-Fi device.
 - If this unit is used within 10 meters (30 feet) of a Wi-Fi device, turn off the Wi-Fi device.
 - Install this unit and the BLUETOOTH device as near to each other as possible.
- Microwaves emitting from a BLUETOOTH device may affect the operation of electronic medical devices. Turn off this unit and other BLUETOOTH devices in the following locations, as it may cause an accident:
 - where inflammable gas is present, in a hospital, train, airplane, or a petrol station
 - near automatic doors or a fire alarm
- This unit supports security capabilities that comply with the BLUETOOTH standard to provide a secure connection when the BLUETOOTH wireless technology is used, but security may not be enough depending on the setting. Be careful when communicating using BLUETOOTH wireless technology.
- We do not take any responsibility for the leakage of information during BLUETOOTH communications.
- Connection with all BLUETOOTH devices cannot be guaranteed.
 - A device featuring BLUETOOTH function is required to conform to the BLUETOOTH standard specified by Bluetooth SIG, Inc. and be authenticated.
 - Even if the connected device conforms to the above mentioned BLUETOOTH standard, some devices may not be connected or work correctly, depending on the features or specifications of the device.
 - While talking on the phone hands free, noise may occur, depending on the device or communication environment.
 - Depending on the device to be connected, it may require some time to start communications.

On charging the unit

- This unit can be charged using USB only. Personal computer with USB port, or USB Charging AC Power Adaptor AC-UD20 (sold separately) is required for charging.
- This unit cannot be turned on, nor can the BLUETOOTH and Electro Bass Booster functions be used, during charging.
- You can use the unit by connecting the supplied stereo mini cable, even while charging the unit.

Note on static electricity


- Static electricity accumulated in the body may cause mild tingling in your ears. To minimize the effect, wear clothes made from natural materials.

If the unit does not operate properly


- Reset the unit.
Set the unit in charging status, then press the POWER and BASS BOOST buttons simultaneously. The unit will be reset. Pairing information is not deleted.
- If the problem persists even after the resetting operation above, initialize the unit as follows.
Turn off the unit by pressing the POWER button for more than 2 seconds. Then, press and hold the POWER button and the button together for more than 7 seconds. The indicator (blue) flashes 4 times, and the unit is reset to the factory settings. All pairing information is deleted.
- Others
 - Do not place this unit in a place exposed to humidity, dust, soot or steam, subject to direct sunlight, or in a car waiting at a traffic signal. It may cause a malfunction.
 - Using the BLUETOOTH device may not function on mobile phones, depending on radio wave conditions and location where the equipment is being used.
 - If you experience discomfort after using the BLUETOOTH device, stop using the BLUETOOTH device immediately. Should any problem persist, consult your nearest Sony dealer.
 - Listening with this unit at high volume may affect your hearing. For traffic safety, do not use this unit while driving or cycling.
 - Do not put weight or pressure on this unit as it may cause the unit to deform during long storage.
 - Do not subject the unit to excessive shock.
 - Clean the unit with a soft dry cloth.
 - Do not expose the unit to water. The unit is not waterproof. Remember to follow the precautions below.
 - Be careful not to drop the unit into a sink or other container filled with water.
 - Do not use the unit in humid locations or bad weather, such as in the rain or snow.
 - Do not get the unit wet.
 - If you touch the unit with wet hands, or put the unit in a damp article of clothing, the unit may get wet and this may cause a malfunction of the unit.
 - The earpads may deteriorate due to long-term storage or use.
 - If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

Optional replacement ear cushions can be ordered from your nearest Sony dealer.

Location of the serial number label



To attach the earpads



- 1 Align the projection in the groove on the main part with the notch on the earpad.
- 2 Place your finger at the notch, and then press and move your finger around the skirt of the earpad once to mount the skirt to the groove on the main part.

Note

Be careful not to catch any foreign objects between the main part and the earpad. Keep metal objects away as they may stick to the speakers in the headset.

Specifications

General

Communication system: BLUETOOTH Specification version 3.0
Output: BLUETOOTH Specification Power Class 2
Maximum communication range: Line of sight approx. 10 m (30 ft)¹⁾

Frequency band: 2.4 GHz band (2.4000 GHz - 2.4835 GHz)

Modulation method: FHSS

Compatible BLUETOOTH profiles²⁾:

A2DP (Advanced Audio Distribution Profile)

AVRCP (Audio Video Remote Control Profile)

HFP (Hands-free Profile)

HSP (Headset Profile)

Supported Codec³⁾: SBC⁴⁾, AAC⁵⁾, aptX⁶⁾

Supported content protection method: SCMS-T

Transmission range (A2DP): 20 Hz - 20,000 Hz (Sampling frequency 44.1 kHz)

Included items:

Wireless stereo headset (1)

Micro-USB cable (approx. 50 cm (19 3/4 in.)) (1)

Stereo mini cable (approx. 1.2 m (47 1/4 in.)) (1)

Reference Guide (this sheet) (1)

Quick Start Guide (1)

Other documents (1 set)

Recommended accessory:

USB Charging AC Power Adaptor: AC-UD20 (sold separately)

¹⁾ The actual range will vary depending on factors such as obstacles between devices, magnetic fields around a microwave oven, static electricity, reception sensitivity, antenna's performance, operating system, software application, etc.

²⁾ BLUETOOTH standard profiles indicate the purpose of BLUETOOTH communications between devices.

³⁾ Codec: Audio signal compression and conversion format

⁴⁾ Subband Codec

⁵⁾ Advanced Audio Coding

Wireless Stereo Headset

Power source:

DC 3.7 V: Built-in lithium-ion rechargeable battery

DC 5 V: When charged using USB

Mass: Approx. 280 g (10 oz)

Operating temperature: 0 °C to 40 °C (32 °F to 104 °F)

Rated power consumption: 1.5 W

Usage hours:

When connecting via the BLUETOOTH device

Music playback time: Max. 20 hours

Communication time: Max. 20 hours

Standby time: Max. 200 hours

About 7 hours of continuous communications is possible after 1 hour charging.

Note: Usage hours may be shorter depending on the Codec and the conditions of use.

Charging time:

Approx. 4 hours

Charging temperature: 5 °C to 35 °C (41 °F to 95 °F)

Receiver

Type: Closed, Dynamic

Driver units: 40 mm

Frequency response: 3 Hz - 20,000 Hz (when using the supplied stereo mini cable)

Maximum input: 1,000 mW [IEC*] (when using the supplied stereo mini cable)

* IEC = International Electrotechnical Commission

Impedance:

24 Ω (1 kHz) (when using the supplied stereo mini cable)

Sensitivity:

106 dB/mW (when using the supplied stereo mini cable)

Microphone

Type: Electret condenser

Directivity: Omni directional

Effective frequency range: 100 Hz - 4,000 Hz

System requirements for battery charge using USB

Personal Computer with pre-installed with any of the following operating systems and USB port:

Operating Systems

(when using Windows)

Windows® 8 / Windows® 8.1 Pro

Windows® 8 / Windows® 8 Pro

Windows® 7

Home Basic / Home Premium / Professional / Ultimate

Windows Vista® (Service Pack 2 or later)


Home Basic / Home Premium / Business / Ultimate

(when using Mac


- Vous risquez de subir des lésions auditives si vous utilisez cet appareil à un volume élevé. Pour des raisons de sécurité, n'utilisez pas cet appareil en voiture ou à vélo.
- N'appliquez pas un poids excessif et n'exercez pas de pression sur l'appareil, car cela pourrait le déformer en cas de stockage prolongé.
- Ne soumettez pas l'appareil à un choc excessif.
- Nettoyez l'appareil avec un chiffon doux et sec.
- N'exposez pas l'appareil à l'eau. L'appareil n'est pas résistant à l'eau.
- Veillez à respecter les précautions suivantes.
 - Veillez à ne pas laisser tomber l'appareil dans un évier ou tout autre récipient rempli d'eau.
 - N'utilisez pas l'appareil dans des endroits humides ou dans de mauvaises conditions climatiques (pluie ou neige).
 - L'appareil ne doit pas être mouillé.
 - Si vous touchez l'appareil avec des mains mouillées ou si vous le glissez dans un vêtement mouillé, de l'eau risque de pénétrer à l'intérieur et de provoquer un dysfonctionnement de l'appareil.
- Les oreillettes peuvent se détériorer en raison d'un stockage ou d'une utilisation prolongée(e).
- En cas de questions ou de problèmes concernant cet appareil qui ne sont pas abordés dans ce mode d'emploi, contactez votre revendeur Sony le plus proche.

Il est possible de commander des coussinets de remplacement auprès de votre revendeur Sony le plus proche.

Emplacement de l'étiquette comportant le numéro de série



Pour fixer les oreillettes



- 1 Alignez la partie saillante dans la rainure sur la partie principale avec l'encoche sur l'oreille.
- 2 Placez votre doigt au niveau de l'encoche, puis faites glisser votre doigt autour de la juge de l'oreille pour fixer la juge sur la rainure sur la partie principale.

Remarque

Faites attention à ne pas coincer d'objets étrangers entre la partie principale et l'oreille. Eloignez les objets métalliques car ils peuvent se coller aux haut-parleurs dans le casque.

Spécifications

Généralités

Système de communication : Spécification BLUETOOTH version 3.0

Portée : Spécification BLUETOOTH Power Class 2

Portée maximale des communications : Environ 10 m (30 pi) en ligne directe¹

Bande de fréquence :

Bande 2,4 GHz (2,4000 GHz - 2,4835 GHz)

Méthode de modulation : FHSS

Profils BLUETOOTH compatibles² :

A2DP (Advanced Audio Distribution Profile)

AVRCP (Audio Video Remote Control Profile)

HFP (Hands-free Profile)

HSP (Headset Profile)

Codec pris en charge³ : SBC⁴, AAC⁵, aptX

Méthode de protection du contenu pris en charge : SCMS-T

Plage de transmission (A2DP) : 20 Hz - 20 000 Hz (fréquence d'échantillonage 44,1 kHz)

Articles inclus :

Casque stéréo sans fil (1)

Câble micro-USB (environ 50 cm (19 3/4 po)) (1)

Mini-câble stéréo (environ 1,2 m (47 1/4 po)) (1)

Guide de référence (ce manuel) (1)

Guide de prise en main (1)

Autres documents (1 ensemble)

Accessoire recommandé :

Adaptateur CA de charge USB : AC-UD20 (vendu séparément)

¹ La portée réelle varie en fonction de nombreux facteurs, tels que la présence d'obstacles entre les périphériques, les champs magnétiques autour des fours à micro-ondes, l'électricité statique, la sensibilité de la réception, les performances de l'antenne, le système d'exploitation, les applications logicielles, etc.

² Les profils standard BLUETOOTH sont destinés aux communications BLUETOOTH entre périphériques.

³ Codec : format de conversion et compression du signal audio

⁴ Codec de sous-bande

⁵ Encodage audio avancé

Casque stéréo sans fil

Source d'alimentation :

3,7 V CC : Batterie rechargeable lithium-ion intégrée

5 V CC : Chargement sur port USB

Masse : Environ 280 g (10 oz)

Température de fonctionnement : 0 °C à 40 °C (32 °F à 104 °F)

Consommation à puissance nominale : 1,5 W

Durée d'utilisation :

Dans le cas d'une connexion via l'appareil BLUETOOTH

Durée de la lecture de musique : 20 heures max.

Durée de communication : 20 heures max.

Durée de veille : 200 heures max.

Une communication continue d'environ 7 heures est possible après 1 heure de charge.

Remarque : Les heures d'utilisation peuvent être plus courtes en fonction du codec et des conditions d'utilisation.

Durée de charge :

Environ 4 heures

Température de charge : 5 °C à 35 °C (41 °F à 95 °F)

Récepteur

Type : Fermé, dynamique

Transducteur : 40 mm

Réponse en fréquence : 3 Hz - 28 000 Hz (utilisé avec le mini-câble stéréo fourni)

*CEI = Commission Électrotechnique Internationale

Impédance :

24 Ω (1 kHz) (utilisé avec le mini-câble stéréo fourni)

Sensibilité :

106 dB/mW (utilisé avec le mini-câble stéréo fourni)

Micro

Type : Condensateur à électret

Directivité : Omnidirectionnel

Plage de fréquences efficace : 100 Hz - 4 000 Hz

Configuration requise pour la mise en charge de la batterie via une connexion USB

Ordinateur personnel doté de l'un des systèmes d'exploitation ci-dessous et équipé d'un port USB :

Systèmes d'exploitation (sous Windows)

Windows® 8.1 / Windows® 8.1 Pro

Windows® 8 / Windows® 8 Pro

Windows® 7

Home Basic / Home Premium / Professional / Ultimate

Windows Vista® (Service Pack 2 ou ultérieur)

Home Basic / Home Premium / Business / Ultimate

(sous Mac)

Mac OS X (version 10.3 ou ultérieure)

La conception et les spécifications sont sujettes à modification sans préavis.

Español

ADVERTENCIA

Para evitar descargas eléctricas, no abra la unidad. En caso de avería, solicite los servicios de personal cualificado.

No sitúe el aparato en un espacio cerrado, como una estantería o un armario empotrado.

No exponga las pilas (la batería o las pilas instaladas) a fuentes de calor excesivo como luz solar, fuego o similares durante un período prolongado.

La marca denominativa BLUETOOTH y sus logotipos son propiedad de Bluetooth SIG, Inc. y Sony Corporation los utiliza bajo licencia.

N Mark es una marca comercial o una marca comercial registrada de NFC Forum, Inc. en los Estados Unidos y en otros países.

Microsoft, Windows y Windows Vista son marcas comerciales registradas o marcas comerciales de Microsoft Corporation en Estados Unidos y en otros países.

Mac y Mac OS son marcas registradas de Apple Inc., registradas en Estados Unidos y otros países.


La marca aptX® y el logotipo de aptX son marcas comerciales de CSR plc o las empresas de su grupo y pueden estar registradas en una jurisdicción o varias.

Las demás marcas y nombres comerciales pertenecen a sus respectivos propietarios.

Precauciones

Comunicaciones BLUETOOTH

- La tecnología inalámbrica BLUETOOTH opera en un rango de 10 metros aproximadamente. El rango máximo de comunicación puede variar dependiendo de los obstáculos (personas, metales, paredes, etc.) o entornos electromagnéticos.
- La antena está incorporada en la unidad como se muestra con la linea punteada. La sensibilidad de las comunicaciones BLUETOOTH mejorará si gira la dirección de la antena incorporada hacia el dispositivo BLUETOOTH conectado. Si existen obstáculos entre la antena del dispositivo conectado y la antena incorporada de esta unidad, es posible que se produzcan ruidos o pérdidas de señal de audio, o que se interrumpan las comunicaciones.



- Es posible que se interrumpan las comunicaciones BLUETOOTH o que se produzcan ruidos o pérdidas de señal de audio en los siguientes casos.

- La existencia de una persona entre la unidad y el dispositivo BLUETOOTH.

Esta situación se puede mejorar al colocar el dispositivo BLUETOOTH frente a la antena de la unidad.

- La existencia de obstáculos, como un objeto metálico o una pared, entre la unidad y el dispositivo BLUETOOTH.

- El uso de dispositivos que utilizan una frecuencia de 2,4 GHz como, por ejemplo, un dispositivo Wi-Fi, un teléfono inalámbrico o un microondas, cerca de la unidad.

• Dado que los dispositivos BLUETOOTH y Wi-Fi (IEEE802.11b/g) utilizan la misma frecuencia (2,4 GHz), pueden producirse interferencias de microondas que produzcan ruidos o pérdidas de señal de audio o la interrupción de las comunicaciones al utilizar esta unidad cerca de un dispositivo Wi-Fi. En este caso, realice el procedimiento siguiente.

- Utilice esta unidad a una distancia mínima de 10 metros del dispositivo Wi-Fi.

- Si utiliza esta unidad a menos de 10 metros de un dispositivo Wi-Fi, apague dicho dispositivo.

- Instale esta unidad y el dispositivo BLUETOOTH a la distancia más corta posible entre sí.

• Las microondas que emite un dispositivo BLUETOOTH pueden afectar el funcionamiento de dispositivos médicos electrónicos. Apague esta unidad y los demás dispositivos BLUETOOTH en los siguientes lugares, ya que podrían provocar un accidente:

- donde existe gas inflamable, en un hospital, tren, avión o gasolinera

- cerca de puertas automáticas o alarmas de incendios

• Esta unidad admite capacidades de seguridad que cumplen con el estándar BLUETOOTH para proporcionar una conexión segura al utilizar la tecnología inalámbrica BLUETOOTH, pero es posible que la seguridad no sea suficiente según la configuración. Tenga cuidado al realizar una comunicación con la tecnología inalámbrica BLUETOOTH.

• No aceptan responsabilidades por la fuga de información que pudiera producirse durante comunicaciones BLUETOOTH.

• No se puede garantizar la conexión con todos los dispositivos BLUETOOTH.

- Un dispositivo que disponga de la función BLUETOOTH debe cumplir el estándar BLUETOOTH especificado por Bluetooth SIG, Inc. y estar autenticado.

- Incluso en el caso de que el dispositivo conectado cumpla el estándar BLUETOOTH mencionado anteriormente, es posible que algunos dispositivos no puedan conectarse o funcionar correctamente, según las características o las especificaciones del dispositivo.

- Mientras esté hablando con los manos libres del teléfono, es posible que se produzca ruido en función del dispositivo o del entorno de comunicación.

• En función del dispositivo que vaya a conectarse, es posible que transcurra cierto tiempo antes de que se inicien las comunicaciones.

Para cargar la unidad

• Esta unidad sólo se puede cargar usando un puerto USB. Se necesita una computadora personal con puerto USB o un adaptador AC-UD20 (se vende por separado) de alimentación de CA de carga mediante USB.

• No es posible encender la unidad ni las funciones BLUETOOTH y Reforzador de bajos electrónico durante la carga.

• Es posible utilizar la unidad al conectar el minicable estéreo proporcionado, incluso durante la carga de la unidad.

Nota sobre la electricidad estática

• La electricidad estática acumulada en el cuerpo puede causar un leve hormigueo en sus oídos. El efecto puede minimizarse al usar ropa hecha de fibras naturales.

Si la unidad no funciona correctamente

- Reinicie la unidad.

Coloque la unidad en estado de carga y pulse los botones POWER y BASS BOOST al mismo tiempo. Entonces, la unidad se reiniciará. La información de emparejamiento no se elimina.



• Si el problema persiste tras reiniciarla de la forma indicada anteriormente, inicie la unidad de la siguiente manera. Apague la unidad al pulsar el botón POWER durante más de 2 segundos. Luego, mantenga presionados los botones POWER y BASS BOOST al mismo tiempo durante más de 7 segundos. El indicador (azul) parpadea 4 veces y la unidad se reinicia con la configuración de fábrica. Toda la información de emparejamiento se elimina.

Otros

- No coloque esta unidad en lugares expuestos a humedad, polvo, hollín, vapor o la luz solar directa, ni la deje en un automóvil en espera ante una señal de tráfico. Se pueden producir fallas de funcionamiento.

• Es posible que el dispositivo BLUETOOTH no funcione en teléfonos celulares dependiendo del estado de las ondas de radio y del lugar donde se utilice el equipo.

• Si siente algún malestar después de utilizar el dispositivo BLUETOOTH, deje de utilizarlo inmediatamente. Si el problema persiste, consulte con el distribuidor Sony más cercano.

• Si usa la unidad a un volumen alto, puede sufrir daños en los oídos. Por razones de seguridad vial, no la utilice mientras conduce o va en bicicleta.