
### **Device basics**



- 1 Charging/Notification light
- 2 Nano SIM/Memory card slot
- 3 NFC
- 4 Volume/Zoom key
- 5 Fingerprint sensor
- 6 Power key
- 7 Wireless charging coil
- 8 Camera key
- 9 USB port/Charger/Audio adapter

# To insert a nano SIM card and a memory card



- Do not cut your SIM card, as this may damage your device.
- 1 Drag out the SIM card tray.
- 2 Place the SIM card securely in the SIM card tray, as shown in the illustration.
- 3 Place the memory card securely in the tray, in the correct orientation as shown in the illustration.
- 4 Gently push the SIM card tray back into the slot until it fits into place.

### To turn on your device

- It is recommended to charge the battery for at least 30 minutes before you turn on your device for the first time. It is important to use the USB Type-C™ cable provided when charging your device, as other types of USB cables can damage your device.
- 1 Press and hold down the power key until the device vibrates
- 2 Wait a moment for the device to start.

#### To activate the screen

• Briefly press the power key.

## Screen protection

Before using your device, remove all protection films to
 enable full functionality.

Screen covers and protectors may help you protect your device against damage. We recommend you use only those screen covers intended for your Xperia™ device. The use of third party screen protection accessories may prevent your device from working correctly by covering sensors, lenses, speakers, or microphones and can invalidate the warranty.

## Support for you

Use the Support app to find your device's model name, software information, help topics and support tools. Visit support.sonymobile.com from the Support app or any browser for user guides, troubleshooting tips, support forum and support contact information.

 You can find support contact information in the Support app even without a network connection. The Support app is not available in all countries and regions.

## To access the Support app

Find and tap ?.

## Warranty, SAR and usage guidelines

For information about warranty, SAR (Specific Absorption Rate) and safety guidelines, please read the Important information provided under Settings > System > About phone > Legal information on your device.

## Transferring contacts and content

For transferring contacts, messages, photos or other data from an old device to your new device, we recommend that you use the Xperia Transfer application.

Visit https://www.sonymobile.com/xperiatransfer for more information

### To view the CE marking and the FCC ID



- 1 Drag out the SIM card tray.
- 2 Drag out the label strip in the same way.
- To see the full text of the EU declaration of conformity, visit: http://www.compliance.sony.de/

# To view the regulatory compliance

• Open the phone dialer, then enter \*#07#.

#### Legal information

Publication number: XXXX-XXXX.1

This Startup guide is published by Sony Mabile Communications Inc. or its local affiliated company, This Startup guide is published by Sony Mabile Communications Inc. or its local affiliated or propagation and errors, inaccuracies of current information, or improvements to programs and/or equipment, may be and be yony Mobile Communications Inc. at any time and without notice. Such changes will, however be incorporated into new editions of this Startup guide. All illustrations are for illustration only and may not accurately depict the actual device.

See regulatory information such as the device CE marking in the relevant label tray in the device

See regulatory initionisations such as the curve Extination; in the necessity in a deed any in the universe of the frespective owners. Any rights not expressly granted herein are reserved.

Visitings: //www.sorymobile.com/global-en/legal/\* for more information.

Manufacturer: Sory Mobile Communications Inc., 4-12-3 Higashi-Shinagawa, Shinagawa-ku, Tokyo, 140-0002 Japan For EU product compliance: Sony Belgium, bikantoor van Sony Europe Limited, Da Vindiana P.D. (1995 Exentem, Belgium).

#### Supported frequency bands

Some frequency bands might be turned off in certain markets or by certain operators.

You can find your model number under Settings > System > About phone. H8116

UMTS HSPA+ (Bands 1, 2, 4, 5, 6, 8, 19) GSM GPRS/EDGE 850, 900, 1800, 1900 LTE (Bands 1, 2, 3, 4, 5, 7, 8, 12, 13, 17, 19, 20, 26, 28, 29, 32, 38, 39, 40, 41, 46, 66) WLAN, 2.4G/SG, NFC

GSM 850/900 : Power Class 4, DCS(1800)/PCS(1900) : Power Class 1, UMTS : Power LTE : Power Class 3, 2.4GHz<100mW, 5.15-5.35GHz<200mW, 5.47-5.725GHz<200mW 5.735-5.835GHz<25mW, NFC 13.56MHz

# SONY

Startup guide

Xperia XZ2 Premium H8116

XPERIA C€