







English



Introduction	4
Getting started	8
Listening to music	10
Calling functions	13
Troubleshooting	14

Sony Ericsson HBH-DS970

This manual is published by Sony Ericsson Mobile Communications AB, without any warranty. Improvements and changes to this manual necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this manual. All rights reserved.

©Sony Ericsson Mobile Communications AB. 2006

Publication number: LZT 108 8379/X P1C

Some of the services in this manual are not supported by all networks. This also applies to the GSM International Emergency Number 112. Contact your network operator or service provider if you are in doubt whether you can use a particular service or not. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Ericsson is under license





This product is leadfree and halogenfree.


















The Stereo Bluetooth™ Headset HBH-DS970 lets you stay in control of your incoming and outgoing phone calls. You can enjoy stereo audio from a phone or other Bluetooth device, such as a computer or a portable music player. When you receive or make a call, the music automatically pauses and starts playing again when the call ends

Your phone or other device should support the following Bluetooth profiles: Bluetooth Handsfree or Bluetooth Headset

- Bluetooth Advanced Audio Distribution
- Bluetooth Audio/Video Remote Control profile.
































Display illiorillation	
Battery status. Animated when charging.	
The headset is on.	
The headset is prepared to be added to a phone.	
The headset is prepared to be added to a phone or other device.	
The headset is successfully added to a phone or other device.	
Incoming call.	
Outgoing call.	
Ongoing call.	
Singlepoint mode – the headset can only connect to one phone.	
Multipoint mode – the headset can connect to several devices.	
Voice control is activated.	
The microphone is muted.	
Connecting to a phone or other device.	
Music mode.	
Adjusting the ringtone volume.	
Adjusting the call volume.	
Adjusting the music volume.	


















First time use: Charge approximately 8 hours before using the headset.

Adding the headset to the phone

Before you can use the headset with your phone it has to be added once to the phone. Follow the instructions from the phone user guide on how to turn on Bluetooth in your phone.

To add the headset to the phone

- **1** Turn on Bluetooth in your phone.
- 2 Turn on Bluetooth visibility in your phone, and keep it close to the headset (20 cm).

















3 Select singlepoint mode and make sure the headset is off

- 4 Press and hold the on/off button for 2 seconds. You hear a signal and the Sony Ericsson logo is displayed briefly. The display shows when the headset is prepared to be added to the phone. If not, make sure the headset is off, and press and hold the on/off button for 5 seconds. You hear a long beep after the first signal.
- 5 If your phone supports auto pairing, press YES when Add device? appears in your phone to complete the procedure. If not, continue with the next step.

6 Prepare your phone according to the phone user

guide on how to add a Bluetooth device. Please note that for some phones you may need to enter a passcode. The headset passcode is 0000.

Note: For Bluetooth communication, we recommend a maximum distance of 10 metres, with no solid objects in between.

To turn the headset on or off


Press and hold the on/off button for 2 seconds. You hear a signal. The Sony Ericsson logo is displayed briefly.

To turn on the backlight

Press any button. The backlight turns off automatically.














- Make sure the headset is off, and press and hold the on/off button for 5 seconds. You hear a long beep after the first signal. The headset is prepared to be added.
 - 2 Press and hold the on/off button and the call handling button simultaneously for 5 seconds. The headset is turned off.

Listening to music



Before you can listen to music, the headset has to be added once to your phone, see instructions on page 8.
















To play a music track

- Start the media player in your phone, and select to use the headset
- 2 Press the music button. The headset connects to your phone, and the music starts playing.
- 3 To pause the music or start playing again, press the music button

To stop the music

- Press and hold the music button. The music stops.
- 2 To start the music again, press the music button. The headset connects to your phone, and the music starts playing.

To skip to another music track Select Next or Previous.

To adjust the music volume

When you listen to music, press the volume button up or down

Using another device as a music source

In singlepoint mode, the headset is connected only to your phone. In multipoint mode, you can use the headset together with your phone and one of your other Bluetooth devices, where music is saved.

Before you can listen to music from another device, the headset has to be added once to the device. The headset can be added to up to 10 devices. When you

















press the music button, the headset connects to the most recently used device.

To add the headset to another device





- 2 Turn on Bluetooth visibility in your device, and keep it close to the headset (20 cm).
- 3 Select multipoint mode and make sure the headset is off
- 4 Press and hold the on/off button for 5 seconds. You hear a long beep after the first signal. The headset is prepared to be added.













12





Calling functions

passcode is 0000.

Your phone uses the headset for calls, even if you are listening to music from another device in multipoint mode.

To answer a call

Press the call handling button. The music pauses during the call.

To reject a call

Press and hold the call handling button for 2 seconds.

To end a call

Press the call handling button. The display shows the duration of the call. The music starts playing again.

To make a call using voice commands

- 1 Press the call handling button and the music is muted
- 2 Say the name you want to call.

To be able to use this function, you first have to activate voice control in your phone and record voice commands. For more information on voice commands, and if your phone supports it, refer to the phone user guide.






13







During an ongoing call in your phone, press the call handling button on the headset. To transfer from headset to phone, refer to the phone user guide.

To switch between two calls

Press and hold the call handling button for 2 seconds.

To redial the last dialled number

Press the call handling button quickly twice.

To turn the microphone on or off (mute) During a call, press both volume buttons.

To adjust the ringtone volume

When you have no ongoing call or music playing, press the volume button up or down.

To adjust the speaker volume for calls During a call, press the volume button up or down.

Troubleshooting

No connection to phone or other device

- Before vou can use your Stereo Bluetooth Headset with your phone or other device it has to be added once according to page 8.
- It is recommended to first add the headset to your phone, in singlepoint mode. Select singlepoint mode and add the headset to the phone again. In multipoint mode, the phone or other device that first adds the headset will be used for phone calls.















- Make sure the headset is charged and within range of the phone or other device. We recommend a maximum distance of 10 metres, with no solid objects in between.
- Check or redo the Bluetooth settings in the phone or other device. For more information on Bluetooth and pairing, go to www.sonvericsson.com/ learnabout

Redial does not work

If the call list in the phone is empty you cannot use the redial function

The headset does not connect to my music source Make sure your device is available, and supports

- Bluetooth Advanced Audio Distribution profile. The headset tries to connect to the most recent device used as a music source. You may have to restart the media player in your device.
- Check the setting of the singlepoint/multipoint mode selection button

The remote control functions do not work Make sure your device supports Bluetooth Audio/Video Remote Control profile.

The headset is switched off automatically

- The battery is too low. You hear a low beep.
- When you are adding the headset, it switches off if you do not add it to the phone within 10 minutes.































We. Sonv Ericsson Mobile Communications AB of Nva Vattentornet 221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type DDA-0002005

to which this declaration relates is in conformity with the appropriate standards EN 300 328, EN 301 489-17. EN 301 489-7 and EN 60950 following the provisions of Radio Equipment and Telecommunication Equipment directive 1999/5/EC with requirements covering EMC directive 89/336/EEC and Low Voltage directive

73/23/EEC

Lund, March 2006



C€ 0682

Ulf Persson, Head of Product Business Unit Accessories We fulfill the R&TTF Directive

We fulfill the R&TTE Directive.

We fulfill the R&TTF Directive We fulfill the R&TTF Directive























This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.







18














정보통신기기인증에 대한 사항



당해 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스를 할 수 없습니다.

ABOUT MIC APPROVAL



Manufacturer/Nation: Sonv Ericsson Corp. / China This radio equipment can not be used for health care related services due to possibility of crossing.

www.sonvericsson.com



Sony Ericsson

Sony Ericsson Mobile Communications AB SE-221 88 Lund, Sweden



LZT 108 8379/X P1C











