



Stereo Bluetooth™ Headset
HBH-DS200/HBH-DS220

English
Language
Language
Language

Sony Ericsson

Stereo Bluetooth™ Headset



2

HBH-DS200/HBH-DS220

User Guide

User Guide

User Guide

User Guide

Sony Ericsson HBH-DS200/HBH-DS220

This User guide is published by Sony Ericsson Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB or its affiliated company at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide. All rights reserved.

©Sony Ericsson Mobile Communications AB, 2007

Publication number: LZT 108 9327/x PA13

Some of the services in this User guide are not supported by all networks. This also applies to the GSM International Emergency Number 112. Contact your network operator or service provider if you are in doubt whether you can use a particular service.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Ericsson is under license.



This product is leadfree and halogenfree.

The Stereo Bluetooth™ Headset HBH-DS200/HBH-DS220 lets you stay in control of your incoming and outgoing phone calls. You can enjoy stereo audio from a phone or other Bluetooth device, such as a computer or a portable music player. During calls, the music automatically pauses and starts playing again when the call ends.

For full functionality, your phone or other device should support the following Bluetooth profiles:

- Bluetooth Handsfree.
- Bluetooth Headset.
- Bluetooth Advanced Audio Distribution.
- Bluetooth Audio/Video Remote Control.

Safe and efficient use

See the Bluetooth Handsfree Important Information guide for more information about safe and efficient use.

The Stereo Bluetooth™ Headset HBH-DS200/ HBH-DS220 lets you stay in control of your incoming and outgoing phone calls. You can enjoy stereo audio from a phone or other Bluetooth device, such as a computer or a portable music player. During calls, the music automatically pauses and starts playing again when the call ends.

For full functionality, your phone or other device should support the following Bluetooth profiles:

- Bluetooth Handsfree.
- Bluetooth Headset.
- Bluetooth Advanced Audio Distribution.
- Bluetooth Audio/Video Remote Control.

Safe and efficient use

See the Bluetooth Handsfree Important Information guide for more information about safe and efficient use.

The Stereo Bluetooth™ Headset HBH-DS200/ HBH-DS220 lets you stay in control of your incoming and outgoing phone calls. You can enjoy stereo audio from a phone or other Bluetooth device, such as a computer or a portable music player. During calls, the music automatically pauses and starts playing again when the call ends.

For full functionality, your phone or other device should support the following Bluetooth profiles:

- Bluetooth Handsfree.
- Bluetooth Headset.
- Bluetooth Advanced Audio Distribution.
- Bluetooth Audio/Video Remote Control.

Safe and efficient use

See the Bluetooth Handsfree Important Information guide for more information about safe and efficient use.

The Stereo Bluetooth™ Headset HBH-DS200/ HBH-DS220 lets you stay in control of your incoming and outgoing phone calls. You can enjoy stereo audio from a phone or other Bluetooth device, such as a computer or a portable music player. During calls, the music automatically pauses and starts playing again when the call ends.


For full functionality, your phone or other device should support the following Bluetooth profiles:

- Bluetooth Handsfree.
- Bluetooth Headset.
- Bluetooth Advanced Audio Distribution.
- Bluetooth Audio/Video Remote Control.

Safe and efficient use

See the Bluetooth Handsfree Important Information guide for more information about safe and efficient use.

Overview
Overview
Overview
Overview



Display information

Display information

Display information

Display information



Power icon. Headset is on.
Power icon. Headset is on.
Power icon. Headset is on.
Power icon. Headset is on.



Pairing icon. Flashing. Prepared to be paired.
Pairing icon. Flashing. Prepared to be paired.
Pairing icon. Flashing. Prepared to be paired.
Pairing icon. Flashing. Prepared to be paired.



Battery status. Animated when charging.
Battery status. Animated when charging.
Battery status. Animated when charging.
Battery status. Animated when charging.



Full.
Full.
Full.
Full.



Medium.
Medium.
Medium.
Medium.




Low.
Low.
Low.
Low.


Getting started
Getting started
Getting started
Getting started


Compatible chargers
Compatible chargers
Compatible chargers
Compatible chargers

- **First time use:** Charge approximately 8 hours.
- **First time use:** Charge approximately 8 hours.
- **First time use:** Charge approximately 8 hours.
- **First time use:** Charge approximately 8 hours.



To charge the headset
To charge the headset
To charge the headset
To charge the headset









To turn the headset on

To turn the headset on

To turn the headset on

To turn the headset on





- Press and hold down the on/off key until the power icon  appears on the display.
- Press and hold down the on/off key until the power icon  appears on the display.
- Press and hold down the on/off key until the power icon  appears on the display.
- Press and hold down the on/off key until the power icon  appears on the display.

To turn the headset off

To turn the headset off

To turn the headset off


To turn the headset off

- Press and hold down the on/off key until the power icon  disappears.
- Press and hold down the on/off key until the power icon  disappears.
- Press and hold down the on/off key until the power icon  disappears.
- Press and hold down the on/off key until the power icon  disappears.

To pair the headset with a phone or a device
To pair the headset with a phone or a device
To pair the headset with a phone or a device
To pair the headset with a phone or a device


Before using your headset with a phone or another device it has to be paired once. Follow the Bluetooth instructions in the phone or device User guide.

Note: *Only one phone or device can be paired at a time.*

- 1. Phone or device:** Turn on Bluetooth and Bluetooth visibility. Keep it close to the headset (20 cm).
- 2. Headset:** Switch it off. Press and hold down the on/off key until the pairing icon  appears on the display.
- 3. Phone:** If your phone supports auto pairing, press YES when Add device? appears to complete the procedure. If not, continue with the next step.
- 4. Phone or device:** Follow the applicable User guide to pair with a Bluetooth headset. You may need to enter a headset passcode (0000).


Before using your headset with a phone or another device it has to be paired once. Follow the Bluetooth instructions in the phone or device User guide.

Note: *Only one phone or device can be paired at a time.* 14

- 1. Phone or device:** Turn on Bluetooth and Bluetooth visibility. Keep it close to the headset (20 cm).
- 2. Headset:** Switch it off. Press and hold down the on/off key until the pairing icon  appears on the display.
- 3. Phone:** If your phone supports auto pairing, press YES when Add device? appears to complete the procedure. If not, continue with the next step.
- 4. Phone or device:** Follow the applicable User guide to pair with a Bluetooth headset. You may need to enter a headset passcode (0000).

Before using your headset with a phone or another device it has to be paired once. Follow the Bluetooth instructions in the phone or device User guide.

Note: *Only one phone or device can be paired at a time.*

- 1. Phone or device:** Turn on Bluetooth and Bluetooth visibility. Keep it close to the headset (20 cm).
- 2. Headset:** Switch it off. Press and hold down the on/off key until the pairing icon  appears on the display.


3. Phone: If your phone supports auto pairing, press YES when Add device? appears to complete the procedure. If not, continue with the next step. 15

4. Phone or device: Follow the applicable User guide to pair with a Bluetooth headset. You may need to enter a headset passcode (0000).

Before using your headset with a phone or another device it has to be paired once. Follow the Bluetooth instructions in the phone or device User guide.

Note: *Only one phone or device can be paired at a time.*

1. Phone or device: Turn on Bluetooth and Bluetooth visibility. Keep it close to the headset (20 cm).

2. Headset: Switch it off. Press and hold down the on/off key until the pairing icon  appears on the display.

3. Phone: If your phone supports auto pairing, press YES when Add device? appears to complete the procedure. If not, continue with the next step.

4. Phone or device: Follow the applicable User guide to pair with a Bluetooth headset. You may need to enter a headset passcode (0000).

Optimal range and wearing
Optimal range and wearing
Optimal range and wearing
Optimal range and wearing



Objects, walls and a greater distance than 5 m can effect the sound. Wear your headset on the same side of your body as your phone for best performance.

Objects, walls and a greater distance than 5 m can effect the sound. Wear your headset on the same side of your body as your phone for best performance.

Objects, walls and a greater distance than 5 m can effect the sound. Wear your headset on the same side of your body as your phone for best performance.

Objects, walls and a greater distance than 5 m can effect the sound. Wear your headset on the same side of your body as your phone for best performance.


To reset the headset to default settings

17


To reset the headset to default settings

To reset the headset to default settings


To reset the headset to default settings

1. Switch the headset off. Press and hold down the on/off key until the pairing icon  appears on the display.


2. Press and hold down the on/off key and the call handling key simultaneously until the headset is off.

1. Switch the headset off. Press and hold down the on/off key until the pairing icon  appears on the display.

2. Press and hold down the on/off key and the call handling key simultaneously until the headset is off.

1. Switch the headset off. Press and hold down the on/off key until the pairing icon  appears on the display.

2. Press and hold down the on/off key and the call handling key simultaneously until the headset is off.

1. Switch the headset off. Press and hold down the on/off key until the pairing icon  appears on the display.

2. Press and hold down the on/off key and the call handling key simultaneously until the headset is off.

정보통신기기인증에 대한 사항



기기의 명칭(모델명): HBH-DS200/HBH-DS220
인증번호: SOK-HBH-DS200/HBH-DS220
인증받은자의 상호: 소니코리아(주)
제조년월: 별도표기
제조사/제조국: Sony Ericsson Mobile Communications AB/

당해 무선설비는 전파혼신 가능성이 있으므로
인명안전과 관련된 서비스를 할 수 없습니다.

www.sonyericsson.com



Sony Ericsson

Sony Ericsson Mobile Communications AB
SE-221 88 Lund, Sweden

LZT 108 9327/x PA13

Printed in XXXX

To play or pause the music

- Press the music control key to start or pause the music.

To stop the music

- Press and hold down the music control key for 2 seconds to stop the phone media player.

To play or pause the music

- Press the music control key to start or pause the music.

To stop the music

- Press and hold down the music control key for 2 seconds to stop the phone media player.

To play or pause the music

- Press the music control key to start or pause the music.

To stop the music

- Press and hold down the music control key for 2 seconds to stop the phone media player.

To play or pause the music

- Press the music control key to start or pause the music.

To stop the music

- Press and hold down the music control key for 2 seconds to stop the phone media player.

To skip to another music track

To skip to another music track

To skip to another music track

To skip to another music track

- Use the media player in your phone or device to select another track.
- Use the media player in your phone or device to select another track.
- Use the media player in your phone or device to select another track.
- Use the media player in your phone or device to select another track.

To adjust the music volume

To adjust the music volume

To adjust the music volume

To adjust the music volume

- When you listen to music, adjust the volume in your phone or device.
- When you listen to music, adjust the volume in your phone or device.
- When you listen to music, adjust the volume in your phone or device.
- When you listen to music, adjust the volume in your phone or device.

Your phone uses the headset for calls. If you are listening to music, the music pauses during the call and starts playing again when the call ends.

Your phone uses the headset for calls. If you are listening to music, the music pauses during the call and starts playing again when the call ends.

Your phone uses the headset for calls. If you are listening to music, the music pauses during the call and starts playing again when the call ends.

Your phone uses the headset for calls. If you are listening to music, the music pauses during the call and starts playing again when the call ends.

To answer a call

To answer a call

To answer a call

To answer a call

- Press the call handling key.
- Press the call handling key.
- Press the call handling key.
- Press the call handling key.

To reject a call

To reject a call

To reject a call

To reject a call

- Press and hold down the call handling key until you hear a beep.
- Press and hold down the call handling key until you hear a beep.
- Press and hold down the call handling key until you hear a beep.
- Press and hold down the call handling key until you hear a beep.

To end a call**To end a call****To end a call****To end a call**

- Press the call handling key. A call on hold is connected again.
- Press the call handling key. A call on hold is connected again.
- Press the call handling key. A call on hold is connected again.
- Press the call handling key. A call on hold is connected again.

To answer a second call**To answer a second call****To answer a second call****To answer a second call**

- Press the call handling key. The ongoing call is put on hold.
- Press the call handling key. The ongoing call is put on hold.
- Press the call handling key. The ongoing call is put on hold.
- Press the call handling key. The ongoing call is put on hold.

To switch between two calls

To switch between two calls

To switch between two calls

To switch between two calls

- Press and hold down the call handling key until you hear a beep.
- Press and hold down the call handling key until you hear a beep.
- Press and hold down the call handling key until you hear a beep.
- Press and hold down the call handling key until you hear a beep.

To redial the last dialled number

To redial the last dialled number

To redial the last dialled number

To redial the last dialled number

- Double-click the call handling key.
- Double-click the call handling key.
- Double-click the call handling key.
- Double-click the call handling key.

To adjust the speaker volume for calls

To adjust the speaker volume for calls

To adjust the speaker volume for calls

To adjust the speaker volume for calls

- During a call, adjust the volume in your phone.
- During a call, adjust the volume in your phone.
- During a call, adjust the volume in your phone.
- During a call, adjust the volume in your phone.

To transfer sound from the phone to the headset

To transfer sound from the phone to the headset

To transfer sound from the phone to the headset

To transfer sound from the phone to the headset

- During an ongoing call in your phone, press the call handling key on the headset. To transfer sound from the headset to the phone, see the phone User guide.
- During an ongoing call in your phone, press the call handling key on the headset. To transfer sound from the headset to the phone, see the phone User guide.
- During an ongoing call in your phone, press the call handling key on the headset. To transfer sound from the headset to the phone, see the phone User guide.
- During an ongoing call in your phone, press the call handling key on the headset. To transfer sound from the headset to the phone, see the phone User guide.

To make a call using voice commands

To make a call using voice commands

To make a call using voice commands

To make a call using voice commands

Before using this function, you have to activate voice control and record voice commands in your phone. For more information, see the phone User guide.

1. Press the call handling key.
2. After the beep: Say the name you want to call.

Before using this function, you have to activate voice control and record voice commands in your phone. For more information, see the phone User guide.

1. Press the call handling key.
2. After the beep: Say the name you want to call.

Before using this function, you have to activate voice control and record voice commands in your phone. For more information, see the phone User guide.

1. Press the call handling key.
2. After the beep: Say the name you want to call.

Before using this function, you have to activate voice control and record voice commands in your phone. For more information, see the phone User guide.

1. Press the call handling key.
2. After the beep: Say the name you want to call.

No connection to the phone or other device

- Make sure your phone or other device is paired with the headset, see page 13.
- Make sure the headset is charged and within range of the phone or other device.
- Verify the Bluetooth settings in the phone or other device.

For more information on Bluetooth and pairing, go to www.sonyericsson.com/learnabout

Redial does not work

- Make sure the call list in the phone is not empty.
- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

I cannot answer a second call

- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

Voice commands does not work

- Make sure that voice commands are enabled and recorded in your phone before you start using them.
- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

The music is not played in the headset

- Make sure your phone or other device is paired with the headset, see page 13. You may have to restart the media player and select to use the headset.
- Make sure your phone or device supports the Bluetooth Advanced Audio Distribution profile.

The remote control music functions do not work

- Make sure your phone or device supports the Bluetooth Advanced Audio Distribution profile.

The headset is switched off automatically

- The battery is too low. When the battery gets low you hear a beep and there is approximately 10 minutes left before the headset is switched off. Charge the battery.
- When pairing for the first time, the headset switches off if you do not pair it with the phone within 10 minutes.

Battery capacity problem

- A battery that has been infrequently used, or a new one, could have reduced capacity. It may need to be recharged a number of times.

Unexpected behaviour

- Reset the headset. See page 17.

No connection to the phone or other device

30

- Make sure your phone or other device is paired with the headset, see page 13.
- Make sure the headset is charged and within range of the phone or other device.
- Verify the Bluetooth settings in the phone or other device.

For more information on Bluetooth and pairing, go to www.sonyericsson.com/learnabout

Redial does not work

- Make sure the call list in the phone is not empty.
- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

I cannot answer a second call

- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

Voice commands does not work

- Make sure that voice commands are enabled and recorded in your phone before you start using them.
- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

The music is not played in the headset

31

- Make sure your phone or other device is paired with the headset, see page 13. You may have to restart the media player and select to use the headset.
- Make sure your phone or device supports the Bluetooth Advanced Audio Distribution profile.

The remote control music functions do not work

- Make sure your phone or device supports the Bluetooth Advanced Audio Distribution profile.

The headset is switched off automatically

- The battery is too low. When the battery gets low you hear a beep and there is approximately 10 minutes left before the headset is switched off. Charge the battery.
- When pairing for the first time, the headset switches off if you do not pair it with the phone within 10 minutes.

Battery capacity problem

- A battery that has been infrequently used, or a new one, could have reduced capacity. It may need to be recharged a number of times.

Unexpected behaviour

- Reset the headset. See page 17.

- Make sure your phone or other device is paired with the headset, see page 13.
- Make sure the headset is charged and within range of the phone or other device.
- Verify the Bluetooth settings in the phone or other device.

For more information on Bluetooth and pairing, go to www.sonyericsson.com/learnabout

Redial does not work

- Make sure the call list in the phone is not empty.
- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

I cannot answer a second call

- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

Voice commands does not work

- Make sure that voice commands are enabled and recorded in your phone before you start using them.
- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

The music is not played in the headset

33

- Make sure your phone or other device is paired with the headset, see page 13. You may have to restart the media player and select to use the headset.
- Make sure your phone or device supports the Bluetooth Advanced Audio Distribution profile.

The remote control music functions do not work

- Make sure your phone or device supports the Bluetooth Advanced Audio Distribution profile.

The headset is switched off automatically

- The battery is too low. When the battery gets low you hear a beep and there is approximately 10 minutes left before the headset is switched off. Charge the battery.
- When pairing for the first time, the headset switches off if you do not pair it with the phone within 10 minutes.

Battery capacity problem

- A battery that has been infrequently used, or a new one, could have reduced capacity. It may need to be recharged a number of times.

Unexpected behaviour

- Reset the headset. See page 17.

- Make sure your phone or other device is paired with the headset, see page 13.
- Make sure the headset is charged and within range of the phone or other device.
- Verify the Bluetooth settings in the phone or other device.

For more information on Bluetooth and pairing, go to www.sonyericsson.com/learnabout

Redial does not work

- Make sure the call list in the phone is not empty.
- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

I cannot answer a second call

- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

Voice commands does not work

- Make sure that voice commands are enabled and recorded in your phone before you start using them.
- Make sure your phone supports the Bluetooth Handsfree profile. See the phone User guide.

The music is not played in the headset

35

- Make sure your phone or other device is paired with the headset, see page 13. You may have to restart the media player and select to use the headset.
- Make sure your phone or device supports the Bluetooth Advanced Audio Distribution profile.

The remote control music functions do not work

- Make sure your phone or device supports the Bluetooth Advanced Audio Distribution profile.

The headset is switched off automatically

- The battery is too low. When the battery gets low you hear a beep and there is approximately 10 minutes left before the headset is switched off. Charge the battery.
- When pairing for the first time, the headset switches off if you do not pair it with the phone within 10 minutes.

Battery capacity problem

- A battery that has been infrequently used, or a new one, could have reduced capacity. It may need to be recharged a number of times.

Unexpected behaviour

- Reset the headset. See page 17.

Declaration of conformity

36

We, **Sony Ericsson Mobile Communications AB**
of

Nya Vattentornet
SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type DDA-0002007

and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards EN 300 328, EN 301 489-17 and EN 60950 following the provisions of Radio Equipment and Telecommunication Terminal Equipment directive **99/5/EC** with requirements covering

EMC directive **89/336/EEC** and Low Voltage directive **73/23/EEC**.

Lund, May 2007

CE 0682



Jacob Sten, Head of Product Business Unit Accessories

We fulfill the R&TTE Directive (99/5/EC).

We fulfill the R&TTE Directive (99/5/EC).

We fulfill the R&TTE Directive (99/5/EC).

We fulfill the R&TTE Directive (99/5/EC).

FCC statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.