



## Quick Start Guide

LocationFree Base Station LF-B20


\* For more details, please refer to the Operating Instructions installed on the CD-ROM which is enclosed in the package.

"LocationFree" is a trademark of Sony Corporation.  
"PlayStation" and "PS2" are registered trademarks of Sony Computer Entertainment Inc.  
Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and other countries.  
All other company names and product names mentioned here may be the trademarks or registered trademarks of their respective companies.  
The symbols for ™ and ® are omitted in these instructions.

©2006 Sony Corporation Printed in Japan

### Before you start setting up the LocationFree Base Station, please check the followings

#### Check the content of the package



**The sticker on the surface of the LocationFree Base Station contains the information which is necessary for setting up the LocationFree Base Station.**

**Note:**  
Please be sure to handle the information, which is necessary for registering your client device(s) to the LocationFree Base Station, with care. Disclosing such information to stranger(s) may result in allowing them to register their client device(s) without your permission. For more details, please refer to the Operating Instructions which is installed on the LocationFree Player CD-ROM.

#### Preparation of the LocationFree client device

Please prepare one of the following LocationFree client devices (some of the client devices listed below may require a LFA-PC20 LocationFree Player software which is enclosed in the package).

##### ● Windows PC

If you intend to use a wireless connection to connect the LocationFree Base Station to your wireless router, you will need a LFA-PC20 LocationFree Player software which is enclosed in the package.

##### ● PSP® (PlayStation® Portable)

Please upgrade the software installed on a PSP® to the latest version.

##### ● Please refer to the following website for more details about other LocationFree client devices.

URL: [sony.com/locationfree](http://sony.com/locationfree)

#### Other necessary items


LAN cable  
Use the LAN cable to connect the LocationFree Base Station to your router. Use the LAN cable also to tentatively connect the LocationFree Base Station to your wireless router for the initial setup.

Composite audio / video cable  
Use the composite audio/video cable to connect the LocationFree Base Station to your audio / video devices.  
 Broadband router (for use on the go)  
Use the broadband router to access the video content from the LocationFree Base Station over the Internet (a Upnp-enabled router is recommended. Please visit our website for more details: [sony.com/locationfree](http://sony.com/locationfree))

#### How to use this guide


##### Connecting / Setting up the LocationFree Base Station

Connect the LocationFree Base Station to your audio/video devices and to your network based on this guide.



For connecting your client device(s) to the LocationFree Base Station and for the settings of your client device(s), please refer to the Operating Instructions installed on the CD-ROM which is enclosed in the package.

### Check the connection of the LocationFree Base Station to your LocationFree client devices




### 1 Connecting the LocationFree Base Station to your wireless router


Tentatively connect the LocationFree Base Station to your wireless router to complete the necessary settings. After you complete the settings, move the LocationFree Base Station close to your audio / video device(s). Proceed to the ② Plugging the LocationFree Base Station and complete the necessary settings.

Use the LFA-PC20 LocationFree Player software for Windows PC to complete the settings.


#### 1 Select "CLIENT" of the wireless mode switch on the underside of the LocationFree Base Station.




#### 2 Connect the LocationFree Base Station to your wireless router using a LAN cable.




#### 3 Connect the power cord and the adapter to the connector on the back panel of the LocationFree Base Station and a wall outlet.




#### 4 Turn on the power.




#### 5 Check to see if the WIRELESS LED flashes in green.




#### 6 Install the LFA-PC20 LocationFree Player software on your PC to connect the LocationFree Base Station to your wireless router wirelessly.



#### 7 Check to see if the WIRELESS LED lights in green.



#### 8 Turn off the power.




#### 9 Unplug the LAN cable and the AC adapter from the back panel of the LocationFree Base Station.


After you complete these settings, please proceed to "2 Plugging the LocationFree Base Station"

### 2 Plugging the LocationFree Base Station


#### 1 Check the wireless mode switch on the underside of the LocationFree Base Station.




#### 2 Attach the LocationFree Base Station stand to the LocationFree Base Station.




2




#### 4 Plug the power cord.




#### 5 Turn on the power.




#### 6 Make sure that the WIRELESS LED lights in green.




#### 7 Use a LAN cable to connect the LocationFree Base Station to your router.



#### 8 Make sure that the NETWORK LED lights in green.



#### 9 Make sure that the SETUP MODE / NET AV LED turns off.




#### Connecting the LocationFree Base Station to your video devices.

Connect the LocationFree Base Station to your DVR and STB.

Connect the IR blaster to the IR blaster connector on the backside of the LocationFree Base Station to configure the on-screen remote control.

After you complete the settings, please turn on the video devices.



#### Type A


You can connect your LocationFree client device(s) to the LocationFree Base Station via your router.

#### Type B

You can connect your LocationFree client device(s) to the LocationFree Base Station wirelessly.

#### Note

The WIRELESS LED will be lit eventually. If the WIRELESS LED keeps on blinking, that indicates the LocationFree Base Station is not receiving the electric wave from your router. Please check to see if the LocationFree Base Station and your router are closely located.



### Before you begin to set up the LocationFree Base Station:

#### Please install the LFA-PC20 LocationFree Player software (the enclosed CD-ROM) on your PC.

After you complete the software installation, click the LocationFree icon on your PC desktop and start the LocationFree Player. Follow the instructions after the LocationFree Player window opens.

#### Type B

Using a wireless connection to connect the LocationFree Base Station to your PC:  
Before you start the LocationFree Player, please connect your PC to the LocationFree Base Station wirelessly using the information (e.g. SSID, WEP Key, Login Password ABCD, SERIAL NO. 0000000) indicated on the sticker which is attached to this guide or to the side of the LocationFree Base Station.

\* For more details about the wireless connection settings, please refer to the Operating Instructions of your wireless LAN device such as your PC or LAN card.

#### For Help:

Please refer to the Operating Instructions installed on the LFA-PC20 LocationFree Player CD-ROM or visit our website at : [sony.com/locationfree](http://sony.com/locationfree)

## Important Safeguards

### Owner's Record

The serial numbers are located at the side of the LocationFree Base Station. Record the serial number in the space provided below. Refer to them whenever you call upon your Sony dealer regarding this product. The nameplate is located on the side of the LocationFree Base Station.

Model No. LF-B20

Serial No. \_\_\_\_\_

### Contacting Sony

If, after reading these operating instructions, you have additional questions related to the use of your Sony LocationFree Base Station, please call our LocationFree Customer Support at

LocationFree Customer Support

1-866-925-SONY (7669) - U.S. & Canada

1-239-768-7688 - International

9:00 a.m. - 9:00 p.m. EST, Mon.-Fri. (English Only)

LocationFree Web sites

http://www.sony.com/locationfree/ - U.S.

http://www.sonystyle.ca/locationfree/ - Canada

### Important Safety Instructions

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11) Only use attachments/accessories specified by the manufacturer.
- 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.




13) Unplug this apparatus during lightning storms or when unused for long periods of time.

14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

## WARNING

To reduce the risk of fire or shock hazard, do not expose the unit to rain or moisture.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Do not let this unit get wet. Never spill liquid of any kind on the unit. If any liquid or solid object fall through the unit, do not operate the unit. It may result in electric shock or damage to the unit.

No naked flame sources, such as lighted candles, should be placed on the apparatus.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth at uncontrolled equipment.

This equipment should be installed and operated with minimum distance at least 20 cm between the radiator and persons body (excluding extremities: hands, wrist, feet and legs) and must not be co-located or operated with any other or transmitter.

\* This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

\* When using the unit with 802.11a (5.15-5.25 GHz), use indoors.

### LocationFree Base Station LF-B20

Contains FCC ID : MCLJ20H031

Contains IC : 2878D-J20H031

The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

### NOTIFICATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

### FCC WARNING

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

This class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de classe B est conforme à la norme NMB-003 du Canada.

### About Wireless Security

Since communication via the wireless LAN function is established by radio waves, the wireless signal may be susceptible to interception. To decrease this danger, the LocationFree Base Station supports various security functions. Be sure to correctly configure the security settings in accordance with your intended purpose and network environment. For details, refer to the Operating Instructions document.

### WARNING

If the following safety precautions are not observed and the product is used incorrectly, it may result in serious injury or death from a fire or an electric shock.

### Installation

- To prevent fire or shock hazard, do not place objects filled with liquids, such as vases, on the apparatus.
- Place the apparatus on a stable surface. If placed on an unstable or inclined surface, the apparatus may fall, causing personal injury.
- Place the LocationFree Base Station at least 10 cm away from the wall.
- Never cover the slots and openings with a cloth or other materials.
- Keep this apparatus out of children's reach.
- Do not place the apparatus in a place where medical equipment is in use. It may cause a malfunction of medical instruments.
- Do not install this apparatus in a vehicle. The motion of the vehicle may cause the apparatus to fall down and cause injury.
- Do not install this apparatus on a ship or other vessel. If the apparatus is exposed to seawater, it may cause a fire or damage the apparatus.
- Do not use power-line operated sets near water - for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc.
- Never place the apparatus in hot, oily, humid or excessively dusty places.
- Do not install this apparatus outdoors. If the apparatus is exposed to rain, it may result in a fire or an electrical shock.
- If this apparatus is exposed to direct sunlight, the apparatus may heat up and it may damage the apparatus.
- Do not connect to the power cord before all connections are complete.
- Do not connect the power cord to, or disconnect it from the AC power adaptor while it is connected to a wall outlet. Doing so may create the danger of fire or electric shock.

### AC power adaptor

- This unit has no power switch. When installing the unit, incorporate a readily accessible disconnect device in the fixed wiring, or connect the power cord to a socket-outlet which must be provided near the unit and easily accessible. If a fault should occur during operation of the unit, operate the disconnect device to switch the power supply off, or disconnect the power cord.
- Do not use a poor fitting AC power outlet. Insert the plug fully into the AC power outlet. A poor fit may cause arcing and result in a fire. Contact your electrician to have the AC power outlet changed.
- Do not use the AC power adaptor placed in a narrow space, such as between a wall and furniture.
- Do not place the AC power adaptor near any heat sources such as other AC adaptor.
- Do not wave the power cord or AC power adaptor cable in the air. The plugs may hit people, or glasses, causing personal injury.
- Do not connect the AC power adaptor to an electric transformer. Doing so may cause overheating or malfunction of the product.
- Do not cover the AC power adaptor with a cloth or bedding materials during use. Heat may build up inside the apparatus, resulting in a deformation of casing or a fire.

### Cleaning

- Unplug the power code before cleaning the apparatus. Cleaning the apparatus connected to a power source may create the danger of electric shock.
- Periodically clean the plug and terminal. If dust accumulating in the terminal or the gap between the plug and the wall outlet gets moist, it may cause poor insulation that creates the danger or fire. Unplug the power cord and clean the plug terminal periodically.

### Use

- Do not allow water or any foreign matter to get in the apparatus. Doing so may create the danger of fire, electric shock, or personal injury. If such materials accidentally get in, immediately unplug the power cord and contact Customer Information Services Center.
- Do not open the casing of the apparatus. Doing so may create the danger of fire or electrical shock.
- Do not operate this product near the medical devices (such as pacemaker, etc.).
- Unplug the power cord when moving the apparatus.
- Do not touch the power cord, the AC adaptor and the apparatus with wet hands. Doing so may cause an electric shock or damage to the apparatus.
- Do not touch the system or AC adaptor for an extended period of time while in use.
- Do not put anything heavy on this apparatus.
- Do not apply strong impact to the apparatus.
- Do not allow any metal object to contact with the terminal. Doing so may cause the apparatus to short, creating the danger of fire or malfunction.
- Do not detach the ferrite core from the cable.

### CAUTION

If the following safety precautions are not observed and the product is used incorrectly, it may result in injury or property damage.

### Care of the product

- Never use rubbing alcohol, benzene, or thinner for cleaning.
- Chemically treated cloths may dull the coating of the product.
- Spraying the product with volatile solvents (Such as an insecticide), or allowing the products to come into prolonged contact with rubber or plastic products may damage the coating or spoil the product.
- Do not use liquid cleanser. It may accidentally get inside the product and cause a malfunction of the product.

### Overseas

Depending on the country, there are limitations on the use of the apparatus. In some cases, use of the apparatus may lead to a fine or other penalty.

### Heat

The LocationFree Base Station and/or the AC power adapter may heat up during operation.

This is not a malfunction.

### AC power adapter (AC-LX1B)

Power requirements	100 - 240 V AC, 50/60 Hz
Rated output	12 V DC, 3A
Operating temperature	32°F to 95°F (0°C to 35°C)
Storage temperature	14°F to 140°F (-10°C to 60°C)
Dimensions	Approx.4 x 1 1/16 x 2 inches (99.5 x 25.5 x 49.5 mm) (w/h/d, excluding protrusions)
Mass	Approx.6 oz. (180 g)

## Dynamic DNS Terms of Use Agreement

PLEASE READ THE TERMS AND CONDITIONS OF THIS AGREEMENT APPLICABLE TO THE DYNAMIC DNS SERVICE (hereinafter referred to as the "Service") THAT ACCOMPANIES THE INSTALLATION OF YOUR SONY LOCATION FREE PRODUCT ("LF-B20": [list models/names] hereinafter referred to as the "Product"). THE USE OF THE SERVICE COMMENCING UPON INSTALLATION AND ACTIVATION OF THE PRODUCT IS EXPRESSLY CONDITIONED UPON YOUR ACCEPTANCE OF THE TERMS OF USE PROVIDED IN THIS AGREEMENT AS FOLLOWS:

### 1. ACKNOWLEDGMENT AND ACCEPTANCE OF TERM SERVICE

All services provided by Sony and its licensors are delivered to you (hereinafter referred to as "User," "You" or "Your") under the rules set forth in these Terms of Use ("TOU") and any other policies set forth by Sony and its licensors. All services provided under this TOU shall be read in concert to the fullest extent possible with the "SOFTWARE LICENSE AGREEMENT" and "GNU LESSER GENERAL PUBLIC LICENSE" that were also provided with your Product, and the rights and obligations of each such Agreement shall apply with full force and effect, notwithstanding this Agreement.

### 2. DESCRIPTION OF SERVICE AND ACCEPTABLE USE

Sony and its licensors are providing User with various DNS-based aliasing and hosting services. User must (1) provide all equipment necessary for their own Internet connection, including computer and modem, and (2) provide for User's own access to the Internet and pay any fees related with such connection. User agrees to provide and maintain certain current, complete, and accurate information about User as prompted to do so by the Service. All information requested on sign-up shall be referred to as registration data ("Registration Data"). Furthermore, User grants Sony and its licensors the right to disclose certain Registration Data about User and Service information where required to do so by any applicable law or legal process. If any information provided by User is inaccurate, Sony and its licensors reserve the right to terminate User's membership and rights to use the Service, with or without notification.

### 3. MODIFICATIONS TO ACCEPTABLE USE POLICY

Sony and its licensors reserve the right to change the terms and conditions of this TOU as necessary. Sony and its licensors expect User to actively ensure that they agree to the current TOU, and a modification date will be posted on any and all copies. User's continued use of the Service constitutes an acknowledgement of the TOU and its modifications by the User and an agreement by the User to abide and be bound by the TOU and its modifications.

### 4. MODIFICATIONS TO SERVICE

Sony and its licensors reserve the right to modify or discontinue the Service with or without notice to the User. Sony and its licensors shall not be liable to User or any third party should Sony and its licensors exercise its right to modify or discontinue the Service.

### 5. PRIVACY POLICY

In order to participate in the Service, you may be required to provide personally identifiable information to Sony and/or its licensors. If you choose not to provide such information, you may not be able to utilize and access the Service. Sony and its licensors take great care in maintaining the security of your personal information and in preventing unauthorized access to it through the use of appropriate technology and internal procedures. However, Sony and its licensors do not guarantee that unauthorized access will never occur. It is, however, Sony and its licensors' policy to respect the privacy of its Users. In addition to the privacy of Registration Data as discussed in Section 2 above, Sony and its licensors will not monitor, edit, or disclose the contents of a User's private communications or data unless required to do so by law or in the good faith belief that such action is necessary to: (1) conform to the edicts of the law or comply with legal processes served on Sony or its licensors; (2) protect and defend the rights or property of Sony and its licensors; (3) act under exigent circumstances to protect the personal safety of its Users or the public; or (4) administer the system to maintain performance for Users, including disclosures between and/or among Sony's affiliated companies, licensors of the Service and such persons or companies with whom Sony or its licensors have engaged to carry out or provide support for the operations of the Service or Sony's related business. Notwithstanding the foregoing, Sony and/or its licensors may also disclose User's personally identifiable information where it has sought User's prior consent. User acknowledges and agrees that Sony and its licensors neither endorse the content of any User communications nor assume responsibility for any threatening, libelous, obscene, harassing, or offensive material contained therein, any infringement on third party intellectual property rights arising therefrom, or any crime facilitated thereby. Unless instructed otherwise by Sony or its licensors may contact You from time to time to provide you with additional information about Your Sony products or the Service. Sony or its licensors may also contact You to request Your consent to share Your personal information with third parties as further described above. If You wish not to receive information from Sony or its licensors, to not grant consent to the sharing of Your personal information, or wish to withdraw any previously provided consent, you may do so by contacting Sony by email to: Privacy@am.sony.com or writing Sony at: Sony Electronics, Inc., Personal Information Management Office, 1 Sony Drive, MD T1-5, Park Ridge, NJ (USA) 07656.

**NOTE TO CALIFORNIA RESIDENTS - YOUR CALIFORNIA PRIVACY RIGHTS:** If you are a California resident, you have the right to receive: (a) information identifying any third party company(ies) to whom Sony or its licensors may have disclosed within the pay year, personal information pertaining to You and Your family for such company's direct marketing purposes; and (b) a description of the categories of personal information disclosed. To obtain such information, please email your request to Privacy@am.sony.com.

**6. DISCLAIMER OF WARRANTIES**

YOU EXPRESSLY AGREE THAT USE OF THE SERVICE IS AT YOUR SOLE RISK. THE SERVICE IS PROVIDED ON AN "AS IS" AND "AS AVAILABLE" BASIS. SONY AND ITS LICENSORS EXPRESSLY DISCLAIM ALL WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT. SONY AND ITS LICENSORS MAKE NO WARRANTY THAT THE SERVICE WILL MEET YOUR REQUIREMENTS, OR THAT THE SERVICE WILL BE UNINTERRUPTED, TIMELY, SECURE, OR ERROR-FREE; NOR DOES SONY AND ITS LICENSORS MAKE ANY WARRANTY AS TO THE RESULTS THAT MAY BE OBTAINED FROM THE USE OF THE SERVICE OR AS TO THE ACCURACY OR RELIABILITY OF ANY INFORMATION OBTAINED THROUGH THE SERVICE OR THAT DEFECTS IN THE SOFTWARE WILL BE CORRECTED. USER UNDERSTANDS AND AGREES THAT ANY MATERIAL AND/OR DATA DOWNLOADED OR OTHERWISE OBTAINED THROUGH THE USE OF THE SERVICE IS DONE AT USER'S OWN DISCRETION AND RISK AND THAT USER WILL BE SOLELY RESPONSIBLE FOR ANY DAMAGE TO USER'S COMPUTER SYSTEM OR LOSS OF DATA THAT RESULTS FROM THE DOWNLOAD OF SUCH MATERIAL AND/OR DATA. SONY AND ITS LICENSORS MAKE NO WARRANTY REGARDING ANY GOODS OR SERVICES PURCHASED OR OBTAINED THROUGH THE SERVICE OR IN ANY TRANSACTIONS ENTERED INTO THROUGH THE SERVICE. NO ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, OBTAINED BY USER FROM SONY OR ITS LICENSORS OR THROUGH THE SERVICE SHALL CREATE ANY WARRANTY NOT EXPRESSLY MADE HEREIN. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF CERTAIN WARRANTIES, SO SOME OF THE ABOVE EXCLUSIONS MAY NOT APPLY TO YOU.

### 7. LIMITATION OF LIABILITY

SONY AND ITS LICENSORS SHALL NOT BE LIABLE FOR ANY DAMAGES, INCLUDING BUT NOT LIMITED TO INCIDENTAL, SPECIAL, CONSEQUENTIAL AND INDIRECT DAMAGES, DAMAGES ARISING FROM ANY INFRINGEMENT OF THIRD PARTY RIGHTS, LOSS OF PROFIT AND LOSS OF DATA, SUFFERED BY USER OR ANY THIRD PARTY DUE TO USER'S MISUSE OR UNAUTHORIZED USE OF THE SERVICE, PRODUCTS OR SOFTWARE WHICH IS NOT IN COMPLIANCE WITH OR NOT ACCORDING TO THIS AGREEMENT OR THE DOCUMENTS PROVIDED TO USER WITH THIS AGREEMENT.

### 8. INDEMNIFICATION

USER HEREBY AGREES TO INDEMNIFY AND HOLD HARMLESS SONY AND ITS LICENSORS FROM AND AGAINST ANY COST, EXPENSE, LOSS, DAMAGE, CLAIM AND LIABILITY ARISING FROM OR IN CONNECTION WITH USER'S MISUSE OR UNAUTHORIZED USE OF THE SERVICE, PRODUCT OR SOFTWARE OR ANY OTHER USE OF THE SERVICE, PRODUCT OR SOFTWARE THAT