NW-MS11

Network Walkman® Digital Music Player

SONY

▲ **REMOVABLE 128MB MAGICGATE™ MEMORY STICK® MEDIA PROVIDES UP TO 4 HOURS OF MUSIC ENJOYMENT***

• **TRANSFER INTERNET DOWNLOADS AND RECORDINGS FROM YOUR CDS**

• **CONNECTS TO USB PORT FOR HIGH SPEED DATA TRANSFER**

• **PLAYS BACK IN ATRAC3™, SUPPORTS MP3, WINDOWS MEDIA™ AUDIO AND WAV**

• **SKIP-PROOF DESIGN—NO MOVING PARTS**

• **SMALL COMPACT DESIGN**

• **BACKLIT LCD DISPLAY WITH 4 MODES**

• **RECHARGEABLE "GUM STICK" STYLE NIMH BATTERY PROVIDES UP TO 10 HOURS OF PLAYBACK**

• **"SEE SAW" SWITCH OPERATION**

• **MUSIC MANAGEMENT SOFTWARE SUPPLIED**

• **128MB MAGICGATE™ MEMORY STICK® MEDIA CARD, MUSIC MANAGEMENT SOFTWARE, BATTERY CHARGER, NIMH BATTERY, USB CABLE, EARBUD HEADPHONES AND CARRY CASE SUPPLIED**

• **SUPPORTS MICROSOFT® WINDOWS® 98, WINDOWS® 98SE, WINDOWS® 2000 PROFESSIONAL, WINDOWS® MILLENNIUM EDITION, WINDOWS® XP HOME EDITION AND WINDOWS® XP PROFESSIONAL**

▲ **STEP-UP FEATURE** ▶ **NEW FEATURE**

SONY

features

▲ **REMOVABLE 128MB MAGICGATE™ MEMORY STICK® MEDIA** provides up to 4 hours of music enjoyment*

• **TRANSFER INTERNET DOWNLOADS AND RECORDINGS** between your CDs and your PC, creating your own music mixes for on-the-go enjoyment

• **CONNECTS TO USB PORT FOR HIGH SPEED DATA TRANSFER** on a PC for "Plug and Play" connection and high-speed data transfer

• **PLAYS BACK IN ATRAC3™, SUPPORTS MP3, WMA AND WAV**

• **SKIP-PROOF DESIGN** with no moving parts for uninterrupted playback even while carrying the Network Walkman player during active uses

• **SMALL COMPACT DESIGN** fits comfortably into the palm of a hand or is easily carried in pocket or purse

• **BACKLIT LCD DISPLAY WITH 4 MODES** depending on the mode chosen, display will feature track number, bit rate, elapsed time, song title, artist name, spectrum analyzer, play mode, and bass/AVLS/battery life indicator

• **RECHARGEABLE "GUM STICK" STYLE NIMH BATTERY** provides up to 10 hours of playback time and offers savings and convenience over disposable batteries

• **"SEE SAW" SWITCH OPERATION** lets you move quickly through tracks and other available functions simply by pressing the switch up or down

• **MUSIC MANAGEMENT SOFTWARE SUPPLIED** to manage and store your digital music files, make custom playlists, and transfer music to your Network Walkman player

• **SONY PROVIDES WHAT YOU NEED—**128MB MagicGate™ Memory Stick® Media Card (which accepts copyright-protected audio files in addition to voice, image and data files), Music Management Software, Battery Charger, NiMH Battery, USB Cable, Earbud Headphones and Carry Case are all supplied, so this Walkman Digital Music Player is ready to enjoy right out of the box

• **SUPPORTS MICROSOFT® WINDOWS® 98, WINDOWS 98SE, WINDOWS® 2000 PROFESSIONAL, WINDOWS® MILLENNIUM EDITION, WINDOWS® XP HOME EDITION AND WINDOWS® XP PROFESSIONAL**

specifications

SYSTEM REQUIREMENTS: IBM PC/AT or Compatible

OPERATING SYSTEM: Pre-Installed Windows® 98, Windows® 98SE, Windows® 2000 Professional, Windows® Millennium Edition, Windows® XP Home Edition and Windows® XP Professional

CPU: Pentium® MMX™, 233 MHz or higher
    RAM: 64 MB or greater
    Hard Disk Drive Space: 60MB or greater
    USB Port
    CD-ROM (internal/external)
    Sound Board

DIMENSIONS (WHD): 1 $^{7}/_{16}$" x 3 $^{1}/_{4}$" x $^{9}/_{16}$" (37.5 x 81.6 x 14.1mm)

WEIGHT: 2 $^{3}/_{8}$ oz (67g) w/MagicGate™ Memory Stick® Media Card and NiMH Battery