




Basics

Startup guide

Overview



Bluetooth® Keyboard BKB10

- 1 Bluetooth® notification light
- 2 Power switch
- 3 Charging port
- 4 Pair key

Charging the keyboard

! Charge the keyboard for 4 hours before using it for the first time. Use a regular charger only.




Sony Mobile Communications AB
SE-221 88 Lund, Sweden
www.sonymobile.com



1281-4064.1

Turning on the keyboard


To turn on the keyboard



- Slide the power switch downwards.

Setting up the keyboard

To pair the keyboard with a mobile device using Bluetooth®



- 1 Make sure the charger is disconnected from the keyboard.
 - 2 Turn on the keyboard. The keyboard enters pairing mode automatically and the Bluetooth® notification light flashes continuously.
 - 3 Turn on the Bluetooth® function in your mobile device, then search for and connect to the keyboard.
- ! If the Bluetooth® notification light stops flashing before you get time to pair your mobile device with the keyboard, hold down the Pair key until

the Bluetooth® notification light flashes and then try again.

Support on the web



Visit www.sonymobile.com/support access a range of support options for your device, including downloads, troubleshooting tips and a User guide.

Legal information

Sony BKB10

Prior to use, please read the *Important information* leaflet separately provided.



This User guide is published by Sony Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide.

All rights reserved.

©2014 Sony Mobile Communications AB.

Publication number: 1281-4064.1

Interoperability and compatibility among Bluetooth® devices varies. Device generally supports products utilizing Bluetooth spec. 1.2 or higher, and Headset or Handsfree profile.

Sony is the trademark or registered trademark of Sony Corporation. Bluetooth is the trademark of the Bluetooth (SIG) Inc. and is used under license. All other marks are the property of their respective owners. All rights reserved.

All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners. Any rights not expressly granted herein are reserved. All other trademarks are property of their respective owners.

Visit www.sonymobile.com for more information.

All illustrations are for illustration only and may not accurately depict the actual accessory.