SONY

DSC-W800

Point and Shoot Digital Still Camera



Specifications

Camera	
Camera Type	Compact zoom digital camera
Imaging Sensor	
Imaging Sensor	1/2.3" Super HAD CCD Sensor
Processor	BIONZ®
Pixel Gross	20.4 MP
Effective Picture Resolution	20.1 MP
Color Filter System	RGB primary color mosaic filters
Recording	
Media Type	Memory Stick Duo; Memory Stick PRO Duo; Memory Stick PRO Duo(High Speed); Memory Stick PROHG Duo; Memory Stick Micro*6; Memory Stick Micro (Mark2)*6; SD/SDHC/SDXC Memory Card; microSD Memory Card*6; microSDHC Memory Card*6; Memory Stick XC-HG Duo; microSDXC Memory Card*6
Still Image Mode	JPEG
Still Image Max Effective Resolution	Approx. 20.1 Megapixels
Still Image Size 16:9	15M(5,152 x 2,896) / 2M(1,920 x 1,080)
Still Image Size 4:3	20M(5,152 x 3,864) / 10M(3,648 x 2,736) / 5M(2,592 x 1,944)
Panorama Still Image Size	Sweep Panorama:360°(11,520×1,080) / Wide(7,152 x 1,080/4,912 x 1,920) / Standard(4,912 x 1,080/3,424 x 1,920)
Video Format	AVI (Motion JPEG)
Video Mode	1280x720 (1,280x720/30fps) / VGA (640x480/30fps) / QVGA (320x240/30fps)
Audio Format	MP3
Microphone/Speaker	Mono / Mono
Optics/Lens	
Lens Type	Sony Lens
Aperture	f 3.2-6.4
Optical Zoom	5x
Digital Zoom	10x
Focal Length (35mm equivalent)	Still 4:3: 26-130mm / Still 16:9: 28.3-141:6mm / Movie 16:9: 31.5-157.3mm / Movie 4:3: 26-130mm
Minimum Focus Distance	iAuto: AF (W: Approx. 5cm (0.16 ft.) to Infinity, T: Approx. 60cm (1.96 ft.) to Infinity) / Program Auto: AF (W: Approx. 5cm (0.16 ft.) to Infinity, T: Approx. 60cm (1.96 ft.) to Infinity)
Aspheric Elements	5
ISO	Auto/100/200/400/800/1600/3200
Steady Shot Mode:Active	Yes
LCD Display	
LCD Type	2.7" Clear Photo™ LCD (230K dots)
Brightness Control	5(Bright) / 4 / 3 / 2 / 1(Dark)
Grid Display	Yes
Focus Control	
AF Modes	Multi Point AF / Center Weighted AF / Tracking Focus / Face Tracking Focus

SONY

Exposure System	
Metering Modes	Multi Pattern / Center Weighted / Spot
Exposure Compensation	Plus / Minus 2.0EV, 1 / 3EV step
Scene Mode(s)	High Sensitivity / Night Scene / Night Portrait / Landscape / Portrait / Beach / Snow / Gourmet / Pet Mode
D-Range Optimizer	Standard / Plus / Off
ISO	Auto / 100 / 200 / 400 / 800 / 1600 / 3200
White Balance Mode	Auto / Daylight / Cloudy / Flourescent White Balance 1 / Flourescent White Balance 2 / Flourescent White Balance 3 / Incandescent / Flash
Minimum Illumination	Auto: 28lux (Shutter Speed 1/30)
ISO Sensitivity (Movie)	Auto: (ISO100-800 level)
Drive System	
Continuous Shooting Speed	Approx.0.52 fps(100 shots)
Self-timer	Off / 10sec. / 2sec. / portrait1 / portrait2
Shutter Speeds	iAuto(2 - 1/1500) / Program Auto(1 - 1/1500)
Burst Mode	Approx 1 fps at 20.4MP (Maximum 100 shots)
Flash	
Flash Modes	Auto / Flash On / Slow Synchro / Flash Off / Advanced Flash
Flash Coverage	ISO Auto: Approx. 0.3m to 2.8m (11 7/8 in. to 9 ff. 2 1/4 in.)(W) / Approx. 1.5m to 2 m (4 ff. 11 1/8 in. to 6 ff. 6 3/4 in.)(T), ISO3200: up to Approx. 5.3 m (17 ff. 4 3/4 in.)(W) / Approx. 3.3 m (11 ff. 10 in.)(T)
Convenience Features	
Self Timer	Off / 10sec. / 2sec. / portrait 1 / portrait 2
Red-Eye Reduction	Auto / On / Off
Erase/Protect	Erase: Single / Select / Date / Folder, Protect: Single / Select / Date / Folder
Power Save Mode	Standard / Max / Off
Advanced Features	
Sweep Panorama	Sweep Panorama (360)
Face Detection	8 faces
Image Stabilization	Optical SteadyShot™ Image Stabilization with Intelligent Active Mode
Intelligent Auto	Yes
Shooting Tips	Yes
Blink Detection	Yes
Interface	
Memory Card Slot	MS Duo and SD/SDHC/SDXC compatible
SD Output	Composite
USB Port(s)	Multi (AV/USB), Hi-Speed USB (USB2.0)
Microphone Input	Mono
Weights and Measurements	
Dimensions (Approx.)	Approx. 50 mm × 22 mm × 54 mm(2 inches × 7/8 inches × 2 1/4 inches) (W/H/D)
Weight (Approx.)	4.7 oz. (125g)
Weight(Approx) (Main unit only)	3.8 oz. (109g)
Power	
Battery Type	LITHIUM ION NP-BN 3.6V
Battery Capacity	typical: 2.3Wh (630mAh), minimum: 2.2Wh (600mAh)
	Approx.1W
rower consumption and operation	P.P.
Power Consumption (in Operation) Power Requirements	AC 100V to 240V, 50/60 Hz, 70mA

SONY

Battery (NP-BN)

AC AdaptorAC-UB10C

Wrist Strap

Multi USB cable Instruction Manual

Supplied Accessories

1. Reacrds in 29 minute segments
2. Requires HDTV and HDMI cable sold separately
3. Requires SEQ 20 cable sold separately
3. Requires SEQ 20 cable sold separately

@ 2014 Sony Electronics Inc. All rights reserved. Reproduction in whole or in part without written permission is prohibited. Sony, Cyber-shot, SteadyShot, Smile Shutter, Sweep Panaram and the Sony BeMoved logo are trademarks of Sony. Microsoft, Windows, and Windows Vista are trademarks in Microsoft Corporation. Mac is a trademark of Apple, Inc. All other trademarks of their respective owners. Features and specifications subject to change without notice.

Updated: June 10, 2014