

**Water Resistant
Portable 2600mAh Power Bank**



SKU# 303-981

Item No: WP26-24 / 2905

INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND
RETAIN FOR FUTURE USE

1

Thank you for using Soundlogic / XT Water Resistant Portable 2600mAh Power Bank. This product is water resistant, universal, portable and chargeable power source which is designed to charge various mobile phones and other USB rechargeable products, such as iPhone, iPod, Samsung, HTC, Blackberry, Nokia, Sony etc.

Getting Started

- Remove the Power Bank from the box.
- Remove any packaging from the product.
- Please retain all packaging after you have checked and counted all the parts and the contents against the list.

Package Contents

- Water resistant, Portable 2600mAh Power Bank
- USB Recharging Cable
- Instruction Manual

Key Features

- Water resistant, Portable Rechargeable Power Bank – capacity 2600mAh.
- Connects to your iPod, iPhone, other Smart phones, and other USB rechargeable devices to recharge the battery.
- Water resistant housing; shock and dust proof.
- Power Bank recharges via USB port of your computer or other USB power source.
- Built-In Over-charge protection
- Fits in your pocket, purse or briefcase for travelling purposes.

SAFETY INSTRUCTIONS

- Keep the unit away from heat sources, direct sunlight.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper

2

- repairs may place the user at serious risk.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This unit is not a toy.


ADDITIONAL SAFETY INSTRUCTIONS AND WARNINGS

- Never charge batteries unattended. When charging batteries you should always remain in constant observation to monitor the charging process and react to potential problems that may occur.
- If at any time you witness a battery starting to swell or heat up, discontinue charging process immediately, disconnect the battery and let it cool down for approximately 15 minutes. This may cause the battery to leak, and the reaction with air may cause the chemicals to ignite, resulting in fire.
- Do not let the device fall down the floor. The internal circuit might get damaged.
- We suggest you put the battery in an enclosure to protect it from damages dropping from height accidentally.
- Never store or charge battery pack in extreme temperatures, since extreme temperature could ignite fire.
- Store battery at room temperature between 40 and 80 degrees F for best results.
- Do not expose battery pack to direct sunlight (heat) for extended periods.
- Storing battery at temperatures greater than 170 degrees F for extended periods of time (more than 2 hours) may cause damage to battery and possible fire.
- Must keep battery pack away from children.

3

- Do not attempt to disassemble the device as it may cause damage.

Description of Parts



INSTRUCTIONS FOR USE

Charging your Portable Power Bank

- Please use the USB Recharging Cable that is included in your pack. Connect one end of the cable to the Micro USB port (DC Input Port) of the power bank, and the other end to your computer USB Port or other suitable USB source.
- Red LED light turns on when charging is in progress. Once it is fully charged, the LED charging indicator turns blue.
- Note: Before using the product for the first time, please charge it for at least 5 hours or until the LED charging indicator turns to blue.

Charging your iPhone, Smart Phones or any other USB Rechargeable Devices –

- Please ensure that the Portable Power Bank is fully charged.
- Please use your device's USB charging cable that is applicable to charge your device (not included). Connect one end to USB Output Port (DC Output) of the power bank and the other end to your device.
- It would start charging your device.

Care and maintenance

Read the following recommendations before using the Portable Power Bank.

- Keep the Safety Flap securely closed in order to

4

prevent water from seeping into the circuit and internal parts of the power bank. This may cause irreparable and permanent damage to the power bank.

- Do not use abrasive cleaning solvents to clean the device.
- Do not expose the device to extremely high or low temperature as it may cause to destroy the battery or distort certain plastic parts.
- Do not dispose of the device to fire as it may result in an explosion.
- Do not expose the device to contact with sharp objects as this will cause scratches and damage.
- Do not let the device fall down the floor. The internal circuit might get damaged.
- Do not attempt to disassemble the device as it may cause damage.

IMPORTANT NOTE: Keep the power bank Safety Flap (covering the USB port area) securely closed, while using it near water. Failing to do so, might allow water to seep into the circuit and other internal parts of the power bank that may cause permanent damage to its performance. Preventing the product from such damage is user's responsibility and will not be covered under product warranty.

Product Specifications:

Water resistant, Portable Power Bank with Built-In Rechargeable Battery
 Battery Capacity: 2600mAh
 Output: DC 5V – 1A (Max)
 Input: DC 5V – 0.6A
 Dimensions: 3.8" x 1" x 1"
 Weight: 2.6 Oz
 Built-In Over-charge protection

TROUBLESHOOTING

Problem	Solution
Charging indicator does not light up when charging the Portable Power Bank	Please ensure that USB Charging Cable and Power Source is connected properly. Please ensure that your Computer is Turned On.
Portable Power Bank does not charge device once connected	Please ensure that USB Charging Cable is well connected.

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

6

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn't cover the following which may be supplied with this product, including but not limited to: LCD Screens, glass parts, lenses, bulbs etc. This warranty is effective only if the product is purchased and operated in USA and Canada, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to,

7

negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

WARRANTY PERFORMANCE: During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@mttradinggroup.com or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

8