



BWA15AA001
Bluetooth® Headset
User manual

1. Notice Before Using

Thank you for purchasing the Bluetooth® Headset BWA15AA001. Please read this User's Manual completely before you use the Headset.

BWA15AA001 designed for listening the high quality music wirelessly that based on the latest Bluetooth® wireless technology, it is built-in MP3, AAC and apt-X low latency codec for high quality audio streaming. BWA15AA001 can be easily connected to a mobile phone for call conversation and music listening, it is also capable to connect to the other Bluetooth®-enabled devices like Notebook, iPod etc.

BWA15AA001 is compliant with Bluetooth V3.0 specification, supports HSP, HFP, A2DP and AVRCP profiles. Please make sure your phone or other device supports these profiles.

2. Specification

Bluetooth specification: V3.0

Operation frequency: 2.402-2.48GHz

Supported profile: HSP, HFP, A2DP,AVRCP

Operation range: Up to 10 meters

Talk time: 7 hours

Play time: 6 hours

Standby time:140hours

Battery type: 120mAh, 3.7V, Polymer Li-ion Battery

Charge time:2 Hours


3. Package Contents List

Please inspect this package and refer to the package contents list below to verify all items were included in this package:

- 1) BWA15AA001 Bluetooth® headset(1)
- 2) USB Charging Cable(1)
- 3) User's Manual(1)
- 4) AUX Cable

4. BWA15AA001 Bluetooth® Headset Overview

- ① Power
- ② Next Track / Volume +
- ③ Play/Pause
- ④ Previous Track / Volume –
- ⑤ Indicator LED
- ⑥ Microphone
- ⑦ Charging Port
- ⑧ AUX IN port



5. Battery information

The device is equipped with an integrated lithium-polymer battery. The battery cannot be replaced. Do not attempt to remove the battery from the device since it would damage the device. The full performance of a new battery is not achieved until after two or three complete charging-discharging cycles. The battery can be charged and discharged several hundred times, but it loses its capacity over time. Disconnect the BWA15AA001 from the power supply as soon as the battery is fully charged, overcharging would reduce the service life of the battery. A charged battery will lose its capacity if it is not used on a regular basis.

Important:

Ensure that the battery is fully charged if you do not use the device for a long period of time. To avoid a complete discharge of the battery, the **BWA15AA001** should be charged at least every 6 months.

6. Charging the battery

The **BWA15AA001** is operated with a rechargeable battery. Charge the battery completely before its first use. Read the section "Battery information" before starting the charging process.

- 1) Connect USB cable to a general USB power supplier.
- 2) Connect the charger to the correct outlet.
- 3) When the charger is connected to the headset, the red indicator light will turn on. Charging the battery fully may take up to 2 hours.
- 4) When the battery is fully charged, the red indicator light will turn blue. Disconnect the charger from the headset and the outlet. The headset is

ready to use.

NOTE:

- For first time use, please charge the headset fully.

- The fully charged battery has power for up to 5 hours of talk-time and 4hours music playing time, and up to 240 hours of standby time. However, the talk and standby times may vary when used with different mobile phones or other compatible Bluetooth® devices, usage settings, usage styles, and environments. When the battery power is low, the headset will remind you by voice prompt "**Battery low**" every 20 seconds, and the red indicator light starts to flash.

- For using the BWA15AA001 with iPhone, an additional battery meter feature will be activated and the remaining battery capacity will display on your phone.



7. Pair to your Bluetooth® phone

Before you use your headset the first time, you must pair the unit with a Bluetooth® enabled mobile phone. Pairing is a one-time process and required only for the first connection with the Mobile phone. The **BWA15AA001** can be connected with two mobile phones simultaneously.

- 1) Keep the BWA15AA001 within 1 meter range of a Bluetooth®-ready Mobile phone.
- 2) Press and hold the **Power** button for about 4 s, the indicator light will flashes red and blue intermittently, the device is now in pairing mode.
- 3) Find the Bluetooth® setting of your Mobile phone and start the search for Bluetooth® devices. (For further details, please read the operating instructions of your Mobile phone).
- 4) From the list of devices found, select the "BW DYNAMIX".
- 5) If required, enter the PIN code "0000" and confirm the entry. Once the pairing process was successful, the BWA15AA001 will connect to Mobile phone automatically then switch to standby mode, the indicator will flash blue every 5 seconds.

Note:

- 1) If pairing is not completed within 2 minutes, the headset will turn off. If this happens, please repeat the pairing steps.
- 2) The BWA15AA001 supports Multi-connection that allows for the simultaneous use of the BWA15AA001 with two mobile phones. After paring successfully with 2 mobile phones, switch off the headset and switch on

again, the headset will connect to both 2 mobile phones automatically. Otherwise, you can connect the headset on the cellphone manually.

8. Turning headset on /off

Turn on your headset

Slide the power button to On to turn on your headset. If your headset has completed the pairing process successfully, when the headset is turned on, it will connect to the phone you last connected automatically. Please ensure your phone's Bluetooth® function is active.

Turn off the headset

Slide the power button to Off to turn off the headset.

Note:

To conserve power, if the headset is not connected to a device for approximately 10 minutes, the headset will turn off automatically.

9. Using for music play

Play/Pause

Press **Play/Pause** button to get the music play or pause.

Next/Previous song

Push and hold toggle button to track the song to next or previous.

Increase/Decrease volume

Push toggle button to increase or decrease volume.

Note:

The BWA15AA001 supports A2DP profile that allows stereo music streaming from a Bluetooth phone. The music will pause automatically while a call is dialed out/incoming, and resume when the call conversation has ended.

10. Using for phone call**Last number re-dialing**

At standby status, double press the **ANSWER**, the last number you dialed will be re-dialed.

Note: the last number re-dialing is available only for the first device if two Mobile phones are connected. The connection sequence can be determined by reconnect manually.

Answering a call

Press **Power** button shortly to answer the incoming call.

Reject an incoming call

Press and hold **Power** button for 3 seconds to reject the incoming call.

Transferring a call

Press and hold **Volume (+)** for 3 seconds to transfer the call between the phone and headset.

Ending a call

Press the **Power** button shortly to end a call.

Call-waiting

- If there is an incoming call while a call is in progress, press **Power** button shortly to accept the waiting call and end current calling.

- If there is an incoming call while a call is in progress, press and hold **Power** button for 2 seconds to accept the incoming call and place the current call on hold.

Note:The same operation could be performed in case of Multi-connection.

Volume adjusting

Push toggle button to increase or decrease volume.

Mute

While a call is in progress, Push toggle button for 3s to mute the headset, a remindful tone would be heard every 10 seconds. Repeat the operation to un-mute.

11. Camera remote control function

The BWA15AA001 has been built-in camera shutter remote control function for a smart-phone. When the headset has been paired and connected to your mobile phone, launch your camera app, then double press Volume(+) button to shoot a picture.

Note:

- 1) Compatible system
iOS 4.0 or upper
Android 3.0 or upper

This feature may vary when used with different mobile phones, please keep your mobile phone's OS version as new as possible.

- 2) If your phone's virtual keyboard has been hidden when the headset connects to, please double press Volume(-) button to callout the keyboard for text input .

12. Safety and general information

- 1) Please read this User's Manual carefully and follow all instructions.
- 2) To avoid any damage or malfunction of the device do not drop the device from high places.
- 3) Keep device away from humidity, water and any other liquid. If the device is exposed to water, moisture and other liquids do not operate it to avoid any electrical shock, explosion and damage to the device or yourself.
- 4) Do not place or keep this device near any heat sources, such as, direct sunlight, radiators, stoves or other apparatus that produce heat. This may cause an explosion, degrade the performance and/or reduce battery life.
- 5) Do not modify, repair or disassemble device (Especially the battery). Doing this will void the warranty.
- 6) Do not place heavy objects on the device.
- 7) Use only the supplied and approved chargers.
- 8) Unplug this device when unused for long periods of time or during lightening storms.
- 9) The battery used in this device may present a risk of fire or chemical burn if mistreated.

10)

13. FCC Statement

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which

- the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

14. EC Declaration of Conformity

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for ANY interference, for example RADIO or TV interference, caused by unauthorized modifications to this equipment.

Such modifications could void the user's authority to operate the equipment. This product is CE certified according to the provision of the R&TTE Directive (99/5/EC). This declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. Please note that this product uses radio frequency bands not harmonized within EU.

Within the EU this product is intended to be used in Austria, Belgium, Denmark, Finland, France, Germany, Greece, Ireland, Italy, Luxembourg, The Netherlands, Portugal, Spain, Sweden, and United Kingdom and within EFTA in Iceland, Norway and Switzerland.

15. Warranty

The condition of this warranty and supplier's responsibilities under this warranty are as follows:

Warranty is non-transferable and is limited to the original purchaser only.

- You must be able to prove the date of original purchase of the unit with a dated receipt.
- The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by an unauthorized third party.
- Supplier's responsibility shall be limited to the repair or replacement of the product at its sole discretion.
- Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorates and other accessories.
- Supplier is not responsible, for failure resulting from accident, abuse, misuse, or any unauthorized repair, or modification.
- Modification and repair of the unit should be done by an authorized and qualified service center or returned to the manufacturer.
- This warranty gives you specific legal rights, and you may also have other rights, which vary under local laws.