




XBASS

Accessories for your Daily Life Best of the Best



PACKAGE CONTENTS


- XBass speaker system
- USB Charge Cable
- 3.5 mm Audio Cable
- User's Guide

CHARGING XBASS SPEAKER

Charge XBass with the included USB charge cable. Flip open the dust cover, plug the micro end into the socket (5V IN) and the other end into a power USB port like on a computer. You may use any USB AC adapter that is available to charge your XBass speaker.

PLAYING MUSIC VIA BLUETOOTH MODE

1. Make sure the XBass Speaker is fully charged.
2. Turn XBass speaker on by pressing the power button at the top panel. A green led will illuminate and blue led will begin flashing.



3. Follow the instructions for pairing that came with your Bluetooth enabled device. You may have to go into your settings and turn Bluetooth ON. Make sure your device is discoverable or in search mode.
4. Your device should discover "Xbass 001". Select this profile. Once connected, the blue led will blink slowly.
5. You are now connected and play your audio content wirelessly!


USING THE SPEAKERPHONE FEATURE

With the built-in microphone, XBass speaker can be used as a speaker-phone whether you are connected via Bluetooth or AUX.

1. When a phone call comes in, answer it with the (☎) button on the top panel.
2. Speak into the microphone located on the top panel.
3. Your caller's voice will play through XBass speakers.
4. When your call is over, hang up as you normally would on your phone.

PLAYING MUSIC VIA AUX IN MODE

1. Make sure the XBass speaker is charged
2. Turn the XBass speaker on by pressing the power button at the top panel. A green LED will appear when on.




3. Connect one end of the included 3.5 mm audio cable to the "AUX IN" port on the side of the unit. Connect the other end to the 3.5mm headphone jack of your audio device.

Note: Connecting the audio cable will override Bluetooth mode. XBass will automatically switch to auxiliary when the audio cable is connected.

4. Make sure the volume of your audio device and the volume of XBass are both set to medium/low.

PLAYING MUSIC VIA AUX IN MODE

1. Make sure the XBass speaker is charged
2. Turn the XBass speaker on by pressing the power button at the top panel. A green LED will appear when on.
3. Connect one end of the included 3.5 mm audio cable to the "AUX IN" port on the side of the unit. Connect the other end to the 3.5mm headphone jack of your audio device.



Note: Connecting the audio cable will override Bluetooth mode. XBass will automatically switch to auxiliary when the audio cable is connected.

4. Make sure the volume of your audio device and the volume of XBass are both set to medium/low.

VOLUME UP AND DOWN

Press the volume up (+) and down (-) buttons to adjust to your desired volume. You can also adjust the volume on your audio device.

XBASS BUTTON

Activate the super bass on your music by pressing down the Xbass button located on the side of the speaker.

LED DISPLAY

Activate the led display by pressing the led mode button located on the speaker. The music flash mode will only work when the speaker is paired and music is playing. Press the led mode button repeatedly to cycle through the modes.

TROUBLE SHOOTING

Problem: Bluetooth not connecting.

Solution: Please consult the User Guide of your Bluetooth enabled audio device for instructions. Make sure that both of your audio device and XBass speaker are discoverable and charged. Try rebooting the speaker by turning it off then back on. Make sure someone else is not already connected.

CAUTION:


When you plug the charge cable into speaker and the RED charging LED not light up that means the battery was going into the Self Protection Mode. Please wait 5-10 minutes until the RED light to turn on.

xbass flash音箱

- USB充电电线
- 3.5毫米音频电线
- 用户指南

为你的xbass音箱充电

请使用附带的USB充电电线来为你的xbass音箱充电。将micro端插入位于扬声器后方插槽（5V IN），另一端插入任何有通电的USB端口。您可以使用任何USB AC变压器来为你的音箱充电。



透过蓝牙模式播放音乐


1. 确保你的音箱已经完全充满电。
2. 打开音箱的侧面的开关。绿色led会常亮，蓝色LED会闪烁并进入配对模式。

3. 按照附带的蓝牙设备进行配对的说明。您可能需要进入设置并打开蓝牙。请确保您的设备是可发现或搜索模式。
4. 你的设备应该发现“xbass flash”。选择此配置文件。一旦连接成功，蓝色LED指示灯将会缓慢闪亮。
5. 您现在已连接并可以无线方式播放音频！

使用免提通话功能

有了内置的麦克风，无论你是通过蓝牙或AUX连接，你的音箱都可以作为一个扬声器。

1. 当一个电话进来，按音量转钮中间的接听来接听电话。
2. 麦克风位于顶部。
3. 你的来电者的声音将通过音箱的扬声器播放。
4. 当您的通话结束后，在手机上挂机就可以续放音乐。



播放音乐AUX IN模式


1. 确保蓝牙音箱已经完全充电
 2. 将蓝牙音箱侧面的开关推至开。绿色的led会显示音箱已开，此时蓝色LED会闪烁并准备连接你的设备
 3. 将附带的3.5毫米音频电缆的一端连接至设备侧面的“AUX IN”端口。将另一端连接到您的音频设备的3.5mm耳机插孔。
- 注：连接音频线将覆盖蓝牙模式。音箱会自动切换到aux in模式。
4. 请确保您的音频设备的音量和EQ的音量都设置为中/低。

调整音量大小

按音量向上 (+) 和向下 (-) 按钮来调整到你想要的音量。您也可以从你的音频设备上调整音乐。

XBASS按钮

如需激活超级重低音，此音箱有加强低音钮。



LED显示屏

如需激活LED显示屏请按下LED按钮，五种不同的灯光效果，选择其中一款可跟音乐互动。音乐互动的闪烁灯光只能在音乐开的模式之下使用。

故障排除

问题：没有蓝牙连接。

解决方案：请咨询您的蓝牙音频设备的有关说明，用户指南。确保两个音频设备和音箱都可以被发现和充电。尝试将其关闭然后再重新打开重新启动扬声器。确保是不是别人已经连接到扬声器。

注意事项:

如喇叭在插入充电线时充电红灯未亮这代表喇叭电池进入保护状态，请耐心等待5-10分钟，充电灯便会正常亮起来。

保修卡

用户填写资料: _____

公司或个人全名 _____

通讯地址 _____

电话 _____ 邮编 _____

所购产品名称及型号 _____

经销商名称 _____

购买日期 _____

尊敬的用户:

感谢您选择ITA品牌音箱产品，希望能给您生活增添色彩。为了提升我们服务水平以便我们更好为您服务，请认真填写保修卡资料。

产品信息及技术支持:

如需查询任何产品相关信息（产品操作方法，规格说明，维修方式及ITA授权维修代理商等），及有关ITA最新信息请随时查阅ITA官方主页。

深圳创微索电子有限公司

地址：深圳市宝安区福永街道办凤凰第三工业区第一工业园A栋

电话：0755-21630920 21630921 21630922

www.itech-acc.com

邮编：518100

Federal Communications Commission (FCC) Interference

Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment must not be collocated or operating in conjunction with any other antenna or transmitter.