



Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna,
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

### BATTERY SAFETY INFORMATION

- Non-rechargeable batteries are not to be recharged.
- Do not use rechargeable batteries.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Battery should always be replaced by an adult.
- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Different types of batteries, or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely. Do not dispose of in a fire as batteries may explode or leak.
- Please retain this information for future reference.

**The Wiggles**  
**RC Big Red Car**  
 Drive the car forward and backward with radio control

CE

5

**The Wiggles**  
**RC Big Red Car**

5

**The Wiggles**  
**RC Big Red Car**

Just back, when you remove the Big Red Car, it will be removed or functional!

5

**The Wiggles**  
**RC Big Red Car**

Drive the Wiggles RC Big Red Car forward and backward with radio control. The car is controlled by a remote control. The car is made of plastic and is suitable for children aged 3 and over. The car is 10cm high and 15cm wide. The car is made of plastic and is suitable for children aged 3 and over. The car is 10cm high and 15cm wide.

5

**The Wiggles**  
**RC Big Red Car**

When you remove the Big Red Car, it will be removed or functional!

5

**The Wiggles**  
**RC Big Red Car**

Cozy plays in the Big Red Car. We have to sing!

←-- CORR -->

