



ATD
User Manual

July 2010



Copyright 2008 Altierre Corporation--All Rights Reserved.

This document contains confidential information. Reproduction, adaptation, or translation or sharing with third party requires prior permission

Publication Number: July 2010

Applicable Product: Altierre ATD

Disclaimer

Information and specifications in this document are subject to change without notice.

Altierre Corporation may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document.

Except as expressly provided in any written license agreement from Altierre Corporation, the furnishing of this document does not grant any license to the patents, trademarks, copyrights, or other intellectual property covering the subject matter enclosed herein.

The names of actual companies and products mentioned herein may be the trademarks of their respective owners.

Altierre Corporation
1980 Concourse Drive
San Jose, CA 95131

Class B digital devices

“This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.”

Changes or alterations to the Altierre ESL System not expressly approved by Altierre could void the user’s authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

“To satisfy RF exposure requirements, this device and its antenna must operate with a separation distance of at least 20 centimeters from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.”



ATD User Manual

The Altierre Tethered Device or ATD is a USB device that connects to a standard Windows PC. It is used to initialize eSigns for subsequent linking to store products.

Enable eSign

Step 1

Place the eSign on the ATD and click 'Enable eSign' to start the enable process.

Disable eSign

Step 1

Place the eSign on the ATD and click 'Disable eSign' to start the disable process.