

Connecting Via WiFi

If you need to charge the device while connected via WiFi you can plug the USB-C cable to a power adapter or PC/MAC.

Note: You cannot transfer data through USB-C at the same time.

Required hardware/accessories



- ① microSD Memory Card* (not included)
- ② Type-C to Type-C Cable (included)
- ③ Power Adapter** (not included)

* Class 10 or above read/write speed

**Power adapter equipped with Type-C port (5V/2A)

WiFi Data Transfer

Using Infiniti Kloud App (iOS & Android)
(Does not provide network data)




Connecting to PC/Mac

Required hardware/accessories

- ① MicroSD Memory Card* (not included)
② Type-C to Type-C cable (included)

* Class 10 or above read/write speed



Status LED

Power Button

USB 2.0 TYPE C

MicroSD Card Slot

IMPORTANT SAFETY INFORMATION

Caution: Do not use device if there is obvious damage.

Warning: Choking hazard. This device is not a toy. Keep away from children.

Important Instructions Before Use

1. Device should only be used for the intended purpose as outlined in the instructions.
2. Do not expose device to moisture or extreme heat.
3. Do not submerge device underwater. Do not expose to liquid, smoke, or steam.

How to Use the Product Wirelessly

1. Insert your MicroSD card into the MicroSD card slot of the device.
2. Turn on the device (Press and hold the power button for 3 seconds).
3. Open the phone/tablet settings > Enable WiFi > Search WiFi "InfinitiKloud Wireless" > Enter connection password (No password by default. You can set the password on Infiniti Kloud App).
4. Upon successful WiFi connection, the indicator light will blink several times. Open the Infiniti Kloud app and you're ready to go.

How to Use the Product with PC/MAC (wired)


Connect the device to PC/MAC using the data cable. When detected, open the folder and click to run the Infiniti Kloud APP to get started. (When connected to PC/MAC, the device cannot be accessed via WiFi).

How to Charge the Product

When the device needs charging, connect to a power source. It takes about 1.5 hours for a full charge. When fully charged, it allows about 2 hours of continuous use.

Custom Backup

File Types




If you wish to back up specific file types, select “File Types”. There will be a list of file formats from which you can select to back up.

There are boxes beside the file formats, either with or without a checkmark. The checkmark indicates that the file format is selected to be backed up. If you wish not to back up that format, ensure that it does not have a tick next to it. Click on the boxes to either check or uncheck them.


Once selected, press the red “Start” button to begin backing up those files.

Backup Location

You can also specify the file locations from which you want to back up your files.



By selecting “Back up only these folders”, you can add specific paths to perform backups.




You can also combine custom backups of File Types and Backup Location.

InfinitiKloud User Guide

To begin using InfinitiKloud Wireless, simply plug in the provided USB Type-C cable to your device and PC/MAC. The InfinitiKloud software will appear in your folders. Open your folders (“File Explorer” for PC, and “Finder” for Mac), and click on the InfinitiKloud icon to start up the program.


Below is what the program should look like. There are tabs on the left indicating each functionality of the InfinitiKloud. Clicking on each tab will enable you to use those functionalities.



To change the language, hover over the drop-down menu in the bottom left corner of any screen and select your desired language. InfinitiKloud is available in English, German, French, Portuguese.

My Files

To view your backed-up files, go to the tab labeled “My Files”. They will appear in the same folders and formats as they are on your computer. You may look through your folders manually or also use the search tool to find specific files. From there, you can view, export, and delete files. Keep in mind that deleting a file from the InfinitiKloud will not delete the file from your computer. You can back up your data as much as you want. If the backed-up file has been updated, the InfinitiKloud will back up the latest version but still keep the previous one(s).




Data Cleanup

This is where you can decide how the data is cleaned up. Click on the gear icon on the bottom left corner. Select “User data”.



Clean Up Your Data

This will erase all backed up data of InfinitiKloud including your pictures, music, videos, documents, and other backed up files.




Passcode Settings

To better protect the data that you have backed up, there is a passcode setting that allows you to create your own passcode. The private passcode must include 4 to 6 digits. You will be asked for this passcode when InfinitiKloud is launched. Below are detailed instructions for use of this security feature.


Passcode is enabled across supported platforms: Windows, Android and macOS.

Enable Passcode

Click on the gear icon on the bottom left corner. Select “Passcode settings”.



Toggle the “Turn on Passcode” switch to the right to activate.




If you wish to remove passcode security, go to Passcode settings. Toggle the “Device passcode required” switch to the left to deactivate.

The passcode will no longer be required to access the InfinitiKloud app.


Set a Passcode

Enter your chosen passcode. It should be 4 to 6 digits long. Click “OK” when complete.



Change or Disable Passcode

Go to Passcode settings, enter the current passcode and new passcode of your choosing and click “Change Passcode”.



InfinitiKloud Android or iOS App

Use our Google Play or App Store mobile app to back up your mobile devices with one tap. There are 2 ways to download the app:

1. On your Android device or Mac, open Google Play or App Store and search “Infiniti Kloud”. Then Download the app.
2. Google Play link: <https://play.google.com/store/apps/details?id=com.infinitikloudmobile>



Technical Specifications

USB type	USB 2.0 TYPE-C
Read/write speed	Class 10 or above
Battery	600mAh
Size	H65 x W50 x D15mm

FCCID: 2AVK9-30342 Product: InfinitiKloud Wireless Model: 30342
The device complies with the European Directives 2014/30/EU.

At the end of its service life, this product may not be disposed of in the normal household waste, but rather must be disposed of at a collection point for recycling electrical and electronic devices. The materials are recyclable according to their labelling. You make an important contribution to protecting our environment by reusing, recycling, or utilizing old devices in other ways. Please ask the municipal administration where the appropriate disposal facility is located.
Subject to change.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.