


Wireless Mouse User Guide

Wireless Mouse is designed for use conveniences with PC in any environment and with an effect operation range of up to 5 m. The Mouse receiver to be connected with USB port and the wireless mouse freely move without any cord.

Features & Description

1. **3D Scroller** can be used for scrolling up and down the display when using IE browser or Windows application.
2. **High Resolution** provides 800 dpi precision tracking which is twice the resolution of a typical ball mouse.
3. **LED indicator** provides the mouse using status.
4. **Plug & Play** support and no need any drivers to install.

Major components



Note: You can use the "USB to PS/2 adapter (option)" to connect PS/2 Port on PC.

INSTALLATION

Installation of receiver

Wireless Mouse connect receiver with digital wireless technology. You are free of connection cable, avoidable of shortcoming of infrared transmit, necessary to shoot against receiver, and enjoyable of the benefit.


Please install directly receiver to USB or PS/2 port. Please follow below diagram and steps.

- 1.Turn off you PC.
- 2.Connect the USB port.
- 3.Use USB to PS/2 adapter to connect the PS/2 port.



Installing Batteries

- 1.Press the battery button and slide the cover backward.
- 2.Insert two AAA batteries correctly into compartment.
- 3.Replace the cover.
- 4.Change the channel, please refer to channels Setting.




Battery button

INSTALLATION

Channel setting

1. Press the channel button on the USB Receiver.
2. Press the channel button on the mouse.
3. Move the mouse or press any button.



LED indication

LED	Status	Indicition
The Led is on shining	Power on	The mouse power on
The LED is shining when the computer is turned on	Normal	The mouse is connecting with the computer
The LED is no shining during use	No detected	Disconnected! please refer to trouble shooting
The LED is flashing	Channels Searching	When you change channels, the LED will flashing.
The LED is flashing during use	In use	When the connection is normal.

Caution: Do not set the ID of mice while computers are being Turned on.

TROUBLE SHOOTING

Trouble shooting

- I. mouse dose not work
 1. Make sure the receiver's connector is okay.
 2. Make sure the batteries is adapted and normal.
 3. Use a mouse pad. Especially the working panel is metal.
 4. Change the channel, please refer to channels setting.
- II. mouse is not detected
 1. Make sure the receiver's connector is okay. When power is on do not plug in or unplug out.
 2. Make sure your port is okay, refer to your computer documents.
 3. Other computer device interfere your mouse. Please refer to IRQ detailed document, change the setting if necessary.
 4. Conclude whether the problems comes from the mouse or the system.
 5. Replace batteries
- III. the cursor dose not move on the screen
 1. Clean the mouse ball and roller
 2. Replace batteries
 3. Change another channel or readjust the receiver's position.
 - If you fail to connect few times during the normal operation, please rest the computer.

Maintenance

1. Open the ball cover anti-clock, and remove it.
2. Clean the ball with clean dry clothes.
3. Clean the roller using a cotton swab dipped with alcohol.
4. Reinstall the ball and ball cover.

FCC & CE approval