

T464 II Operation Manual

(K2MA-1)

BUTTON ① : A. Press and release to Arm/Disarm.
B. Press and hold for 4 seconds to activate panic mode.

BUTTON ② : A. Quickly press and release to Arm/Disarm with no siren chirp(silent).
B. Press and hold for 2 seconds to activate AUX channel #1.

BUTTON ①+② : Press together for 1.5 sec. to activate AUX channel #2.

Remote Transmitter Programming

1. Turn Ignition ON and OFF 3 times quickly, leaving it ON the 3rd time. (ON/OFF, ON/OFF, ON) You should hear (3) chirps.
2. Press the Program/Override Button 5 times and you should hear 5 light flashes and 5 siren chirps.
3. Press #1 (LOCK/UNLOCK) Button on the new transmitter. Siren chirps one time for Code-learn confirmation. Press #1 Button on a second, third or fourth remote at this time (If needed).
4. Turn OFF Ignition. Siren will chirp 3 times and lights will flash 3 times for exit confirmation.

Note 1: This system will learn a total of 4 transmitters max.

Option Programming

1. Turn the Ignition ON and press the Override/program button 5 times. You should hear a long confirmation chirp.
2. Within the next few seconds, press the Override/Program button [again] the number of times that corresponds to the feature list below. The siren will chirp for each button press. DO NOT LOSE COUNT!!
3. When you get to the desired option number, press the appropriate button on the transmitter according to the chart below. Turn Ignition OFF. See below for Option numbers, description, and values. (Button 1 give a single light flash/chirp, Button 2 give two light flashes/chirps, and Button (1+2) together gives three light flashes/chirps.)
4. Change One option at a time repeating steps 1-3 as needed. When you are finished customizing options, check operation to see if the option(s) have changed.

Programming Options Chart

*=Default Settings

Option #	Option Description	Button 1 LOCK	Button 2 UNLOCK	button (1+2) Together
1.	Factory Horn Chirps / Pulses	Pulse with trip only	Arm/Disarm Chirps & Pulse with trip	Arm/Disarm/Warn Chirps & Pulse with trip *
2.	Passive Arming / Passive Chirp Countdown	ON	OFF*	Passive Arm with Chirp Countdown
3.	Passive Lock / Custom Override	ON	OFF*	Custom Override
4.	Ignition Controlled Locks	ON*	OFF	Ignition Lock Only
5.	10/60 Sec. Door Open Warning	10 Sec.	60 Sec.	
6.	Active Re-Arm	Enabled*	Disable	
7.	Double Unlock Pulse	Disabled*	Enable	
8.	Silent Arm/Disarm (Chirp Defeat w/Button 1)	Disabled*	Enable	
9.	Parking Lights on with Disarm	Enabled*	Disable	
10.	Disarm with trunk pop	Disabled	Enabled*	
11.	Silent Arm/Disarm with Remote (Button #2)	Enabled*	Disable	
12.	Door Lock Pulse Time	0.7 Sec.*	3 Sec.	
13.	Type of CarJack Protection	Active*	Passive	
14.	Carjack Feature Enable/Disable	Disabled*	Enabled	
15.	Arm/Disarm with Ignition ON (**Overrides Carjack functions)	Disabled*	Enabled**	

NOTE: Options can be instantly restored to Factory Default Values: To Restore default values: Perform step #1 above, then press button (1+2) together. The siren will chirp 4 times and lights will flash 4 times. Turn OFF Ignition. All programming options should be restored to "*" values (See chart above).

T464 II Operation Manual

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment

IMPORTANT NOTE : To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void users authority to operate the operate the device.