

APT-1320 INSTRUCTION

INSTALLATION:

APT-1320 own easy-to-use and simple installation feature .

- 1.Plug adaptor into the power outlet (Fig.1) .
- 2.Plug appliance into the socket of receiver(Fig.2).
- 3.Remove the insulating tab on the back of transmitter(Fig.3) .
- 4.Make sure your appliance is turned on , when power is connected , you can turn on /off your appliance by pressing the buttons on the transmitter .




figure 1




figure 2




figure 3

5.If the indicator light doesn't work , it is possible that the fuse has been burned, to replace a new fuse is required.

6.The appliance attached to each outlet of receiver can be controlled individually. .

SAFE CAUTIONS:

- 1.The receiver is forbidden to use in damp area (cellar , swimming pool , etc.) or outdoors(court , corridor etc.)
2. The receiver is forbidden to use in the explosive and inflammable place (garage, boiler room, painting room and storage room etc.)
3. The power of appliance attached to the receiver can not exceed 1000W, otherwise the fuse in the receiver will be burned , the fuse can be replaced .

SPECIFICATION :

VOLTAGE : AC 110±10V/60Hz

LOAD : 1000W MAX.(for each outlet)

FREQUENCY: 303.875MHz

DISTANCE : 100feet Max.

FUSE: 10A



The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To comply with the FCC RF exposure compliance requirements, this device and its antenna must not be co-located or operating to conjunction with any other antenna or transmitter.