


INSTRUCTION MANUAL

SoundArt



Parts:

1. 3.5mm AUX input
2. Power switch: on/off
3. Micro USB charging port
4. LED indicators (red LED on means charging and LED off means end of charging; blue LED on means wireless pairing and LED off means end of pairing)

Accessories:

USB Charging Cable (2m) x 1pc
Instruction manual x 1pc

Specifications:

Product Size: L310 x W223 x H23mm
Speaker: 24mm 4 ohms
Rated power: 3W

Battery Parameters:

Capacity: 500mAh, 3.7V, Li-ion Battery
Music Playback Time: 5 hours at 70% Volume
Charging Standard: DC 5V, 500mAh
Charging Time: Around 1 hours

Wireless Parameters:

Operation Frequency: 2.400GHz - 2.480GHz
Power Output (Peak): Class 2 / 2dbm
Received Sensitivity: -85dbm
Operating Range: Around 8-10m

Operations with mobile:


1. Turns on the power of speaker
2. Activate wireless connection in mobile
3. Search the wireless devices named as "SoundArt"
4. Pairing
5. Connect and play music

Compatibility:

- Be applicable to most wireless devices
- Be applicable to most 3.5mm audio out devices

Placement:

SoundArt can place in vertical / horizontal on the table.



Troubleshooting:

1. Wireless is a bidirectional transmitting protocol; transmitting distance is highly related to the audio player.
2. When the speaker cannot be connected, please delete the rest Wireless devices name on the list of user's computer / mobile phone. Then, follow the steps in operation instructions.
3. The sound performance could also be affected under poor signal environment, or product is low battery capacity. Please move the product to environment with strong signal or charging the product.

Caution:

- This product must for indoor use.
- This product is not suitable to use in bathroom, high humidity and high temperature environment.
- This product is not suitable for children under 36 months due to small parts.
- This product is not a toy. Please retain these instructions.
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

Environmental Friendly Disposal

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.



FCC ID: RVX-FP0001

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

2157 instruction manual
size:180 x 105 mm